


Console Desk

Assembly Instructions - Please keep for future reference



Dimensions

Width - 110cm
Depth - 50cm
Height - 75.5cm

Important – Please read these instructions fully before starting assembly



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on pages 2 and 3.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



- We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.
- Dispose of all packaging carefully and responsibly.


Care and maintenance

- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Glass care and maintenance

- Do not place very hot or cold items on the glass surface(s) unless adequately thick table mats or coasters are used to prevent such items from coming into contact with the glass
- Do not sit or stand upon the glass.
- Do not use the glass as a chopping surface.
- Do not strike the glass with hard or pointed items.
- When cleaning glass panels use a damp cloth or leather with washing up liquid or soft soap if necessary: do not use washing powders or any other substances containing abrasives since these substances scratch glass.

Tools required




Crosshead screwdriver
(medium & large)



Small
hammer

Components - Parts

Please check you have all the parts listed below



- 1** - Top
- 2** - Left Side
- 3** - Left Central Upright
- 4** - Right Central Upright
- 5** - Right Side
- 6** - Back Panel
- 7** - Base
- 8** - Leg
- 9** - Left Drawer Side
- 10** - Right Drawer Side
- 11** - Medium Drawer Back
- 12** - Medium Drawer Base
- 13** - Medium Drawer Front
- 14** - Large Drawer Back
- 15** - Large Drawer Base
- 16** - Large Drawer Front
- 17** - Small Drawer Back
- 18** - Small Drawer Base
- 19** - Small Drawer Front



A × 16



B × 10



C × 18



D × 3



E × 10



F × 12



G × 12



H × 12



I × 12



J × 1



K × 1



L × 6



M × 6


Assembly Instructions

Step 1

a: Tighten 10x Camlock Bolts (A) to Top **1**.

Use 3x Small Screw (D) to attach Plastic Stopper (D) to Top **1**.

a:




b: Fit 9x Dowel (C) to Top **1**.

Sit panels **2**, **3**, **4**, **5** and **6** onto Top **1** - as shown in image b.


Add 10x Camlock Nut (B) to panels **2**, **3**, **4**, **5** and **6** then rotate in a clockwise direction to tighten.

b:



c: Insert remaining 9x Dowel (C) into panels **2**, **3**, **4**, **5** and **6**.

c:




Assembly Instructions

Step 2

d: Sit Base **7** onto Dowels (C) then secure by screwing in 10x Screw (E).


d:



e: Mount 4x Legs **8** to the Base **7** using the Hex Key (J), Bolt (G), Sprung Washer (I), Washer (H).

e:

Each Leg **8** requires 3x Bolt (G) to secure. Repeat this process to fit all Legs **8**.



Assembly Instructions


Step 3

f: Insert 2x Dowel (F) into Medium Drawer Back **11**. Secure Left Drawer Side **9** and Right Drawer Side **10** to the Medium Drawer Back **11**.

Slide Medium Drawer Base **12** into the groove of the drawer frame.


Screw in 2x Camlock Bolt (A) to the Medium Drawer Front **13**. Fix Medium Drawer Front **13** to the frame then add 2x Camlock Nut (L) to Left Drawer Side **9** and Right Drawer Side **10**. Tighten 2x Camlock Nut (L) to complete the first drawer.

f:



g: Repeat the process as above, however use Large Drawer Back **14**, Left Drawer Side **9**, Right Drawer Side **10**, Large Drawer Base **15** and Large Drawer Front **16**.

g:




Assembly Instructions

Step 4

h: Repeat process again using Small Drawer Back **17**, Left Drawer Side **9**, Right Drawer Side **10**, Small Drawer Base **18** and Small Drawer Front **19**.


h:



i: To mount the desk to the wall, attach Wall Mounting Strap (K) to the rear of the unit, using a Washer and Small screw provided.

Using the wall plug guide on the next page, attach the Wall Mounting Strap (K) to the wall to complete assembly.

i:



Assembly is complete.

A Guide to - Wall Mounting & Fixings

Important note:

If plastic wall plugs are supplied with your product:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to using incorrect fixings is the responsibility of the installer.



Important: When drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.


Hints:

- 1: General rule:** Always use a larger screw and wall plug if you are not sure.
- 2:** Ensure you use the recommended drill bit to match the wall plug and hole size.
- 3:** Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.
- 4:** Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.
- 5:** Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.1 "General Purpose" wall plug




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.2 "Plasterboard" wall plug




For use when attaching light loads on to plasterboard partitions.

No.3 "Cavity Fixing" wall plug




For use with plasterboard partitions or hollow wooden doors.

No.4 "Cavity Fixing-Heavy Duty" wall plug




For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No.5 "Hammer Fixing" wall plug



For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.6 "Shield Anchor" wall plug Heavy loads



For use with heavier loads such as TV & HiFi speakers and satellite dishes etc.



Care & Maintenance

Safety: Always check the fitting and location to ensure your safety in and around the home.

Fitting: From time to time check the fitting to ensure the wall plugs or screws do not become loose.