



# ASSEMBLING & INSTALLATION INSTRUCTIONS

The drawing shown may not exactly match the product enclosed.  
However, the installation instructions do apply to this product.

**\*\*\*WARNING! SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER.**

**\*\*\*ATTENTION! COUPER LE COURANT AU FUSIBLE OU UN DISJONCTEUR.**

1. Pull wires through post base. Aligning the bottom column with the three screw holes on the base. Fix the middle column to bottom column using three (3) machine screws as shown on FIG

2. Secure Anchor Bolts: All three (3) anchor bolts must be assembled onto mounting plate (template) with 1 hex nut above and 1 hex nut below locking in mounting plate so that threaded portion protruding from mounting plate measures 1-1/2"(38mm) and cast into cement as shown on FIG.1. Cement Base should be a minimum of 18" (46cm) wide by 2-3 feet deep (61-91cm)(depending on area frost line). Anchor Bolts should extend 1-1/2"(38mm) out of the cement. After Post Base is placed on top of Cement Base, Anchor Bolts can not protrude more than 1/4" (6mm) from Post Base.

3. Once the cement is fully dried, place the post light over the anchor bolts and pull electrical wire through hole. Secure post base to concrete with three (3) cap nuts threaded over anchor bolts as shown on FIG.

NOTE: Make sure that Electrical Wiring Connections are made AFTER the Center Body Assembly is treaded and secure.

4. Electrical Connections: Connect the bare copper wire to the green ground wire on the socket to a bare ground wire at the bottom of the base and screw a wire nuts to the wiring point. Connect the white extension wire and the white wire on the socket to the reserved power neutral wire and screw a wire nuts to the wiring point. Connect the black wire from central body and the black wire on the socket to the reserved power live wire and screw a wire nuts to the wiring point. Secure three wire nuts with electrical tape (not included).



