

GoBar® PRO

Included:


GoBar® Pro Frame



Storage Shelf



Black Skirt



Carrying Case



Warning Read Before Use:

Injury and/or damage may occur if failure to do the following:

- Never stand or sit on the GoBar®, do not use for any other purpose than its intended function.
- Always set up the GoBar® on a flat even surface. Failure to do so may cause the bar to tip over causing damage.
- Be aware if using GoBar® in high winds, the front skirt can cause the bar to tip over.

Weight Limits:

- Bar Top Maximum Weight: 30 pounds
- Shelf Maximum Weight: 50 pounds

Note: Front skirt is machine washable. Follow instructions on the wash tag on the skirt.


Set Up:

Assemble on a soft, non-abrasive surface to prevent damage to the GoBar®.

1. Begin by laying the table on its side and fold out both legs.
2. Ensure the hinges are fully extended and then **lock the hinges** by sliding the locks over the hinge on both sides.
3. With 2 adults, flip the table upright.
4. Snap the storage shelf into place on the two cross supports on the legs.
5. Attach the skirt onto the frame.
6. Finally check to make sure the table is sitting flat. Use the adjustable feet to add stability if needed.

How to Fold:

1. First remove the skirt from the frame and remove the storage shelf.
2. With 2 adults flip the table on its side.
3. **Unlock the hinges** by sliding the locks up, then pop the hinges in.
4. The side with the extended bracket must be folded last, so fold the other side in first.
5. With the legs properly folded, store the GoBar® in the included carrying case in a dry cool place protected from the elements.



Fold side with larger bracket last

Customer Service:

If you have any questions or concerns regarding your GoPong® GoBar® Pro, please reach out to us at info@pandpimports.com and we will get back to you right away. We 100% stand behind our products and want to make sure you get the full enjoyment that you paid for. Enjoy!

Warranty Information: GoPong.com/warranty