


ASSEMBLY INSTRUCTIONS

COD01 Storage Cabinet



Thank you for purchasing our product!

Please refer and use this assembly instruction to assemble the product.

Contact our customer service department in case there are any missing or damaged parts or hardware. Please also tell us your "Order ID", We will solve for you as soon as possible.

EMAIL: customerservice@hkfoam.com

ASSEMBLY PREPARATION:

1. Remove all packaging materials, staples and packing straps from the carton.
2. Refer to Parts List and Hardware List and ensure they are correct before assembly. Contact customer service for missing parts.
3. Place all wooden parts on a clean, flat and soft surface (e.g. carpet or rug) to prevent parts from getting scratched.

SAFETY PRECAUTION:

1. Keep all hardware parts out of reach of children.
2. Dispose plastic packaging material immediately to avoid any risk of suffocation to children and animals..

TIPS FOR ASSEMBLY:


1. Allow ample room for assembly and in close proximity to where product will be placed.
2. Assemble the product on a surface that does not scratch or damage the exterior gloss and finish of the furniture.
3. Identify all of the parts, hardware and quantities required for each step.
4. During assembly, do not over-tighten any fittings as this may cause damage.
5. DO NOT USE POWER TOOLS TO ASSEMBLE THIS PRODUCT.
6. Always place the product on a flat, level surface.
7. Do not sit or stand on the partially assembled product; only use the product for which it is intended.

CARE AND MAINTENANCE:

- Use a slightly damp cloth to clean the product. Do not use bleach or abrasive cleaning material.
- Check all the fittings periodically and re-tighten as necessary. Do not use the product if any of the parts is damaged or broken.
- Never allow any kind of liquid to remain on your furniture. Absorption can cause wood to warp or delaminate.
- Do not place hot items (e.g. hot drinks) directly onto the wood surface.

















Part List

Please check if all the pieces listed below are received



Hardware List

Please check if all the pieces listed below are received

<p>A Cam bolt</p>  <p>110pcs</p>	<p>B Cam lock</p>  <p>110pcs</p>	<p>C Screw</p>  <p>94pcs</p>	<p>D Screw</p>  <p>40pcs</p>	<p>E 11.8in drawer slide</p>  <p>12pcs</p>
<p>F Plastic wedge</p>  <p>8pcs</p>	<p>G Screw</p>  <p>6pcs</p>	<p>H Light strip</p>  <p>1pcs</p>	<p>I Remote control</p>  <p>1pcs</p>	<p>J Light strip clip</p>  <p>4pcs</p>
<p>K Power strip</p>  <p>1pcs</p>	<p>L Screwdriver</p>  <p>1pcs</p>	<p>M Anti-tip plate</p>  <p>2pcs</p>	<p>N 13.8in drawer slide</p>  <p>4pcs</p>	<p>O Non-slip pads</p>  <p>2pcs</p>
<p>P Non-slip pads</p>  <p>6pcs</p>				

**ASSEMBLY
REQUIREMENTS**

3 Hours
Assembly Time
(Approximate)

2 -Person Assembly




Tools Required (Not Provided):


Power Drill




HOW the knock down assembly system work



CAM LOCK SYSTEM OPERATION



1. Screw the cam bolt [A] into the threaded insert on the panel.
2. Connect both panels together making sure cam bolt [A] goes into the pre-drilled large hole on the end of panel for cam lock [B].
3. Insert the cam lock [B] into the pro-drilled large hole on the panel. Make sure the cross slot of cam lock [B] faces out (The arrow should point towards Screw No. A).
4. Rotate the cam lock [B] clockwise with a self-supplied phillips screwdriver to lock the cam bolt [A] in place (Rotate 100-180 degrees until tight).







Hardware installation demonstration

- Before installing the drawer rails, you need to split rail No. E into outer rail No. E1 and inner rail No. E2

1. Place the rail No. E as shown in picture, Then Pull out the E2



2. Find the latch position, press it and split.




Warm Reminder: Press it and split

Step 1



I. Use screws (C) to attach the slide rail (E1) to panels (1).

This is the front view of slide rail (E1).

From the front side of the slide rail, install screws (C) to secure slide rail (E1) to panel (1).



This is the back view of the slide rail, clearly showing which holes on slide rail (E1) are used to install screws (C).




C	X9
E1	X3

Step 2



I. Use screws (C) to attach the slide rail (E1) to panels (3).

This is the front view of slide rail (E1).

From the front side of the slide rail, install screws (C) to secure slide rail (E1) to panel (3).






This is the back view of the slide rail, clearly showing which holes on slide rail (E1) are used to install screws (C).



C	X9
E1	X3


Step 3

I. Screw in cam-bolt (A) into the designated holes on panel (1,3).




Step 4

I. Use screws (C) to attach the slide rail (E1) to panels (2).





This is the front view of slide rail (E1).

From the front side of the slide rail, install screws (C) to secure slide rail (E1) to panel (2).





This is the back view of the slide rail, clearly showing which holes on slide rail (E1) are used to install screws (C).





Step 5

I. Rotate panel (2) 180 degrees, use screws (C) to attach the slide rail (E1) to panels (2).

This is the front view of slide rail (E1).
From the front side of the slide rail,
install screws (C) to secure slide rail
(E1) to panel (2).



This is the back view of the slide rail,
clearly showing which holes on slide
rail (E1) are used to install screws (C).







Step 6

I. Screw in cam-bolt (A) into the designated holes on panel (2).

Note: Install cam-bolt (A) on panel 2, please use a manual screwdriver.



It is not recommended to use an electric screwdriver.



Step 7


I. Attach panel (4,5,6,6,6) to panel (3), insert cam-lock (B) into the panel (4,5,6,6,6), then turn clockwise to lock onto cam-bolt.

Note: The direction of installing cam-lock (B) is shown in the figure





Step 8

I. Install panel (23) as per diagram and slide them into the grooves until they are fully seated.



Step 9



I. Attach panel (2) to panel (4,5,6,6,6,23), insert cam-lock (B) into the panel (4,5,6,6,6), then turn clockwise to lock onto cam-bolt .



Step 10


I. Attach panel (4,5,6,6,6) to panel (2), insert cam-lock (B) into the panel (4,5,6,6,6), then turn clockwise to lock onto cam-bolt.

Note: The direction of installing cam-lock (B) is shown in the figure





Step 11

I. Install panel (23) as per diagram and slide them into the grooves until they are fully seated.




Step 12

I. Attach panel (1) to panel (4,5,6,6,6,23), insert cam-lock (B) into the panel (4,5,6,6,6), then turn clockwise to lock onto cam-bolt.





Step 13

I. Install panel (23,23) as per diagram and slide them into the grooves until they are fully seated.





Step 14

I.Screw in cam-bolt (A) into the designated holes on panel (9).



Step 15

I.Screw in cam-bolt (A) into the designated holes on panel (8,11).




Step 16



I. Use screws (C) to attach the slide rail (N1) to panels (11).



This is the front view of slide rail (N1).

From the front side of the slide rail, install screws (C) to secure slide rail (N1) to panel (11).



This is the back view of the slide rail, clearly showing which holes on slide rail (N1) are used to install screws (C).




C	X6
	
N1	X2
	

Step 17



I. Use screws (C) to attach the slide rail (N1) to panels (8).



This is the front view of slide rail (N1).

From the front side of the slide rail, install screws (C) to secure slide rail (N1) to panel (8).



This is the back view of the slide rail, clearly showing which holes on slide rail (N1) are used to install screws (C).





C	X6
	
N1	X2
	

Step 18


I. Attach panel (7,10) to panel (11), insert cam-lock (B) into the panel (7,10), then turn clockwise to lock onto cam-bolt.

II. Attach panel (8) to panel (7,10), insert cam-lock (B) into the panel (7,10), then turn clockwise to lock onto cam-bolt.




Step 19

I. Use screws (D) to attach panel (9) to panels (7, 8, 10 and 11).





Note: As shown in the figure, the grooves on the panel (9) are in this direction and in the same direction as the panel (11).





Step 20

I. Attach panel (9) to panel (1,2,3), insert cam-lock (B) into the panel (1,2,3), then turn clockwise to lock onto cam-bolt.





Step 21

- I. As shown in the illustration, use screws (G) to secure the anti-tip plate (M) to panels (1 and 3).
- (It is strongly recommended to install this device, especially if there are children in the household.)
- II. Attach the non-slip pad (O) to the anti-tip plate (M) to prevent scratching the floor.
- III. Attach the non-slip pads (N) to panels (1, 2 and 3).





Step 22

I. As shown in the illustration, use screws (C) to secure the power strip to panel (7).





Step 23

I. Peel off the adhesive backing from the light strip (H) and the light strip clips (J).
II. Attach the light strip (H) to panels (7, 8, 10, and 11). Use the light strip clips (J) to hold the light strip (H) in place for added stability.





Step 24

I. Insert the thinnest side of Plastic wedge (F) into the gap between panel (1) and panel (23), and secure the Plastic wedge (F) with screws (C).





Step 25

I. Screw in cam-bolt (A) into the designated holes on panel (13,13,14,14,15).



Step 26



I. As shown in the illustration, connect panels (13 and 14) to panel (12), insert the cam lock (B) into the corresponding holes on panels (12), and then use a screwdriver to turn the cam lock (B) clockwise to secure the cam bolt (A).



X2

Step 27





I. As shown in the illustration, connect panels (12, 13 and 14) to panel (15), insert the cam lock (B) into the corresponding holes on panels (12, 13 and 14), and then use a screwdriver to turn the cam lock (B) clockwise to secure the cam bolt (A).



X2


Step 28

I. Use screws (C) to attach the slide rail (N2) to panels (13, 13, 14 and 14).




Step 29

I. Use screws (D) to attach panels (16, 18 and 20) to panel (17).





X6



Step 30



I. As shown in the illustration, use a screwdriver to insert the cam bolt (A) into the corresponding hole on panel (21 and 22).

II. As shown in the illustration, connect panels (21 and 22) to panel (16, 18 and 20), insert the cam lock (B) into the corresponding holes on panels (16, 18 and 20), and then use a screwdriver to turn the cam lock (B) clockwise to secure the cam bolt (A)



Step 31



I. Use screws (C) to secure the slide rail (E2) to the panel (16, 18) and tighten them with a screwdriver.
 Note: For the correct orientation of slide rail (E2), please refer to the image (front and back).



Step 32

I. Connect the assembled panels (13,14,15) to the panels (8,11), align the slide rails (N2) on the panels (13,14) with the slide rails (N1) on the panels (8,11), and then push them in the direction of the arrow;

Note: This step requires two people to assemble: one person holds the assembled panel (13, 14, 15), and the other person squats under the assembled panel (13, 14, 15), pushes out part of the steel balls on the slide rail (N1), then aims at the slide rail (N2), and then pushes in the direction of the arrow.



Step 33

I. Install the assembled drawer on the cabinet.

Note: Please install the panel (21) of the assembled drawer on the right as shown in the figure, and install the panel (22) of the assembled drawer on the left.

If drawer 21 and drawer 22 are not aligned vertically, you can adjust this screw (C) to align them: you can first use a screwdriver to loosen the screw (C), then move the panels (16,18) upward or downward, and then use a screwdriver to tighten the screw (C).

