


Assembling Instruction

Assembly Instructions

Generating Drawings



ATTENTION

If there is any missing, please kindly send us messages to let us know the name of missing part regarding to the first page of instructions.


We will send replacement to you asap. We are concerned about each customer's experience, if there is any loss or damage, please contact us at any time, we will provide effective solutions.

Please attach your Order ID so that we can assist you better.




General Assembly Guidelines

- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are : wood dowels , screws and bolts.
- VI. A Phillips head screwdriver is required for the assembly of this product .




- VII. Power tools should not be used to assemble this product .

























- VIII. Concealed hinges are three-way adjustable.

Parts List



HARDWARE PACK CONTENT





<p>A</p>  <p>M6x35mm 35+4PCS</p>	<p>B</p>  <p>Ø15x9mm 35+4PCS</p>	<p>C</p>  <p>M4x40mm 7+1PCS</p>	<p>D</p>  <p>Ø6x30mm 18+2PCS</p>	<p>E</p>  <p>M3x12mm 16+2PCS</p>
<p>F</p>  <p>M3x14mm 12+2PCS</p>	<p>G</p>  <p>M3.5x12mm 30+4PCS</p>	<p>H</p>  <p>96mm 3PCS</p>	<p>I</p>  <p>4PCS</p>	<p>J</p>  <p>2PCS</p>
<p>K</p>  <p>Ø35mm 4PCS</p>	<p>L</p>  <p>M5x20mm 4PCS</p>	<p>M</p>  <p>8+1PCS</p>	<p>N</p>  <p>2PCS</p>	<p>O</p>  <p>2PCS</p>
<p>P</p>  <p>M4x12mm 4PCS</p>	<p>Q</p>  <p>Ø20mm 35+4PCS</p>	<p>CL</p>  <p>300mm 1PCS</p>	<p>CR</p>  <p>300mm 1PCS</p>	<p>DL</p>  <p>300mm 1PCS</p>
<p>DR</p>  <p>300mm 1PCS</p>				



Philips head screwdriver required for assembly
(not included)

*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*


Step 1




A x 20PCS



Step 2


NOTE: Use #4 board to connect #3 and #5 legs, Use #7 board to connect #6 and #8 legs.







Note: Align the ends with white plastic pads on parts #3, #5, #6, and #8 with the four-hole sides of panels #4 and #7.






	B x 12PCS
	D x 8PCS





Step 3





	E x 6PCS
	CL x 1PCS
	CR x 1PCS

Step 4




A x 6PCS

Step 5




F x 4PCS





J x 2PCS


Step 6

Note: Ensure the slots on board #2 face board #9.




Note: Pay attention to the magnet's direction.

	B x 7PCS
	D x 2PCS




Step 7




D x 2PCS

Step 8




B x 7PCS



Step 9




Ensure the U-shaped holes on the back panel are at the top.






D x 4PCS

Step 10


Secure O with P to 95% tightness.




	A x 4PCS
	O x 2PCS
	P x 4PCS

Step 11


Slot





B x 4PCS



Step 12












NOTE: Please insert #11 boards before installing the door.






L x 4PCS

Step 13





	E x 4PCS		
	G x 12PCS		I x 4PCS
	H x 2PCS		K x 4PCS

Step 14





To adjust the vertical height.

Loosen the four screws "A" on both hinges. Two of them are usually in slotted holes which allows you to adjust up or down by a few mm. Then tighten back up.



To adjust depth.


Loosen screw "B" on both hinges and move the door to suit. If the door doesn't move, turn screw "C" on both hinges 1-2 turns and try again. Finally, tighten both screw "B" and reset both screw "C".



To adjust side ways.

Turn screw "C" clockwise or counterclockwise on both hinges until the door is in the desired position.

Step 15




NOTE: The left door is #14 and the right door is #15. Make sure metal handle is on the top of door.




G x 16PCS

Step 16






C x 5PCS




Step 17




D x 2PCS


Step 18




	A x 5PCS
	G x 2PCS
	H x 1PCS




Step 19





	B x 5PCS
---	-----------------

Step 20



	E x 6PCS
	DL x 1PCS
	DR x 1PCS

Step 21





F x 8PCS



M x 8PCS

Step 22






Q x 31PCS

Step 23

Drill 2 holes on the wall at the required position for anti-falling device installation.


WALL



N x 2PCS


Step 24

WALL






C x 2PCS

Step 25




WALL



Q x 4PCS

Step 26

WALL





WARNING



Children have died from furniture tipover. To reduce the risk of furniture tipover:

- **ALWAYS** install Anti-tip device provided.
- **NEVER** put a TV on this product.
- **NEVER** allow children to stand, climb or hang on drawers, doors, or shelves.
- **NEVER** open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

