

Assembly Instructions:

Tools Needed:

7/16" Wrench or Socket
Power Drill (Optional)

Parts List (per bench):

1 - Bench Top
2 - Bench Legs
2 - Braces

Hardware (per bench):

4 - 3½" Bolts
4 - 2" Lag Screws
1 - Allen Wrench

Step 1

Lay the bench top upside down on a clean surface. Place the bench legs on the outside of the 2x2 on the bench top. One side of the leg has a predrilled pilot hole in the center. Make sure this side is turned toward the inside of the bench. Insert the 3½" bolts through the legs & turn into the threaded inserts in the 2x2. Tighten with the Allen wrench (see photo 1).




photo 1




photo 2

Step 2

Attach the braces to the bench. Align the predrilled hole in one end of the brace with the predrilled pilot hole in the center of the leg & the other hole in the brace with the predrilled pilot hole in the bench top. Fasten with the 2" lag screws. (See photos 2 & 3.) Before fully tightening the lag screws with the 7/16" wrench or socket, set the bench upright. This will prevent it from being uneven when tightened. If you have a 2' bench the braces need to be attached beside each other (see photo 4).



photo 3



photo 4