

Assembly Manual

OFFICE CHAIR














Please read this manual carefully before any operation and keep it properly for future use.

Product Overview




Accessories List

<p>(1) Backrest</p> 	<p>(2) Seat Cushion</p> 	<p>(3) Armrest</p> 	<p>(4) Central Base Tube</p> 
<p>(5) Split Base Tube</p> 	<p>(6) Air Rod</p> 	<p>(7) Base Plate</p> 	<p>(8) Castor</p> 
<p>(9) Screws (M6*25mm)</p>  <p>×12</p>	<p>(10) Screws (M6*14mm)</p>  <p>×10</p>	<p>(11) Screw Cover Caps</p>  <p>×8</p>	<p>(12) Hexagon Wrench (L-Shape)</p> 

Assembly Instruction


STEP 1

Insert Split Base Tube into Central Base Tube



STEP 2


Insert Castors and Air Rod into parts done in Step 1



Assembly Instruction


STEP 3

Install the Base Plate onto the Seat Cushion.



STEP 4


Install Handrails on Both Sides



Assembly Instruction

STEP 5

Connecting the Chair Body and the Base



STEP 6

Install the Screw Cap into the Corresponding Screw Position.



Chair Safety Warnings

1. General Safety Warnings

- "This chair is designed for office or home use only. Do not use it for industrial, medical, or other unintended purposes."
-

2. Assembly Warnings

- "Follow the assembly instructions precisely. Incorrect assembly may lead to instability or collapse."
 - "Ensure all screws and bolts are fully tightened before use. Check periodically for looseness."
-

3. Usage Warnings

- "Do not stand on the chair or use it as a step ladder. The chair is not designed to support dynamic loads."
 - "Avoid leaning back excessively or rocking the chair violently, as this may cause tipping."
-

4. Adjustment Warnings

- "Adjust the seat height so your feet rest flat on the floor. Improper adjustment may cause posture-related injuries."
-

5. Maintenance Warnings

- "Use only mild cleaners. Harsh chemicals may damage materials or weaken structural integrity."
 - "Inspect the chair regularly for wear and tear (e.g., gas cylinder, wheels). Replace damaged parts immediately."
-