

JY9942BS01




As this item contains many parts, please read the installation instruction carefully before installation . Please use tools properly and carefully. If you have any questions about the product and installation, please contact us.

hosoteservice@gmail.com

Our professional after-sales team will serve you online all day.

Before You Start




- ✓ Read through each step carefully and follow the proper order
- ✓ Separate and count all your parts and hardware
- ✓ Give yourself enough room for the assembly process
- ✓ Have the following tools: Flat Head Screwdriver, #2 Phillips Head Screwdriver and Hammer
- ✓ Caution: If using a power drill or power screwdriver for screwing, please be aware of to slow down and stop when screw is tight. Failure to do so may result in stripping the screw. (Assembly speed can be increased by using electric screwdriver)

Helpful Hints


PEOPLE NEEDED FOR ASSEMBLY: 1-2

- Open your item in the area you plan to keep it to avoid excessive heavy lifting.




- Identify, sort and count the parts before attempting assembly.

- Compression dowels are lightly tapped in with a hammer.




- Slides are labeled with an **R** (right) and **L** (left) for proper placement.



- Make sure to always face the point on the top of the Cam Lock towards the outer edge.


- If there is a back panel in the package, please install it to make sure your unit is complete and sturdy.



- Please fix all the screws provided for the back panel which can enhance product stability. If it is difficult to fix it when tightening, it can be fixed with the help of a hammer and then tightened.




- Do NOT use harsh chemicals or abrasive cleaners on this item.




- Never push, pull, or drag your furniture.

Board Identification


Not actual size




(A)
TOP
Qty:1




(B)
LEFT SIDE PANEL
Qty:1




(C)
RIGHT SIDE PANEL
Qty:1




(D)
PARTITION
Qty:1




(E)
BACK SLAT
Qty:1




(F)
FRONT SLAT
Qty:1



(G)
REAR LOWER PANEL
Qty:1




(H)
UPPER LEFT PANEL
Qty:1



(I)
UPPER MIDDLE PANEL
Qty:1


Board Identification

Not actual size




ⓐ

UPPER RIGHT PANEL
Qty:1




ⓑ

UPPER TOP PLATE
Qty:1




ⓒ

FRONT BAFFLE
Qty:1




ⓓ

FIXED SHELF
Qty:2




ⓔ

FIXED SHELF
Qty:1




ⓕ

FRONT BAFFLE
Qty:1




ⓖ

FIXED SHELF
Qty:2



ⓗ

COSMETIC MIRROR
Qty:1




ⓓ

UPPER BACK PANEL
Qty:1


Board Identification

Not actual size




Ⓢ

UPPER BACK PANEL
Qty:1




Ⓣ

LEFT DRAWER FRONT
Qty:1




Ⓤ

RIGHT DRAWER FRONT
Qty:1




Ⓥ

DRAWER RIGHT SIDE
Qty:2




Ⓦ

DRAWER LEFT SIDE
Qty:2




Ⓧ

DRAWER BACK PANEL
Qty:2




Ⓨ

DRAWER BOTTOM
Qty:2



Ⓩ

CABINET TOP
Qty:1




ⒶⒶ

CABINET LEFT SIDE PANEL
Qty:1


Board Identification

Not actual size




BB

CABINET LEFT SIDE PANEL
Qty:1




CC

BACK SLAT
Qty:1




DD

FRONT SLAT
Qty:1




EE

SMALL DRAWER FRONT
Qty:2




FF

DRAWER LEFT SIDE
Qty:2




GG

DRAWER RIGHT SIDE
Qty:2




HH

SMALL DRAWER BACK PANEL
Qty:2



II

SMALL DRAWER BOTTOM
Qty:2




JJ

SPONGE CUSHION
Qty:1


Board Identification

Not actual size




ⓀⓀ

STOOL SIDE PANEL
Qty:2




ⓁⓁ

STOOL SKIRTS
Qty:2




ⓂⓂ

STOOL BOTTOM BOARD
Qty:1



ⓃⓃ


LOWER BACK PANEL
Qty:1




ⓄⓄ

CABINET
Qty:1


Part List




CAM LOCK
spare:3




CAM BOLT
spare:3




WOOD DOWEL
spare:1




WOOD DOWEL
spare:2




SCREW
spare:2




SCREW
spare:3




SCREW
spare:3




SCREW
spare:2




SCREW
spare:1




SCREW




SCREW




SCREW
spare:1




SCREW
spare:1




SCREW




HANDLE




HAIR DRYER RACK




LEFT CABINET MEMBER



RIGHT CABINET MEMBER




LEFT DRAWER RUNNER




RIGHT DRAWER RUNNER

Part List




18 X2

METAL SLIDE




19 X1

POWER STRIP




20 X58

PERFECT STICKER
spare:3




21 X1

THE POWER PLUG




22 X1

METAL FIXING RING




23 X1

LAMP




24 X1

HEX KEY



25 X1

SCREW




26 X1set

TIPPING RESTRAINT
HARDWARE KIT


Cam Lock Fastening System

Insert the cam bolt into the hole first, then insert the cam lock and lock it.













Board Identification





Not actual size



STEP 1




STEP 2




WITHOUT EDGE BANDING

WITHOUT EDGE BANDING












WITHOUT EDGE BANDING




Insert the cam bolt into the hole first, then insert the cam lock and lock it.





STEP 3



90°








Insert the cam bolt into the hole first, then insert the cam lock and lock it.








Proper orientation of CAM LOCK


STEP 4



STEP 5



Insert the cam bolt into the hole first, then insert the cam lock and lock it.



Proper orientation of CAM LOCK

STEP6


WARNING

How To SEPARATE BALL BEARING SLIDE.


1) Pull toward arrow to open the slide until its stops and then flip it over.



2) Push plastic lever down and pull apart.







Cabinet member






Drawer member









STEP 8














STEP 9






STEP 10




STEP 11








STEP12








EDGE BANDING





STEP13





STEP14




STEP15




STEP 16



THIS STEP REQUIRES 2 PEOPLE










Insert the cam bolt into the hole first, then insert the cam lock and lock it.





Proper orientation of CAM LOCK


STEP 17







Step 1



Step 3



Step 2





Proper orientation of CAM LOCK


Insert the cam bolt into the hole first, then insert the cam lock and lock it.


X2


STEP18



 Ø3.5X14mm	
7	X12





14"  350mm	
17DL	X2

14"  350mm	
17DR	X2



X2





STEP 19





Cabinet Slide

Drawer Slide


STEP20




Take the power connector out what in the hole like the picture before assembling the part 18







STEP 21



THIS STEP REQUIRES 2 PEOPLE





STEP 22




Make sure the wire through the part 22 that on the part N like the picture.





STEP23




Before attaching the back panel, be sure that the unit is at 90°.





STEP 24






STEP 25











 Ø3.5X14mm	
7	X12

14"  350mm	
17CL	X2




14"  350mm	
17CR	X2




STEP 26



STEP27






Insert the cam bolt into the hole first, then insert the cam lock and lock it.




Proper orientation of CAM LOCK

STEP28







Insert the cam bolt into the hole first, then insert the cam lock and lock it.










Proper orientation of CAM LOCK

STEP 29




Before attaching the back panel, be sure that the unit is at 90°.


STEP30






Step 1



Step 2



Step 3





Proper orientation of CAM LOCK


Insert the cam bolt into the hole first, then insert the cam lock and lock it.


X2


STEP31



 Ø3.5X14mm	
7	X12



14"  350mm	
17DL	X2


14"  350mm	
17DR	X2





X2


STEP32




 M6*25mm	
10	X2





 Ø25X21mm	
15	X1

 4X65mm	
24	X1


 M4X16mm	
25	X1




STEP33




- 1 First mount Part 1 on the back of the top of the OO board as shown




- 2 Tear the adhesive film on the stainless steel sheet.









- 3 Aim at the place where you want to install it, stick it up and press it tightly.



- 4 You can always take it off when you want to charge it.








STEP34






X2


STEP35



STEP36











Insert the cam bolt into the hole first, then insert the cam lock and lock it.







Proper orientation of CAM LOCK


STEP37



STEP38




STEP39




NOTE: The tipping restraint hardware included is for wooden stud wall construction. It must be attached to a wall stud. Depending upon your wall construction different anchor hardware may be required. Please contact your local hardware store for assistance. Young children can be seriously injured by tipping furniture. You must install the tipping restraint hardware with the unit to prevent the unit from tipping, causing any accidents or damage. The tipping restraints are intended only as a deterrent and are not a substitute for proper adult supervision. The tipping restraints are not earthquake restraints. If you wish to add the extra security of earthquake restraints, they must be purchased and installed separately.


Install the tipping restraint hardware




1. make mark on the wall




2. drill two Ø6 holes on the wall



3. put two anchors in the holes



4. fix the device on the wall by the long screws



5. Push the cabinet close to the wall so that the two bases are close to each other, and then put on nylon tie to tighten it.

