


# Assembly Instructions




# Before Assembly

## Tips Before Your Start:


- Remove all wrapping material, including staples & packing straps before you start to assemble.
- DO NOT tighten all screws and bolts until the assembly is completely assembled.
- Keep all hardware parts out of reach of children.

## QUICKFIT



Tighten quickfit until shoulder is flush with panel. Do not overtighten or undertighten.


## CAM LOCK



When fitting a cam lock, ensure the starting position is correct before inserting the connecting QUI CKFIT

Quickfit head should be in the centre of the cam lock when the two panels are joined.

Cam lock should be inserted before quickfit.




Turn cam lock clockwise to tighten.


# Before Assembly

## Tips Before Your Start


### How to separate the drawer slider:



## Drawer Front Alignment
























If the drawer front panel is NOT level after being assembled, then...




Loosen the screws on the left and right hand side, then adjust the drawer slide up or down, until the drawer fronts are even/level, then tighten the screws.


# Part List

<b>No. A</b> Quantity:20 Pcs Cam Lock Dowel 8*28mm 	<b>No. B</b> Quantity:48 Pcs Cam φ15 	<b>No. C</b> Quantity:48 Pcs Sticker Ø20 	<b>No. D</b> Quantity:32 Pcs Dowel 8*30mm 
<b>No. E</b> Quantity:3 Sets Drawer Slider 10" 	<b>No. F</b> Quantity:12 Pcs Screw M4*30mm 	<b>No. G</b> Quantity:54 Pcs Screw M3.5*14mm 	<b>No. H</b> Quantity:3 Pcs Handle Ø20*23mm 
<b>No. I</b> Quantity:5 Pcs Slip Mat Ø20 	<b>No. J</b> Quantity:3 Pcs Screw M4*16mm 	<b>No. K</b> Quantity:4 Sets Rotary bearing 56*15*11 K1  K2 	<b>No. L</b> Quantity:2 Sets Magnetic Door Catcher 
<b>No. M</b> Quantity:6 Pcs Shelf Support 30*17*13mm 	<b>No. N</b> Quantity:14 Pcs Screw M6*40mm 	<b>No. O</b> Quantity:1 Pcs Allen Key 4# 	<b>No. P</b> Quantity:4 Sets Plastic Wedge 
<b>No. Q</b> Quantity:2 Sets Anti-falling Parts 	<b>No. R</b> Quantity:28 Pcs Cam Lock Dowel 8*28mm 	<b>No. S</b> Quantity:56 Pcs Screw M4*50mm 	<b>No. T</b> Quantity:1 Pcs Screwdriver 

# Product structure



# STEP 1




No. A  
Quantity: 8 Pcs  
8\*28 mm



No. G  
Quantity: 8 Pcs  
M3.5\*14mm




No. K1  
Quantity: 4 Pcs



No. R  
Quantity: 28 Pcs  
8\*28 mm



# STEP 2




**Pay attention to the direction of the magnet.**

No. G  
Quantity: 8 Pcs  
M3.5\*14mm





No. L  
Quantity: 2 Sets




## STEP 3



The first screw hole should corresponded with the board location hole




No. E  
Quantity: 3 Sets  
10"



No. G  
Quantity: 12 Pcs  
M3.5\*14mm




## STEP 4



No. B  
Quantity: 28 Pcs  
Ø15





No. D  
Quantity: 28 Pcs  
8\*30mm




All the wooden strips are locked in this way.


## STEP 5





No. S  
Quantity: 56 Pcs  
M4\*50mm



No. T  
Quantity: 1 Pcs



## STEP 6




No. M  
Quantity: 6 Pcs  
30\*17\*13mm






## STEP 7



No. G  
Quantity: 6 Pcs  
M3.5\*14mm




## STEP 8





No. G  
Quantity: 4 Pcs  
M3.5\*14mm



No. K2  
Quantity: 2 Pcs




## STEP 9




No. G  
Quantity: 4 Pcs  
M3.5\*14mm



No. K2  
Quantity: 2 Pcs




## STEP 10



No. B  
Quantity: 4 Pcs  
Ø15




## STEP 11




No. B  
Quantity: 4 Pcs  
Ø15




No. D  
Quantity: 2 Pcs  
8\*30mm




## STEP 12




## STEP 13



## STEP 14



No. D  
Quantity: 2 Pcs  
8\*30mm




No. N  
Quantity: 8 Pcs  
M6\*40mm




No. O  
Quantity: 1 Pcs  
4#



## STEP 15




## STEP 16



No. I  
Quantity: 5 Pcs  
Ø20



## STEP 17



**×3**

No. A  
Quantity: 12 Pcs  
8\*28 mm




No. H  
Quantity: 3 Pcs  
Ø20\*23mm



No. J  
Quantity: 3 Pcs  
M4\*16mm




## STEP 18




**×3**

No. F  
Quantity: 12 Pcs  
M4\*30mm



## STEP 19



**x3**


No. B  
Quantity: 12 Pcs  
Ø15



## STEP 20




The first screw hole should corresponded with the board location hole



**x3**


No. E  
Quantity: 3 Sets  
10"




No. G  
Quantity: 12 Pcs  
M3.5\*14mm



## STEP 21



## STEP 22



No. N  
Quantity: 6 Pcs  
M6\*40mm




No. O  
Quantity: 1 Pcs  
4#






## STEP 23




Description: Insert the thinner end of the reinforcement into the gap in this back panel, then tighten the screws. This will make the cabinet more stable.


No. P  
Quantity: 4 Pcs




## STEP 24



## STEP 25



No. Q  
Quantity:2 Set



**Note:**  
Please lift up the furniture by two people when moving is needed.  
Dragging may cause the legs failure.