





Assembly Instructions




General assembly guidelines

- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are wood dowels, screws and bolts.
- V. A philips head screwdriver, hammer and tape measure is required for the assembly of this product.



- VI. Power tools should not be used to assemble this product.




VII. Maintenance Guide


To maintain long term performance and easy gliding of your solid wood drawers, we recommend applying wax to the wooden guide rails.

1. Bee's wax is recommended or Paraffin wax from a standard candle can be used.
2. Apply the wax by rubbing it on the wooden guide rails where there is wood-on-wood contact when opening and closing the drawer. (Wax should be room temperature, do not melt the wax onto the wood)
3. Wax should be applied every few months for the first year and then only when needed after that to keep the drawers sliding smoothly.

Parts List




















The side drawer with **WARNING LABEL**, should be mounted in highest drawer.




Part #	Description	Qty
1	Top panel	01 pc
2	Left side panel	01 pc
3	Right side panel	01 pc
4	Base	01 pc
5	Front rail	02 pcs
6	Large wood slider	06 pcs
7	Foot	02 pcs
8	Back panel	02 pcs
9	Drawer Front	06 pcs


Part #	Description	Qty
10	Drawer Front	06 pcs
11	Left drawer side	06 pcs
12	Right drawer side	05 pcs
13	Drawer back	06 pcs
14	Drawer Bottom	06 pcs
15	Right Drawer side with Warning	01 pc
16	Division	01 pc
17	Wood Slider	06 pcs
18	Center Foot	01 pc

Hardware List


A		Ø8*30mm	Wooden dowel	58 pcs
B		Ø10*20mm	Wooden dowel	48 pcs
C		Ø4,0*25mm	Screw	72 pcs
D		Ø3,5*30mm	Screw	28 pcs
E		Ø4,0*40mm	Screw	09 pcs
F		Ø10*10mm	Nail	36 pcs
G		Ø7,0*60mm	Screw	01 pc
H		4mm	Hex Key	01 pc
I		Ø8*40mm	Wooden dowel	12 pcs
J		Ø15*30mm	Cam bolt	33 pcs
K		Ø15*10mm	Cam lock	33 pcs
L			Wall anchor	01 pc
M			Washer	02 pcs
N		Ø6*35mm		01 pc
O		Ø4*16mm	Screw	01 pc
P		Ø4,0*40mm	Screw	01 pc
Q		1441mm	"H" Profile	01 pc



Hammer recommended for assembly (not included)




Philips head screwdriver required for assembly (not included)



Tape measure required for assembly (not included)



The hardware quantities listed above are required for proper assembly. Some extra hardware may also have been included.

Step 1




Insert wood dowel (B) into part 6 and 17.


Attention to the
dowel size:
Ø10*20mm




Step 2





Insert wood dowel (B)
into part 9.



Step 3






Please assemble on
a clean soft surface
to avoid damage.




Insert wood dowel (A) into parts 2, 3, 5, 7, 11, 12, 15 and 16

Step 4



1 - Ensure cam bolt is installed straight and not at an angle.
 2 - Tighten cam bolt until shoulder on cam bolt is flush. Do not over-tighten.




Fix the Cam bolt (J) in part 1 and 10 using a Philips head screwdriver.




Step 5




Secure part 6 to part 2 and 3 with screw (C) and Philips head screwdriver.




Step 6




Secure part 17 to part 16 with screw (C) and Phillips head screwdriver.




Step 7



Attach parts 5 to parts 2, 3 and 16, using screws (D) and Philips head screwdriver.




Step 8



Secure foot 7 to base 4 using screw (C) and Philips head screwdriver.

C		12
		Ø4*25mm


Step 9






Attach the center foot part 18 to base 4 using the screw (G) and the hex key (H).

H		01
G		01
		Ø7,0*60mm


Step 10



Step 11



Step 12




Insert wood dowel (A) into parts 6 and 17.

A		12
<small>Ø8*30mm</small>		

Step 13



Name and address of the supplier and date of production.




Secure back panel 8 and hardware (Q) to body with nails (F) and hammer.

F		30
<small>Ø10*10mm</small>		
Q		01


Step 14




Secure back panel 8 to body with nails (F) and hammer.




Step 15




Attach part 9 to part 10, with screws (C) and Philips head screwdriver.




Step 16




Attach parts 11, 12 and 15 to part 10 with Cam lock (K) and Philips head screwdriver.

K		Cam lock	24
---	--	----------	----

Step 17





Insert part 14 between parts 11 and 12. Attach part 13 to parts 11 and 12 with screws(D), and Phillips head screwdriver.

D		Ø3,5*30mm	24
---	---	-----------	----

Step 18




The assembled drawer with this warning must be placed on top of the unit.



Insert wood dowel (I) on the inside of all drawers, with the drawer inside the unit, after having passed the wood dowel that is in the drawer slide.

The dowel is not flush with the panel, it is a little inside the drawer to help when you need to remove the lock dowel to remove the drawer.




Step 19

WARNING


Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.

Wall anchor and hardware are included with this product. Please make sure hardware is suitable for your walls before installing, as different wall materials may require different types of anchors.





! 1st

Attach part (L) with screw (O) and washer (M), in the frame of unit top panel using Phillips head screwdriver.









! 2nd

With drilling machine make one hole in the wall, insert part (N) in the hole. Secure part (L) with screw (P) and washer (M) in the wall using a Phillips head screwdriver.




Wall



L		01
M		02
N		01
O	 Ø4*16mm	01
P	 Ø4,0*40mm	01

Name and address information for the manufacturer responsible for the anti-tip hardware and date of production can be found on the label on the back of the furniture.

Step 20



Assembly Complete!