

TRUNDLE


Examine all packaging material for small parts that may have come loose during shipment. Periodic checks are recommended to insure that all components are in proper position, tight and free from damage. Keep this assembly instruction for future reference. Adult assembly is required.

HARDWARE LIST

- A (8) Allen Bolts $\frac{1}{4}" \times 1\frac{1}{4}"$
- B (24) Allen Bolts $\frac{1}{4}" \times 1\frac{3}{4}"$
- C (4) Screws $\frac{3}{16}" \times 1\frac{1}{8}"$
- D (8) Screws 35 mm
- E (4) Wood Knobs
- F (6) Metal Casters
- G (1) Allen Wrench

PARTS LIST

- H (1) Front Panel
- J (2) Side Panels
- K (1) Rear Panel
- L (6) Wheel Blocks
- M (2) Slat Sets



STEP 1:

Attach each Wood Knob (E) to the Front Panel (H) by aligning holes and securing from the backside with 1 Screw (C) per each.

STEP 2:

To assemble the Trundle, attach each Trundle Side Panel (J) to the inside of the Front Panel (H) by aligning holes and securing with 2 Allen Bolts (A) per each corner. Tighten all bolts using the Allen Wrench (G) that has been provided.

STEP 3:


Next attach the Trundle Back Panel (K) to each Trundle Side Panel (J) By aligning the holes and securing with 2 Allen Bolts (A) per each corner. Tighten all bolts.

STEP 4:

Attach each Wheel Block (L) to inside of each Front & Rear Panels (H & K) by aligning each in place and securing with 4 Allen Bolts (B). Tighten all bolts. Attach each Metal Caster (E) to the bottom of each block by screwing in place.

STEP 5:

Finally attach the Slat Sets (M) to the inside of the Trundle unit (now assembled) using 8 Wood Screws (D) to secure in place. Tighten all screws. The Assembly is now complete.



CARE & MAINTENANCE: The touch of a soft cloth is all the maintenance the finish will ever need. Please do not use harsh or abrasive cleaners for polishing, as they may cause damage to the finish. Periodic checks are recommended to make sure that all hardware is securely tightened.