






# Installation Instruction



If you have any questions, please contact us  
We will help you with in 24 hours



We recommend using hand tools for assembly.  
If an electric screwdriver is used, reduce power and torque to avoid damage to the product.



### Install the Anti-Tip Straps


Using the anti-tip straps can reduce the risk of tipping over, but can not eliminate it.

#### Notice:

1. Follow the installation instructions. Please confirm all accessories are preset before installation.
2. Do not fully tighten the screws during initial assembly. Fully tighten screws only once all pieces which are correctly assembled.
3. If you encounter any problems during installation, please contact our customer service.
4. Please unbox the item from the side with an open-label and put a carpet on the floor to avoid scratching it.



Recommended installers:2



Put a carpet on the floor  
before unpacking



Estimate installation time:  
60 minutes

## Instructions For Fastening CAM-BOLT and CAM-LOCK



CAM-BOLT



CAM-LOCK

Tools Required



### INSERTING AND TIGHTENING CAM-BOLT

Place Cam-bolt on pre-drilled hole and screw in vertically

Shoulder is flushed (on the same level) with the panel.

Shoulder is above the panel.

Place Cam-bolt on the designated pre-drilled holes on the panel. Use a Phillips Screwdriver to screw-in Cam-bolt vertically until shoulder is flushed (on the same level) with panel.

### INSERTING CAM-LOCK

Insert Cam-lock with arrow align to Cam-bolt head


CORRECT

WRONG

Align the arrow on the Cam-lock to the Cam-bolt head and insert the Cam-lock. Ensure Cam-lock is fully inserted.





























### TIGHTENING CAM-LOCK

Use a Flat-head Screwdriver to turn Camlock clockwise so it locks onto the head of the Cam-bolt. Turn until it is snug (about 3/4ths of a turn) -- over-tightening could damage Cam-lock or/and Cam-bolt.



























**Caution!!!**

Make sure all parts are included. Most board parts are labeled or stamped on the raw edge. Contact us for free replacement if having damaged or missing parts.









Item no.	Reference Image	Qty.	Item no.	Reference Image	Qty.
1		X1	15		X2
2		X1	16		X2
3		X1	17		X1
4		X1	18		X1
5		X1	19		X1
6		X1	20		X1
7		X2	21		X1
8		X1	22		X1
9		X1	23		X1
10		X1	24		X2
11		X1	25		X2
12		X1	26		X2
13		X1	27		X2
14		X1	28		X2

# The Hardwares


Item no.	Reference Image	Qty.
(A)	 Cam Bolt Ø6x35mm	X62
(B)	 Cam Lock Ø15x10mm	X62
(C)	 Wood Dowel Ø8x30mm	X30
(D)	 Screw Ø4x30mm	X10
(E)	 Screw M4x12mm	X4
(F)	 Handle	X1
(G)		X2
(H)	 Back Panel Fastener	X8
(I)	 Screw M3x14mm	X14
(J)		X3
(K)		X2
(L)	 Screw M3.5x12mm	X37

Item no.	Reference Image	Qty.
(M)	 Ø6x18mm	X2
(N)		X2
(O)		X2
(P)		X2
(Q)		X1
(R)		X1
(S)	 Screw M3x12mm	X2
(T)		X2
(CL)		X2
(CR)		X2
(DL)		X2
(DR)		X2

# STEP 1




180°












## Cam Lock Fastening System





This Cam Lock Fastening System will be used throughout the assembly process






# STEP 2






# STEP 3








STEP 4












# STEP 5







# STEP 6






# STEP 7








# STEP 8





STEP 9











# STEP 10















# STEP 11





# STEP 12










# STEP 13







STEP 14



# STEP 15



# STEP 16



# STEP 17

