

SAFETY TIPS

- Ensure that the cabinet is positioned square and firm on the floor so that it will not fall over. Some cabinets are equipped with adjustable floor levelers. Adjust the levelers for maximum stability and proper alignment (Figure 1).
- Some cabinets include a Safety Strap. Follow the instructions included with the Safety Strap to ensure maximum stability (See step #3 in Cabinet Set Up Instructions).
- Some cabinets are illuminated. Combustible materials or those adversely affected by drying or fading from the heat should not be placed close to the lamp.
- Some cabinets include a cabinet door lock. Lock the cabinet door to keep the contents secure and away from minors.
- Some cabinets include a location for a cooler. Follow the cooler manufacturer's installation instructions for clearance and caution issues.
- Keep plastic bags and small parts away from children.

CABINET SET UP INSTRUCTIONS:

1. **Turn the adjustable floor levelers**, located on the bottom of the cabinet, all the way in (up) (Figure 1).
2. **Inspect the inside of the cabinet, carton and packaging** to make sure you have removed all separately packed parts. Do NOT dispose of any packing material until the set up is complete.

If your cabinet has shelves, they may be secured inside the cabinet with shipping clips. To remove the shipping clips, you will need a Phillips screwdriver (Figure 2). The shelves may also be packed on top, underneath, or along side of the cabinet. You may need to lay the cabinet on its backside to remove the shelves from underneath the cabinet. Use caution when removing these shelves.

3. **Move the cabinet to its final location.**

Locate any electrical cords that may be exiting the back or bottom of the cabinet. Move them out of the way as you move the cabinet to its final location.

- Some cabinets include a Safety Strap** to prevent tipping. If a Safety Strap was included: with your cabinet, review the instructions included with the Safety Strap at this time and choose the assembly option which best fits your application. The cabinet should be attached to the wall for maximum stability. If your cabinet does not have this feature, proceed to the next step.

4. **Install the Shelves, Racks, and other separately packed parts.**

Do NOT put any items onto the shelves or racks until completely finished with the set up instructions.

The shelves may not all be the same size. Please use care to install each shelf in its proper location within the cabinet. The shelves will rest on Shelf Clips or wood rails inside the cabinet.

Pad-Lock™ Shelf Clips: Securely place the Shelf Clips into the desired holes inside the cabinet (Figures 3 and 4). There may be several holes that can be used for shelf height adjustment. Position the shelves onto the Shelf Clips as shown in Figures 3 and 4.

5. **Close and secure the door(s)** using the lock or latch provided with your cabinet.
6. **Level the Cabinet.** Place a level alongside the cabinet from front-to-back and side-to-side (Figure 5). There are adjustable levelers under the cabinet (Figure 1) that can be turned in (up) or out (down) to make adjustments. Adjust the levelers until the cabinet is level in all directions, and is square and firm on the floor.

CAUTIONS FOR USE OF GLASS SHELVES:

To prevent breakage of glass shelves and/or items placed on the glass shelves, good judgement must be used during the installation and loading of glass shelves.

Sudden shock from any size item can result in broken glass, personal injury, or damage to valuable items. Care should be taken when placing items onto each glass shelf.

The weight of items placed on the shelves must be evenly distributed and must not exceed 25 pounds.

The end use of this cabinet is beyond our control and therefore, the Howard Miller Company can not assume responsibility for broken shelves or personal effects.





FIGURE 1
FIGURA 1
FIGURE 1
ABBILDUNG 1



FIGURE 2
FIGURA 2
FIGURE 2
ABBILDUNG 2

Pad-Lock™ Shelf Clip
Pad-Lock™ Soporte de repisa
Cornière Pad-Lock™
Pad-Lock™ Regalklemme



CORRECT
CORRECTO
CORRECT
RICHTIG



INCORRECT
INCORRECTO
INCORRECT
FALSCH

FIGURE 3
FIGURA 3
FIGURE 3
ABBILDUNG 3



FIGURE 4
FIGURA 4
FIGURE 4
ABBILDUNG 4



FIGURE 5
FIGURA 5
FIGURE 5
ABBILDUNG 5

Distribute Load Evenly on Shelf.
Do NOT exceed 25 pounds.
Distribuya el peso sobre la repisa por igual.
NO exceda de 25 libras (11.35 Kg.)
Répartir la charge de façon uniforme sur l'étagère.
NE PAS dépasser 11.35 kg (25 lb.)
Last gleichmäßig auf dem Regal verteilen.
Darf 11 kg NICHT überschreiten.



FIGURE 6
FIGURA 6
FIGURE 6
ABBILDUNG 6

ILLUMINATED CABINETS (Available on some models):

Some cabinets are illuminated. Determine which lighting option is provided with your cabinet.

TOUCH-LITE™:

The light is activated by touching the door hinge with the wire attached to it. (Typically this is the upper right door hinge on the cabinet.)

The light begins in the OFF position. The operation is sequential and will advance to the next light illumination level with each subsequent touch to the hinge.


- 1st touch = Low Light Illumination Level
- 2nd touch = Medium Light Illumination Level
- 3rd touch = High Light Illumination Level
- 4th touch = Turns light off

AUTO-ON:

The light will automatically turn ON when the door is opened, and turn OFF when the door is closed.

PREP SHELF (Available on some models):

Some cabinets have a hinged, lift-up prep shelf on the inside of the drawer (Figure 7). If you would like to remove this shelf, pull the drawer all the way open. Locate the pins on each side of the drawer that hold the shelf in position. Push one of the pins in using a narrow object. Once the pin is pushed in far enough to clear the inside edge of the drawer, lift up on that side of the shelf. Lift the shelf out at an angle, up and away from the drawer. It is not necessary to remove the drawer from the cabinet in order to perform this operation. (Reverse these instructions in order to reinstall the shelf into the drawer.)



CARE AND MAINTENANCE

GENERAL GUIDELINES FOR STONE SURFACES:

Contact a stone restoration specialist regarding specific care and any questions you might have regarding the stone surfaces (i.e. granite, marble, etc.) that your cabinet may have. You may consider contacting Stone Care International at 1-800-839-1654 or visit their website at www.stonecare.com

Clean the stone surface on a regular basis with cleaning products specifically designed for use on stone surfaces. General scouring powders or creams may contain abrasives that can scratch the stone surface.

Protect the stone surface from condensation or spills. (Coasters under drink glasses and bottles can help prevent glass rings or stains from occurring.) Products that contain lemon, vinegar or any fluid that contains an acid or alkali, may damage stone surfaces.

Spills: Pick up or blot spills **immediately** to prevent staining or etching. Blot the spill with a clean paper towel or cloth. Don't wipe the area, as this will spread the spill (and possibly increase the stain area). Flush the area with plain water. Use a cleaner or stain remover that is specifically designed for use on stone surfaces.

Scratches and Nicks: Remove any loose debris from the stone surfaces to prevent scratching. Minor surface scratches may be buffed out with a polishing or restoration product specifically designed for use on stone surfaces.

GENERAL GUIDELINES FOR CABINETRY:

Protect wood & leather surfaces from scratches, dents, condensation or spills. Use cutting boards and coasters to protect the surfaces. (Coasters under drink glasses and bottles can help prevent glass rings or stains from occurring.)

Wax and polish your cabinet as frequently as you do your other furniture. Use a non-silicone liquid or paste wax.

Avoid exposing the cabinet to direct sunlight and protect it from extreme temperatures and humidity changes. Prolonged exposure to direct sunlight may fade the finish while extreme temperature and humidity changes may cause the wood to split or crack.

Check periodically that your cabinet is level and rests firmly on all four levelers. This is especially important the first few months if the cabinet settles into carpet (Figures 1 and 5).

SERVICE INFORMATION

Howard Miller offers a limited 1-year warranty on your product from the original date of purchase or date of receipt if the product was a service award. In the unlikely event that your product appears to be malfunctioning or requires repair within the warranty period, please contact your retailer or the company who provided the item if it was an award. They will be your first resource for information regarding your warranty and service options.

If your product is more than one year old from the date of purchase or receipt as an award, your product is no longer under the manufacturer's warranty. Support for products that are no longer under warranty is available through the "Help Center" at www.howardmiller.com.

We recommend that you carefully read and follow all instructions provided with your Howard Miller product before pursuing service. These instructions will provide detailed information to answer most questions.

To find additional information regarding your product, to order parts or to find a service center, please go to the "Help Center" located at www.howardmiller.com. The "Help Center" also has links to product manuals, instructions, videos and frequently asked questions.

Before contacting your retailer, award provider or a service center, please have the following information available. The model number and serial number can be found on the Product Information Label which is normally on the back or bottom of the product.

Model Number: _____
Serial Number: _____
Date Purchased: _____
Where Purchased: _____

If the item was shipped directly to you, it is your responsibility to report freight loss or damage to the carrier and your retailer or award provider. If the carton indicates signs of "visible damage", instruct the driver to note the damage on the freight bill. If damage is found after the item has been delivered, notify your retailer or award provider and the carrier immediately. Many carriers require notification within 2 days. Failure to notify the carrier within their required time frame may waive your rights to a damage claim and you may be liable for the damage.

