




Product Installation Instructions







Ax2




Bx2




Cx2




Dx2




Ex4




F1x1




F2x1




Gx1




Hx1




Ix2










Jx1



Kx1




①		Two In One Screw (6x28mm)	50pcs +5pcs
②		Two In One Nut (10x12mm)	50pcs +5pcs
③		Mute pad	6pcs
④		Corner Connector & Screw (3.5x12mm)	16pcs +4pcs 8pcs
⑤		Rebound Device & Screw (4x12mm)	16pcs +4pcs 2pcs




Double-head screwdriver, use as required

Product structure decomposition




Use parts ① and ②



Step 1




Step 2



Step 3





Use a screwdriver to lock in the direction of the "+" sign





Disassemble along the direction of "-" sign

Step 1




x2

Step 2




x4

Step 3




Note: the three-in-one hole of C board is on it.




x2




Step 4


2  x4



Note: the hole should face down.



Step 5

2  x4





Note: the hole should face down.

Step 6





x2



Step 7




Step 8



Step 9




Step 10





Note: Do not install the No.2 nut yet.

Step 11




Note: Do not install the No.2 nut yet.

Step 12


④  x8  x16


Note: When installing the corner code, you should first pinch two adjacent plates by hand to make them close together, and then tighten the screws.

Note: Fixed the four corner codes below first, and then fix the corner code above.




Step 13


②  x14



Step 14


②  x6

Note: F1F2 Make no mistake.




Step 15

3




x6

Tear off release paper and stick the black mute pad on the board



Step 16



5




x1

x1

x8






Adjustable left and right




Step 17


5 x8



Adjustable back and forth




Move the sliding ball to the position shown in the picture




Push in

Step 18



Step 19




If there is a significant gap between the "J" board and the "K" board after installation, the gap between the "J" board and the "K" board can be adjusted by adjusting the screws




Adjustable back and forth

Step 20




If there is a significant gap between the "J" board and the "K" board after installation, the gap between the "J" board and the "K" board can be adjusted by adjusting the screws



Adjustable left and right

Open



Close

