





# HLG0126

Version: 1.0



**EN\_IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.**

*. THANK YOU FOR PURCHASE! .*

# FREE REPLACEMENT PARTS AVAILABLE!



*---NEED HELP WITH YOUR FURNITURE?---*

Scan the QR code to contact us!



If you're experiencing any issues—whether due to shipping, assembly, or any other reason  
—we're here to help.  
For any damaged or missing components, we're happy to provide FREE replacement parts.



WhatsApp


**Email: support @anymaple.com**

---


## *WANT TO CONTACT US THROUGH AMAZON?*

- ▶ Log in to your Amazon account.
- ▶ Go to “Your Orders” and locate your furniture order.
- ▶ Click on “Get Help with Order” to send us a message directly.


Our customer support team is ready to assist you and we will respond within  
12-24 HOURS to resolve your concerns quickly!




**EN\_QUICKFIT:** Tighten quickfit until shoulder is flush with panel. Do not overtighten or undertighten.



**EN\_CAM LOCK:** When fitting cam lock, ensure starting position is correct before you insert connecting quickfit.















**EN\_Quickfit** head should be in the centre of the cam lock when the two panels are joined.  
Cam lock should be inserted before quickfit.




**EN\_Turn** cam lock clockwise to tighten.






 <p><b>A</b> x26 Ø6x35mm +2(spare)</p>	 <p><b>B</b> x26 Ø15x10mm +2(spare)</p>	 <p><b>C</b> x52 Ø6x30mm +3(spare)</p>	 <p><b>D</b> x32 Ø4x35mm +3(spare)</p>	 <p><b>E</b> x4 Ø10x3mm +2(spare)</p>	 <p><b>F</b> x2 Ø4x12mm</p> 
<p><b>G1</b></p>  <p><b>G2</b></p>  <p><b>G</b> x14 Ø3x16mm +1(spare)</p>	 <p><b>H</b> x36 Ø20mm +4(spare)</p>	 <p><b>I</b> x2 Ø6x30mm</p>			




**01**



B x4




C x8



D x4


Ø4x35mm



B x6






C x12



D x6

Ø4x35mm






C x8

D x8

Ø4x35mm



Notice

6



C x8



09



**Note: At least two people are required for this step.**




**Notice**



**Attention: Which side of the back panel on the 10th and 11th has the same color as the cabinet, facing towards the front of the cabinet.**

D x8  
Ø4x35mm






Notice

C x8

E x4




F x2  
Ø4x12mm







Notice



Notice





**Attention: Board 8 is shorter than Board 7 and Board 12**

B x3






90°



G x14


G1

G2





Please ask users to use hole stickers according to their own appearance requirements "H".




D x2

I x2



(1)x2



First, use a ruler to measure the approximate height of the product on the wall, and then mark it with a pen.

(2)x2


WALL  
+  
drilling hole  
Ø6x30mm



Then use a tape drill to make holes in the wall that are suitable for the product screws.

(3)x2


WALL I



Then, put the expansion bolt into the hole

(4)x2

WALL



Finally, pass the matching screws through the "anti-rewind" and tighten them to fix them on the wall.

