



# FITNESS TRAMPOLINE

38 inch



## ASSEMBLY INSTRUCTIONS

Model: AZJ-38 MINI

15+

Not recommended for users under 15 years of age.

### CONTACT INFO

Distributed by Airzone Ltd.  
Questions or Comments? Call **1-800-775-6524**

Made in China.



Adult assembly required

## IMPORTANT

After receiving the shipment, inspect the product thoroughly to ensure that it has been shipped with care.

Before assembly make sure that the packaging contains all parts.

For service or parts replacement under warranty, the official sales receipt and serial number sticker is required. Please keep your official sales receipt for future reference

### OFFICIAL SALES RECEIPT CAN BE ATTACHED HERE

Service or parts under warranty  
only available with show of Receipt,  
Sticker with Serial Number and Instruction Manual

SERIAL NUMBER

**DO NOT return this product to the place of purchase.** Please contact us for any questions or comments at **1-800-775-6524**

## Save these IMPORTANT Safety Instructions

### **⚠ WARNING**

Read these materials prior to assembling and using this trampoline.  
Keep this manual so you can refer to it later.

For recreational use ONLY. Not for professional use.  
User weight limit is 200 lbs.  
One user at a time for safe use.

Age Grade **15+**

# TABLE OF CONTENTS

03	- Liability
03	- Essential information
04	- Installation Instructions
04	- Care and Maintenance Instructions
05	- User instructions
06	- Trampoline Safety and Accident Prevention
07	- Assembly Instructions
08	- Limited Warranty

## LIABILITY

While every attempt is made to embody the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risks of injury due to use of this product. All merchandise is sold on this condition, which no representative of the company can waive or change.

## ESSENTIAL INFORMATION

In addition to the instructions and precautions provided with your trampoline, the following precautions must be observed:

Misuse and abuse of this trampoline is dangerous and can cause serious injuries.

Trampolines, being rebounding devices, propel the performer to unaccustomed heights and into a variety of body movements.

All purchasers or persons assembling and using the trampoline must become familiar with the manufacturer's recommendations for the proper assembly, use, and care of the trampoline. Also, be alert to the user's limitations in the execution of trampoline techniques and progressions. Suggestions for the care and maintenance are included to promote safe, enjoyable use of this product.

It is the responsibility of the owner to insure that all users of this trampoline are adequately informed of all warnings and safety instructions.

Always check with your doctor before starting any exercise program.

This item has small parts, not for users under 15 years old.

Adult assembly required. Care should be taken in the unpacking & assembly of the trampoline.

**NOT FOR PROFESSIONAL USE.**

**WEIGHT LIMIT FOR TRAMPOLINE USER IS 200 LB.**

# INSTALLATION INSTRUCTIONS

Adequate overhead clearance is essential. A minimum of 10ft from ground level is recommended. Provide clearance for wires, ceiling fans and other possible hazards.

Lateral clearance is essential. Place the trampoline away from walls, structures, furniture and other play areas. Maintain a clear space on all sides of the trampoline. A minimum of 10ft from the edge is recommended.

Assembly by adults only. Please use gloves to protect your hands from pinch points during assembly. When you are ready to start, make sure that you have plenty of space and a clean dry area for assembly. Failure to follow all instructions and warnings exactly may result in serious injury.

Place the trampoline on a level surface before use.

Use the trampoline in a well-lighted area. Artificial illumination may be required for indoor or shady areas.

Remove any obstructions from beneath the trampoline.

The owner and supervisors of the trampoline are responsible to make all users aware of practices specified in the user instructions.

# CARE AND MAINTENANCE INSTRUCTIONS

Inspect the trampoline before each use and replace any worn, defective or missing parts. The following conditions could represent potential hazards:

1. Missing, improperly positioned, or insecurely attached frame padding.
2. Punctures, frays, tears, or holes worn in the bed or frame padding.
3. Deterioration in the stitching or fabric of the bed or frame padding.
4. Ruptured springs.
5. A bent or broken frame.
6. A sagging bed.
7. Sharp protrusions on the frame or suspension system.
8. Loosened or missing legs.

# USER INSTRUCTIONS

Do not allow more than one person on the trampoline. Use by more than one person at the same time can result in serious injuries.

Keep objects away which could interfere with the performer. Maintain a clear area around the trampoline. Do not allow foreign objects or animals on or under the trampoline.

Use trampoline only with mature, knowledgeable supervision.

The trampoline should be assembled in its entirety before each use. The frame cover should be positioned correctly at all times. By doing this you will make the trampoline safer.

Inspect the trampoline before each use. Make sure the frame cover is correctly and securely positioned. Replace any worn, defective, or missing parts.

The metal frame of the trampoline will conduct electricity. Lights, extension cords, and all such electrical equipment must never be allowed to come in contact with the trampoline.

Wear comfortable clothing. Remove jewelry, necklaces, and earrings.

Step on and off the trampoline. It is a dangerous practice to jump from the trampoline to the ground or floor when dismounting, or to jump onto the trampoline when mounting. Do not use the trampoline as a springboard to other objects.

Stop bounce by flexing knees as feet come in contact with the trampoline bed. Learn this skill before attempting others.

Avoid bouncing too high. Stay low until bounce control and repeated landing in the center of the trampoline can be accomplished. Control is more important than height.

While keeping the head erect, focus eyes on the trampoline toward the perimeter. This will help control bounce.

Avoid bouncing when tired. Keep turns short.

Do not use the trampoline while under the influence of alcohol or drugs.

For additional information concerning the trampoline equipment, contact the manufacturer.

Bounce only when the surface of the bed is dry.

Read all instructions before using the trampoline. Warnings and instructions for the care, maintenance, and use of this trampoline are included to promote safe, enjoyable use of this equipment.

# TRAMPOLINE SAFETY AND ACCIDENT PREVENTION

As in most recreational sports, participants may be injured. This section covers the most common accidents. Responsibilities of the supervisors and jumpers in accident prevention are also outlined.

The following are reasons why accidents happen:

**Attempting somersaults.** Landing on the head or neck can cause serious injury, paralysis, or death, even when landing in the middle of the bed.

**More than one person on the trampoline.** Use by more than one person at the same time can result in serious injuries.

**Incorrect mounting and dismounting.** Carefully step out of and onto the trampoline bed. Do not jump off to the ground. Do not jump from a table, or other object onto the ground. Do not step onto the suspension system.

**Hitting the frame.** Stay in the center of the trampoline when jumping. Injury may result from hitting the frame when control is lost. Be sure the frame cover is always on. Do not jump into the frame pad.

**Loss of control.** A jumper who loses control will increase his/her chance of injury. To regain control and stop your jump, bend your knees sharply as you land.

**Alcohol and drug use.** Because alcohol and drug use impairs the jumper's coordination, loss of control as well as injuries are greatly increased.

**Foreign objects.** Please make sure there is nothing sharp under and around the trampoline. Hitting objects under the trampoline can cause injury. Jumping with a foreign object can also increase the chances of getting injured. Be sure there is adequate clearance 10 feet above and 10 feet around the trampoline. Be careful of overhead wires, ceiling fans etc.

**Poor maintenance of the trampoline.** Make sure you inspect the trampoline before every use. Check for punctures on the bed, sharp burrs on the frame, stitching that has gone bad or loose elastic bands. If a replacement part is needed, please call our hotline to order .


**Storage.** Once the circular frame is assembled, it may not be taken apart. Remove legs & store entire frame when not in use.

# ASSEMBLY INSTRUCTIONS

Place all parts from the box in a cleared area and position them on the floor in front of you. Remove all packing materials from your area and place them back into the box. Do not dispose of the packing materials until assembly is completed.

**WARNING: Assembly by adults only.** Please use gloves to protect your hands from pinch points during assembly. When you are ready to start, make sure that you have plenty of space and a clean dry area for assembly. Failure to follow all instructions and warnings exactly may result in serious injury.

Keep children away from the trampoline during assembly.



Screw the 6 legs onto the trampoline.

# 90 DAYS LIMITED WARRANTY

## DO NOT RETURN TO PLACE OF PURCHASE

Subject to the following limitations, in addition to any imposed by virtue of applicable law, Airzone warrants this trampoline to be free of defects in material or workmanship for a period of 90 days from the date of original purchase. This warranty is limited to the repair and/or replacement of defective parts only.

1. This Limited Warranty will apply only if the Trampoline and/or its parts are properly returned to the Customer Service Department listed below and are determined by Customer Service in its sole discretion, to be defective.
2. This Limited Warranty applies only to Airzone trampolines purchased from authorized dealers. Limited Warranty is extended only to the original consumer purchaser and is not transferable.
3. Be sure to retain your original purchase sales receipt for any warranty claim. All warranty claims must be accompanied by the original purchase receipt from the authorized dealer.
4. Before returning any Trampoline and/or parts to Customer Service for warranty inspection, the consumer purchaser must obtain prior authorization from Customer Service. Such authorization can be obtained by calling our customer service representatives at the toll-free numbers listed below or writing to the Customer Service Department at the address listed below. Customer is responsible for all shipping costs.
5. This Limited Warranty does not cover damage or loss from: wind, rain, fire, snow, ice, or other forces of nature; accident; normal wear; improper assembly, disassembly, or adjustment during set-up or take-down; or any abuse, neglect or misuse of this trampoline and/or its parts. Any alteration to the original product void the warranty.
6. To the extent allowed by applicable law, any implied warranty of merchant ability or fitness applicable to this Trampoline is limited to the duration of this Limited Warranty. Airzone does not warrant against, and in no event shall Airzone or its authorized agents be liable for, any personal loss, injury, or direct or indirect incidental or consequential damage resulting from the use of this product. Please note that some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This Limited Warranty gives you specific legal rights and you may have other rights which vary from state to state.
7. Upon receipt of authorization from our Customer Service Department, you must submit your warranty claim to the address below, shipped prepaid and accompanied by the original dated purchase receipt. Do not return this product to the place of purchase. For warranty service, or for missing parts, replacement parts or any other problems, call or write to our Customer Service Department below. We will send any replacement parts via U.P.S. Ground.



**Distributed by Airzone Ltd.**

**Questions, Comments or Warranty Claims Call 1-800-775-6524**