


# Assembly Instructions




# Before Assembly

## Tips Before Your Start:


- Remove all wrapping material, including staples & packing straps before you start to assemble.
- DO NOT tighten all screws and bolts until the assembly is completely assembled.
- Keep all hardware parts out of reach of children.

## QUICKFIT



Tighten quickfit until shoulder is flush with panel. Do not overtighten or undertighten.


## CAM LOCK



When fitting a cam lock, ensure the starting position is correct before inserting the connecting QUI CKFIT

Quickfit head should be in the centre of the cam lock when the two panels are joined.

Cam lock should be inserted before quickfit.





Turn cam lock clockwise to tighten.

# Before Assembly


## Tips Before Your Start

How to separate the drawer slider:




2. Pull out the inner slider for drawer box fixing

## Drawer Front Alignment

















If the drawer front panel is NOT level after being assembled, then...




Loosen the screws on the left and right hand side, then adjust the drawer slide up or down, until the drawer fronts are even/level, then tighten the screws.



# Part List

<p><b>No. A</b> Quantity: 35 Pcs Cam Lock Dowel 8*28mm</p> 	<p><b>No. B</b> Quantity: 35 Pcs Cam φ15</p> 	<p><b>No. C</b> Quantity: 35 Pcs Sticker Ø20</p> 	<p><b>No. D</b> Quantity: 9 Pcs Dowel 8*30mm</p> 
<p><b>No. E</b> Quantity: 2 Sets Drawer Slider 10"</p> 	<p><b>No. F</b> Quantity: 16 Pcs Screw M3.5*12mm</p> 	<p><b>No. G</b> Quantity: 8 Pcs Screw M4*30mm</p> 	<p><b>No. H</b> Quantity: 8 Pcs Dowel 10*40mm</p> 
<p><b>No. I</b> Quantity: 9 Pcs Slip Mat Ø20</p> 	<p><b>No. J</b> Quantity: 2 Pcs Screw M6*40mm</p> 	<p><b>No. K</b> Quantity: 1 Pcs Allen Key 4#</p> 	<p><b>No. L</b> Quantity: 8 Sets Four-in-one</p> 
<p><b>No. M</b> Quantity: 2 Sets Anti-falling Parts</p> 	<p><b>No. N</b> Quantity: 1 Pcs Allen Key 5#</p> 		

# Product structure





# STEP 1



No. A  
Quantity: 5 Pcs  
8\*28 mm




# STEP 2




No. B  
Quantity: 5 Pcs  
Ø15





No. D  
Quantity: 2 Pcs  
8\*30mm





# STEP 3




The first screw hole should correspond with the board location hole






Flip to the other side.



No. E  
Quantity: 1 Sets  
10"




No. F  
Quantity: 4 Pcs  
M3.5\*12mm



No. A  
Quantity: 22 Pcs  
8\*28 mm




# STEP 5



No. B  
Quantity: 18 Pcs  
Ø15




No. D  
Quantity: 6 Pcs  
8\*30mm



# STEP 6

Note: Assemble the slide rail with the back side up.



No. J  
Quantity: 2 Pcs  
M6\*40mm




No. K  
Quantity: 1 Pcs  
4#




# STEP 7

Note: After the hardware is installed, the position of the holes must be as shown in the figure.




No. L  
Quantity: 8 Sets




Note: After the hardware is installed, the position of the holes must be facing up.

# STEP 8

Four-in-one  
installation method



No. H  
Quantity: 4 Pcs  
10\*40mm



No. N  
Quantity: 1 Pcs  
5#



No. L  
Quantity: 4 Sets




# STEP 9


No. B  
Quantity: 4 Pcs  
Ø15



No. D  
Quantity: 1 Pcs  
8\*30mm




No. H  
Quantity: 4 Pcs  
10\*40mm



No. N  
Quantity: 1 Pcs  
5#





No. L  
Quantity: 4 Sets




## Four-in-one installation method

The direction of the hole remains consistent.




The direction of the hole is upward.




Tighten with wrench completed.

# STEP 10



No. I  
Quantity: 9 Pcs  
Ø15




# STEP 11



The first screw hole should correspond with the board location hole




No. E  
Quantity: 1 Pcs  
10"





No. F  
Quantity: 2 Pcs  
M3.5\*12mm




# STEP 12



The first screw hole should correspond with the board location hole





No. E  
Quantity: 1 Pcs  
10"



No. F  
Quantity: 2 Pcs  
M3.5\*12mm




# STEP 13




No. A  
Quantity: 8 Pcs  
8\*28 mm



# STEP 14




No. G  
Quantity: 8 Pcs  
M4\*30mm





**× 2**

# STEP 15



**×2**

# STEP 16





No. B  
Quantity: 8 Pcs  
Ø15




# STEP 17



The first screw hole should corresponded with the board location hole




No. E  
Quantity: 2 Sets  
10"



No. F  
Quantity: 8 Pcs  
M3.5\*12mm



# STEP 18



# STEP 19

