


# 490R-I INSTRUCTIONS



1. Swing out all four cross-arms to a right angle (90 Degree).
2. Insert the clamp on cross arms.
3. Overlap the extension arms onto the cross arms, so that the center rail is right on the middle of the bed.
4. Slide the clamp onto the overlapped area (Fig. 1).
5. Determine desired width.
6. Tighten the L-Screws.
7. Insert glide on legs and adjust to proper height by turning the glide.
8. Adjust nut to support insert (Fig. 2)