


12' x 18' Metal Patio Gazebo

ASSEMBLY MANUAL



MODEL#: LGMF1619B

Missing part? Damaged? Contact us via email at

service@domioutdoorliving.com

www.domioutdoorliving.com

Pre-assembly



1. Two or more people are required for assembly.



2. You will need one or more stepladders.



3. Wearing protective gloves is recommended.



4. You may need a safety hat.



5. Please use a Phillips screw driver.



6. For ease of construction, you may need a drill.



7. You may need a safety goggle.



8. Do not fully tighten screws prior to complete assembly.

Warning & Attention



-Try to assemble this product on the flat ground, otherwise it is difficult to carry out;

-It would be much easier to assemble the product with three or more people;



-After assembly, please check whether all screws are tightened, to prevent parts from falling apart.

▲ Use bolts to secure the frame to the ground to against the strong wind.



1



If the deck is hard wood and the depth of it is over 3 inch, you can use **5/16 in. x4 in. Structural Wood Screw** to mount the gazebo.



2



If the ground is concreted and the depth of it is over 3 inch, you can use 1/4 inch expansion bolts to mount the gazebo


3



Or you can make a concrete footing for gazebo, **15x15x15 inches** is recommended. use expansion bolts to mount the gazebo like ② shows.



IMPORTANT:
Anchor is not recommended





A 4x Pole



A1 2x Pole




C 2x Beam



C1 2x Beam



D 2x Beam



D1 2x Beam




D2 2x Beam



E 4x Corner Roof Bar




E1 4x Corner Roof Bar Connector




E2 8x Roof Bar



F 4x Solidfying Bar




G 4x Solidfying Bar



G1 2x Solidfying Bar




G2 2x Solidfying Bar




H 2x Finishing Bar




H1 2x Finishing Bar



(H2) 2x Finishing Bar




(J) 2x Finishing Bar



(J1) 2x Finishing Bar



(J2) 2x Finishing Bar



(J3) 4x Finishing Bar



(K) 2x Finishing Bar



(K1) 2x Finishing Bar




(K2) 2x Finishing Bar




(K3) 2x Finishing Bar




(K4) 4x Finishing Bar




(K5) 4x Finishing Bar




(L1) 2x Roof Panel




(L2) 2x Roof Panel




(L3) 2x Roof Panel




(L4) 2x Roof Panel




(M1) 2x Roof Panel



(M2) 2x Roof Panel




M3 2x Roof Panel




M4 2x Roof Panel




M5 2x Roof Panel




M6 2x Roof Panel




M7 2x Roof Panel




M8 2x Roof Panel




N1 2x Roof Panel



N2 2x Roof Panel




N3 6x Roof Panel




N4 2x Roof Panel




N5 2x Roof Panel




P1 2x Roof Panel




P2 2x Roof Panel



P3 2x Roof Panel




P4 2x Roof Panel



P5 2x Roof Panel



P6 2x Roof Panel




P7 2x Roof Panel




P8 2x Roof Panel



P9 2x Roof Panel




P10 2x Roof Panel




P11 2x Roof Panel




P12 2x Roof Panel




Q 2x Net Frame




Q1 2x Net Frame



Q2 2x Net Frame



Q3 2x Net Frame



Q4 2x Net Frame



T 4x Track




T1 4x Track



T2 2x Track




T3 2x Track




B 4x Base




B1 12x Bracket




B3 2x Base




C2 6x Union Bar




(R) 4x Corner Solidifying Bar




(R1) 4x Corner Solidifying Bar




(S) 1x Inside Roof Connector




(S1) 1x Outside Roof Connector



(S2) 3x J-Hook




(U) 4x Bracket



(U1) 6x Bracket



(U2) 4x Bracket




(U3) 8x Bracket



(U4) 2x Bracket




(V) 144x Hook



(W) 148x Black Rubber



(X) 6x Joint Cover



(X1) 4x Corner Cover




(X2) 14x Finishing End




(X3) 12x Finishing End



(Y) 4x Curtains



(Y1) 4x Mosquito Netting




(Y2) 2x Mosquito Netting



(Y3) 2x Curtains



(Z) 72x Plastic Bracket



(Z1) 4x Plastic Bracket



(Z2) 4x Plastic Bracket



(Z3) 6x Plastic Bracket



(Z4) 6x Plastic Bracket



(1) 1x S4



(2) 36x ST6.3x15



(3) 24x ST5x16



(4) 32x M6x15




(5) 152x M6



(7) 28x M6x10




(8) 278x M6x16



M6x25

9


8x



M6x28

10


92x



M6x45

11


4x



M6x50

12

44x



	<p>A 4x</p>
	<p>B 4x</p>
	<p>B1 8x</p>
	<p>S4</p> <p>1 1x</p>
	<p>M6x16</p> <p>8 28x</p>
<p>8</p>	



(2) Attach Part #B to Part #A
with 3 Bolts #8.

(3) Repeat the above procedures to assemble the other 3 Part #A.










Diagram showing the installation of the B1 bracket to the side of the unit using screws 8. The bracket is labeled B1 and the screws are labeled 8. The quantity 2X is indicated.


(2) Attach Part #B3 to Part #A1 with 4 Bolts #8.




X2

(3) Repeat the above procedures to assemble another Part #A1.


BEAM ASSEMBLY:



C 2x




C1 2x



C2 2x



X 2x




1 1x




M6x16


8 20x




(1) Insert Part #C2 into Part #C1 and secure with 3 Bolts #8.




(2) Insert the other side of Part #C2 into Part #C and secure with 3 Bolts #8.




(4) Insert Part #X into the beam and secure with 1 Bolt #8.



(3) Connect Part #C1 and Part #C through Part #C2.















X2









(5) Secure the bottom of Part #X and Part #C/C1 with 3 Bolts #8.

(6) Repeat the above procedures to assemble the another beam.




(6) Repeat the above procedures to assemble the another beam.



(C2) 2x

(D1) 2x

(X) 2x

(S4) 1x

(8) 20x




(1) Insert Part #C2 into Part #D2, and secure with 3 Bolts #8.





(2) Insert the other side of Part #C2 into Part #D2 and secure with 3 Bolts #8.



(4) Insert Part #X into the beam and secure with 1 Bolt #8.





(3) Connect Part #D2 and Part #D through Part #C2.




(5) Secure the bottom of Part #X and Part #D2/D1 with 3 Bolts #8.

(6) Repeat the above procedures to assemble the another beam.

- 


T 4x
- 

T1 4x
- 


V 112x

TRACK ASSEMBLY:


(1) Slide the plastic hooks to the double-rail track #T & T1 (each slot should slide 7 plastic hooks).



(2) Repeat the above procedures for the other 3 track #T & T1.



T2 2x








T3 2x



V 32x

(1) Slide the plastic hooks to the double-rail track #T & T1 (each slot should slide 4 plastic hooks).



X2

(2) Repeat the above procedures for the another track #T2 & T3.

✓ S4


1 1x



M6x16

8 12x

(1) Use 6 Bolts #8 to fix the track T & T1 to the beam C & C1.



(2) Repeat the above procedures for the other beam.

✓ S4


1 1x



M6x16

8 24x


(1) Use 12 Bolts #8 to fix the track T,T2 ,T3 &T1to the beam D, D2 & D1.



(2) Repeat the above procedures for the other beam.




1 1x



M6x35

4 32x



(1) Connect Part #C and #D to Part #A with 8 Bolts #4.
(From Outside)

(2) Repeat the above procedures to assemble the other 3 corners.

▲ Please don't tighten all bolts.

✓ S4


1 1x



M6x16

8 16x

(1) Connect Part #C and #D to Part #A with 4 Bolts #8.
(From Inside)



Repeat the above procedures to assemble the other 3 corners.

▲ Please don't tighten all bolts.

✓ S4



1 1x



M6x16


8 10x

(1) Connect Part #A1 to the middle of Part #D2 with 5 Bolts #8.




Repeat the above procedures to assemble the opposite side.

▲ Please don't tighten all bolts.




(1) Affix Part #R and Part #R1 to the frame with 8 Bolts #8.

Inside View



Outside View



Repeat the above procedures to assemble the other 3 corners.

▲ Please don't tighten all bolts.





X1 4x



ST5x16



3 16x







(1) Cover the corner with Part #X1. (2) Secure with 2 Self-tapping Screws #3. (from top to bottom)




(3) Secure with 2 Self-tapping Screws #3. (from bottom to top)






Assemble the 4 Corner Roof Bars:




(1) Connect Part #E1 and Part #E with 2 Bolts #8 .



(2) Attach Part #U to Part #E with Bolt #8 .

(3) Repeat the above procedures to assemble the other 3 corner roof bars.



(S) 1x



S4

(1) 1x




M6x16

(8) 16x


Please have a freestanding ladder ready at the center of the gazebo.

(1) Place 4 Part #E1 on the 4 corners of Part #S. Secure with 8 Bolts #8.
(from bottom to top)









Outside View







ATTENTION: You can also finish this step on the ground and then lift 4 corner roof bars and inside roof connector to the top together.
(Need 2 people and 2 ladders)



Outside View







(2) Place 4 Part #E on 4 Part #A; secure with 8 Bolts #8.







-  **E2** 6x
-  **U1** 6x
-  **S4**
-  **1** 1x
-  **M6x10**
-  **7** 6x



(1) Attach Part #U1 to Part #E2 with Bolt #7 .



(2) Repeat the above procedures to assemble the other 5 roof bars.

-  E2 2x
-  U4 2x
-  S4
-  1 1x
-  M6x10
-  7 2x




(1) Attach Part #U4 to Part #E2 with Bolt #7 .


(2) Repeat the above procedures to assemble another roof bar.




(1) Place Part #E2 on part #S. Secure with Bolt #8 (from bottom to top).



Outside View





Inside View



(2) Connect Part #E2 and Part A1 with part #U4. Secure with 2 Bolts #8.

(3) Repeat the above procedures to assemble the opposite side.




1 1x





8 6x


(1) Place Part #E2 on Part #S.
Secure with Bolt #8 (from bottom to top).



Outside View





Inside View




(2) Connect Part #E2 and the Assembled Beam (C&C1) with
part #U1. Secure with 2 Bolts #8.




(3) Repeat the above procedures to assemble the opposite side.



(1) Place Part #E2 on Part #S.
Secure with Bolts #8 (from bottom to top).




Outside View




Inside View

(2) Connect Part #E2 and the Assembled Beam (D1&D2&D) with part #U1. Secure with 2 Bolts #8.


(3) Repeat the above procedures to assemble the opposite side.



S1 1x





S2 3x




Secure 3 Part # S2 to Part #S and Part #S1. (From bottom to top)

ATTENTION: The holes of Part #S and Part #S1 need to be aligned, on the same vertical line.






G1 2x



G2 2x



U3 6x



1 1x



M6x10


7 6x




M6x16

8 8x


30




(1) Insert Part #U3 into Part #G1 and secure with Bolt #8.




(2) Insert 2 Part #U3 into Part #G2 and secure with 2 Bolts #8.




Inside View




(3) Attach Part #G1 and Part #U3 to Part #E2 with Bolt #7.



(4) Attach Part #G2, G1 and Part #U3 to Part #E2 with Bolt #7 and Bolt #8.




(5) Attach Part #G2 and Part #U3 to Part #E2 with Bolt #7.




Outside View

(6) Repeat the above procedures to assemble the opposite side.



G 4x





1 1x




M6x16


8 4x



Inside View




(1) Attach Part #G and Part #U3 to Part #E2 with Bolt #8




Outside View

(2) Repeat the above procedures to assemble the opposite side.



F 4x



U3 2x



1 1x



M6x10



7 2x



M6x16

8 4x

Attach 2 Part #F and Part #U3 to Part #E2 with Bolt #7 and Bolt #8.



Repeat the above procedures to assemble the opposite side.



U2 4x






1 1x



M6x16

8 12x



Outside View


2x













(1) Insert Part #U2 into Part #F and Part #G.

(2) Secure with 2 Bolts #8.

(3) Secure them to Part #E with Bolt #8.




(4) Repeat the above procedures to assemble the other 3 sides.



J1 2x

J2 2x

J3 4x

Q1 2x

Q2 2x

Q3 2x

Q4 2x
 
1 1x

M6 5 8x
34

- (1) Connect Part #J1 and Part #Q1 with 1 Bolt #7 and 1 Nut #5.
- (2) Connect Part #J3 and Part #Q3 with 1 Bolts #7 and 1 Nuts #5.


X2



X2



- (3) Connect Part #J3 and Part #Q4 with 1 Bolts #7 and 1 Nuts #5.
- (4) Connect Part #J2 and Part #Q2 with 1 Bolt #7 and 1 Nut #5.



- (5) Repeat the above procedures to assemble the opposite side.




M6x10

7 8x




ST6.3x15


2 6x




Inside View




(1) Place the Assembled J1 & Q1, J3 & Q3, J3 & Q4 and J2 & Q2 on Part #E2, securing with 3 Self-tapping Bolts #2.




(2) Repeat the above procedures to assemble the opposite side.



J 2x



Q 2x



1 1x



ST6.3x15

2 2x



M6

5 4x




M6x10



7 4x

36

(1) Connect Part #J and Part #Q with 2 Bolts #7 and 2 Nuts #5.



(2) Place the Assembled Part #J & #Q on Part #E2, securing with 1 Self-tapping Bolt #2.



(3) Repeat the above procedures to assemble the opposite side.




(X3) 4x




ST6.3x15

(2) 4x

(1) Place Part #J and Part #J1 on Part #E; put on Part #X3 and secure with Self-tapping Screw #2.












Inside View



(2) Repeat the above procedures to assemble the other 3 corners.


Cover Part #Z, #Z1 & #Z2 to Roof Panels.

-  (L1) 2x
-  (L2) 2x
-  (L3) 2x
-  (L4) 2x
-  (Z) 8x
-  (Z1) 4x
-  (Z2) 4x




Attach Z/Z1/Z2/Z3/Z4 by lightly tapping with a screwdriver.


Cover Part #Z, #Z3 & #Z4 to Roof Panels.




(N1) 2x




(N2) 2x



(N3) 6x



(N4) 2x



(N5) 2x



(Z) 12x





(Z3) 2x




(Z4) 2x

X2




Section View




X2


ATTENTION: The bigger roof panel need to cover the smaller one.




H1 2x



H2 2x





H1




H2

(1) Insert Part #N1 and Part #N2 into the frame; attach Part #H1 to Part #E2, securing with Bolt #2.

(2) Insert Part #N5 and Part #N4 into the frame; attach Part #H2 to Part #E, securing with Bolt #2.




⚠ Please don't tighten all bolts.





(3) Repeat the above procedures to assemble the opposite side.

(1) Insert 3 Part #N3 into the frame.




⚠ When installing Part #H1, K4, K5, H2, you should unscrew the bolt that have not been tightened.





K4 2x



K5 2x




X2 6x




ST6.3x15



2 6x



(1) Place Part #H1 and Part #K4 on Part #E2; put on Part #X2 and secure with Bolt #2.




(2) Place Part #K4 & #K5 on Part #E2; put on Part #X2 and secure with Bolt #2.



(3) Place Part #K5 and Part #H2 on Part #E2; put on Part #X2 and secure with Bolt #2.

(4) Repeat the above procedures to assemble the opposite side.

ATTENTION: The bigger roof panel need to cover the smaller one.




(H) 2x




ST6.3x15




(2) 2x



(1) Insert Part #L1 and Part #L2 into the frame.



(2) Insert Part #L4 and Part #L3 into the frame.



(3) Attach Part #H to Part #E2, securing with Self-tapping Bolts #2.

(4) Repeat the above procedures to assemble the opposite side.




(X3) 4x




ST6.3x15

(2) 4x

(1) Place Part #H and Part #H2 on Part #E1;
put on Part #X3 and secure with Self-tapping Screw #2.





Outside View




(2) Repeat the above procedures to assemble the other 3 corners.

Cover Part #Z to Roof Panels



X2




Section View




X2




M1 2x




M2 2x




M3 2x




M4 2x



M5 2x




M6 2x



M7 2x



M8 2x




Z 28x


Cover Part #Z, #Z3 and #Z4 to Roof Panels




P1 2x




P2 2x




P3 2x



P4 2x



P5 2x



P6 2x



Z 12x




Z3 2x





Z4 2x

46




X2




X2

Cover Part #Z, #Z3 and #Z4 to Roof Panels


P7 2x




P8 2x




P9 2x




P10 2x



P11 2x



P12 2x



Z 12x




Z3 2x



Z4 2x



47



P7


X2

P8

P9

Z4

X2



P10

P11

P12

Z

Z


Z


Z

Z





Z


Z3






▲ Part #W should be inserted between roof panels and solidifying bar or beams, then secure with bolts and nuts.





(W) 24x



(1) 1x




M6

(5) 24x



M6x28



(10) 20x



M6x50



(12) 4x

ATTENTION: The bigger roof panel need to cover the smaller one.




(1) Insert Part #P1, Part #P2 and Part #P3 into the frame.

(2) Insert Part #P12, Part #P11 and Part #P10 into the frame.




(3) Place 2 Part #W between roof panels and solidifying bars. Then secure with 2 Bolts #12 and 2 Nuts #5.


(4) Place 10 Part #W between roof panels and beams. Then secure with 10 Bolts #10 and 10 Nuts #5.



(5) Repeat the above procedures to assemble the opposite side.



(W) 40x



(1) 1x




M6

(5) 40x



M6x28

(10) 24x




M6x50



(12) 16x

ATTENTION: The bigger roof panel need to cover the smaller one.


(1) Insert Part #P4 and Part #P5 into the frame.




(2) Insert Part #P9 and Part #P8 into the frame.




(3) Place 8 Part #W between roof panels and solidifying bars. Then secure with 8 Bolts #12 and 8 Nuts #5.




(4) Place 12 Part #W between roof panels and beams. Then secure with 12 Bolts #10 and 12 Nuts #5.



(5) Repeat the above procedures to assemble the opposite side.



(W) 24x




(1) 1x



M6

(5) 20x




M6x25

(9) 4x



M6x28

(10) 12x





M6x50


(12) 8x

ATTENTION: The bigger roof panel need to cover the smaller one.



(1) Insert Part #P6 into the frame.



(3) Place 4 Part #W between roof panels and solidifying bars. Then secure with 4 Bolts #12 and 4 Nuts #5; Place 1 Part #W between roof panels and Part #E2. Then secure with 1 Bolt #9.




(2) Insert Part #P7 into the frame.




(4) Place 6 Part #W between roof panels and beams. Then secure with 6 Bolts #10 and 6 Nuts #5; Place 1 Part #W between roof panels and Part #E2. Then secure with 1 Bolt #9.

(5) Repeat the above procedures to assemble the opposite side.



(W) 12x



(1) 1x



M6


(5) 12x




M6x28

(10) 12x


ATTENTION: The bigger roof panel need to cover the smaller one.



(1) Insert Part #M1 and Part #M2 into the frame.




(2) Insert Part #M8 and Part #M7 into the frame.




(3) Place 6 Part #W between roof panels and beams.
Then secure with 6 Bolts #10 and 6 Nuts #5.

(4) Repeat the above procedures to assemble the opposite side.



(W) 20x




(1) 1x




M6

(5) 20x



M6x28

(10) 12x




M6x50



(12) 8x

ATTENTION: The bigger roof panel need to cover the smaller one.


(1) Insert Part #M3 into the frame.




(2) Insert Part #M6 into the frame.




(3) Place 4 Part #W between roof panels and solidifying bars. Then secure with 4 Bolts #12 and 4 Nuts #5.




(4) Place 6 Part #W between roof panels and beams. Then secure with 6 Bolts #10 and 6 Nuts #5.



(5) Repeat the above procedures to assemble the opposite side.



(W) 24x




(1) 1x



M6

(5) 20x




M6x25

(9) 4x



M6x28

(10) 12x




M6x50


(12) 8x

ATTENTION: The bigger roof panel need to cover the smaller one.


(1) Insert Part #M4 and Part #M5 into the frame.




(2) Place 4 Part #W between roof panels and solidifying bars. Then secure with 4 Bolts #12 and 4 Nuts #5;
Place 1 Part #W between roof panels and Part #E2. Then secure with 1 Bolt #9.




(3) Place 6 Part #W between roof panels and beams. Then secure with 6 Bolts #10 and 6 Nuts #5; Place 1 Part #W between roof panels and Part #E2. Then secure with 1 Bolt #9.



(4) Repeat the above procedures to assemble the opposite side.



(W) 4x




(1) 1x



M6



(5) 4x




M6x45

(11) 4x


Place Part #W between roof panels and Part #E2. Then secure with Bolt #11 and Nut #5.




Repeat the above procedures to assemble the other 3 sides.




K2 2x




K3 2x



K4 2x



K5 2x




X2 6x





ST6.3x15


2 6x



(1) Place Part #K4 and Part #K5 on Part #E2; Put on Part #X2 and secure with Bolt #2.




(2) Place Part #K2 on Part #K4 and Part #E2; Put on Part #X2 and secure with Bolt #2.




(3) Place Part #K3 on Part #K5 and Part #E2; Put on Part #X2 and secure with Bolt #2.

(4) Repeat the above procedures to assemble the opposite side.



(K) 2x



(K1) 2x





(X2) 2x



ST6.3x15

(2) 2x

(1) Attach Part #K and Part #K1 to the frame; Put on Part #X2 and secure with Self-tapping Bolt #2.



(2) Repeat the above procedures to assemble the opposite side.




X3 4x



ST6.3x15

2 4x



(1) Place Part #K3 and Part #K on Part #E;
Put on Part #X3 and secure with Self-tapping Screw #2.


(2) Repeat the above procedures to assemble the other 3 corners.



ST5x16

3


8X



Attach roof panels to finishing bars
with 8 Self-tapping Screws #3.




Y1 4x




Y2 2x



Hang up Mosquito Netting to Inside Track



Y1




Y1



Y1


7 Hooks

Y1



7 Hooks



7 Hooks



Y1

7 Hooks


Y2 8Hooks



Y2


8Hooks

Y1




7 Hooks

7 Hooks



Y1

7 Hooks







Y 4x



Y3 2x

Hang up Curtains to Outside Track




7 Hooks

Y

7 Hooks


7 Hooks



7 Hooks

Y


Y3 8Hooks



8Hooks

Y3


Y



7 Hooks


7 Hooks

7 Hooks



7 Hooks

Y



Thanks for your purchase.

At domi outdoor living, we believe in our products.

That's why we provide a 12-month warranty and friendly, easy-to-reach after-sales service. So if you have any questions about our product and assembly, please feel free to contact us. We will be here for you.

Support:



After-sales contact email:

service@domioutdoorliving.com

Please tell us your order ID when contact.

Attach photos of damaged part for instant reply.