


























<p>1</p>  <p>1PCS</p>	<p>2</p>  <p>1PCS</p>	<p>3</p>  <p>1PCS</p>	<p>4</p>  <p>1PCS</p>
<p>5</p>  <p>1PCS</p>	<p>6</p>  <p>1PCS</p>	<p>7</p>  <p>1PCS</p>	<p>8</p>  <p>1PCS</p>
<p>9</p>  <p>1PCS</p>	<p>10</p>  <p>2PCS</p>	<p>11</p>  <p>1PCS</p>	<p>12</p>  <p>1PCS</p>
<p>13</p>  <p>1PCS</p>	<p>14</p>  <p>2PCS</p>	<p>15</p>  <p>1PCS</p>	<p>16</p>  <p>1PCS</p>
<p>17</p>  <p>1PCS</p>	<p>18</p>  <p>1PCS</p>	<p>19</p>  <p>2PCS</p>	<p>20</p>  <p>4PCS</p>
<p>21</p>  <p>2PCS</p>	<p>22</p>  <p>1PCS</p>		

STEP 1







STEP 2







STEP 3

Make sure the screws are loose before pressing




A1	22PCS
	
Ø6*35mm	



STEP 4



Q	6PCS	N ₁	2PCS
M3.5*14mm		12"	





STEP 5




A2	4	B	4
Ø15*11.5mm		Ø8*40mm	



STEP 6




A2	2
	
Ø15*11.5mm	



STEP 7




A2	4	B	4
			
Ø15*11.5mm		Ø8*40mm	


STEP 8




A2	4	B	4
			
Ø15*11.5mm		Ø8*40mm	


STEP 9





R	4
	
M3.5*30mm	





STEP 10






A2	8	B	8
			
Ø15*11.5mm		Ø8*40mm	


STEP 11






P*12
Q*12

R*7


R	7	P	12	Q	12
					
M3.5*30mm				M3.5*14mm	




STEP 12




C	6PCS	N ₂	2PCS
M3.5*12mm		12"	




STEP 13




D	6PCS	E	6PCS
M4*45mm		10*10mm	




STEP 14



D	6PCS	E	6PCS
M4*45mm		10*10mm	




STEP 15




H	3PCS	G	2PCS	F	2
M6*22mm		M4*16mm			


STEP 16




Q	8PCS	K	4PCS	G	4PCS
M3.5*14mm				M4*16mm	




STEP 17






Note: align N1 with N2 and push it in



STEP 18





Q 8	S 8
	
M3. 5*14mm	




STEP 19

The screw holes on the top and bottom can adjust the height of the door panel.




Q	16PCS
	
M3.5*14mm	




Door hinge adjustment method

Method 1:



Method 2:



Method 3:

