

# Assembly Instructions



### **General Assembly Guidelines**


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are : wood dowels , screws and bolts.
- V. The provided glue is to secure wood dowels in place. When first inserting dowels, locate the appropriate hole for the dowel, place a small amount of glue in the hole and insert the dowel. Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together , place a small amount of glue on the end of the dowel before attaching parts together . Wipe away excess glue immediately.




VI. A Phillips head screwdriver is required for the assembly of this product.



VII. Power tools should not be used to assemble this product.






## Hardware List


Α		Ø8x30mm	Wooden dowel	6	pcs
В		Ø6x35mm	Cam bolt	6	pcs
С		Ø15x12mm	Cam lock	6	pcs
D			Door stopper	1	рс
E	<	Ø3x15mm	Small screw	2	pcs
F	<i>ammmmm</i>	Ø6x50mm	Large screw	4	pcs
G		Ø4mm	Wrench	1	рс
Н	<b></b>		Nail	22	pcs
I		Ø5x15mm	Shelf support pin	8	pcs
J			Handle	2	pcs
K	<=====================================	Ø4x22mm	Screw	2	pcs
L		Ø83x23x2	Door hinge	4	pcs
M		Ø4x15	Flat-head screw	24	pcs
N		Ø13x5x8	Small bolt	2	pcs
Р			Nylon strap	1	рс
Q	<	Ø3x12	Small screw	1	рс
R	<======================================		Large screw	1	рс
S			Plug	1	рс
Т			Glue tube	1	рс
U		Ø30	Sticker	6	pcs

<sup>\*</sup> A hammer is required to install nails (H).


The hardware quantities listed above are required for proper assembly. Some extra hardware may also have been included.




Screw cam bolts (B) into top panel (1). Insert dowels (A) into shelf (7). Attach door stopper (D) to top panel (1) using small screws (E). Attach nylon strap (P) to top panel (1) using small screw (Q).











Attach side panels (3,4) to shelf (7) using cam bolts and dowels as guides. Insert cam locks (C) into shelf (7) and tighten with a screwdriver.


## Step 4



Attach bottom panel (2) to the assembly from Step 3 using large bolts (F) and wrench (G).









Attach top panel (1) to the assembly from Step 4 using cam bolts and dowels as guides. Insert cam locks (C) into top panel (1) and tighten with a screwdriver.






Secure back panel (9) to the assembly from Step 5 by gently hammering nails (H) into the assembly at the points shown above. Note that nylon strap (P) should hang out the back of the assembly.

## Step 7




Insert shelf support pins (I) into the stand assembly at desired shelf heights. Carefully place shelves (8) onto shelf support pins (I). Note that there will be two shelf support pins on either end of each shelf.



Attach handles (J) to doors (5,6) using medium screws (K). Attach hinges (L) to doors (5,6) using flat-head screws (M). Screw small bolts (N) into doors (5,6).






Attach doors (5,6) to the assembly from Step 7 using flat-head screws (M) at hinges (L).

Step 10

**WALL** 




Final Assembly


### Step 11 (Optional)

We strongly recommend that this item is attached to a wall to prevent it from falling over. Due to the wide variety of wall types, the necessary hardware for wall attachment may not be included. There is included in this package large screw (R) and plug (S) for use in general wall attachment. To attach the item to a wall, use only hardware that is suitable for that particular wall type. Several hardware and wall types are illustrated below. Suitable hardware is available from any hardware store. Please seek professional advice if you are unsure of your ability to mount this item correctly.


### **Cement/Brick**



#### **Wood Studs**



#### **Drywall**



### **Metal Studs**

