
























# ASSEMBLY INSTRUCTIONS

## DAYBED WITH LIFT-UP TRUNDLE


<b>A</b> Post A  2PCS	<b>B</b> Post B  2PCS	<b>C</b> LSF Arm  1PC	<b>D</b> RSF Arm  1PC
<b>E</b> Back Frame  1PC	<b>F</b> Rail  2PCS	<b>G</b> Trundle Rail  2PCS	<b>H</b> Trundle End Rail  2PCS
<b>I</b> Trundle Leg  2PCS	<b>J</b> Trundle Caster  4PCS	<b>K</b> Slat  42PCS	<b>L</b> Slat Spacer  40PCS
<b>M</b> Slat Connector  84PCS	<b>N</b> Bracket  4PCS	<b>O</b> Bolt 5/16" x 40mm  4PCS	<b>P</b> Bolt 1/4" x 55mm  6PCS
<b>Q</b> Bolt 1/4" x 19mm  22PCS	<b>R</b> Bolt 5/16" x 19mm  8PCS	<b>S</b> Bolt 5/16" x 34mm  4PCS	<b>T</b> Nut 5/16"  8PCS
<b>U</b> Allen Key 4mm x 100mm  1PC	<b>V</b> Wrench 1/4" - 5/16"  1PC		




The above page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

**1**


Attach Post (A & B) to LSF Arm (C) using Bolt (Q & P) with Allen Key (U).

**2**

Attach Post (A & B) to RSF Arm (D) using Bolt (Q & P) with Allen Key (U).


**3**

Attach Back Frame (E) to Arm (C & D) using Bolt (Q & P) with Allen Key (U).




4

Attach Rail (F) to Post (A & B) and Arm (C & D) using Bolt (R) with Allen Key (U).




5

Insert Slat (K) into Rail (F) as shown. Then lock Slat Connector (M) to fix Slat (K).




6

Connect Slat (K) using Slat Spacer (L) as shown.




7

Attach Trundle Caster (J) to Trundle Leg (I) using Bolt (O) and Nut (T) with Allen Key (U) and Wrench (V).




8

Attach Trundle End Rail (H) to Trundle Rail (G) using Bolt (Q) with Allen Key (U).




9

Attach Trundle Leg (I) to Trundle Rail (G) using Bolt (S) and Nut (T) with Allen Key (U) and Wrench (V).




**10**


Attach Bracket (N) to Trundle Rail (G) using Bolt (Q) with Allen Key (U).

**11**

Insert Slat (K) into Trundle Rail (G) as shown. Then lock Slat Connector (M) to fix Slat (K).

**12**

Connect Slat (K) using Slat Spacer (L) as shown.



## Cleaning & Care

Treat surfaces with care. Surfaces are resistant to scratches but are not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.