
















Metal Chair



PART LIST

A 	B 	C 	D 	E 
Chair Back 1 PC	Chair Seat 1 PC	Left Support Leg 1 PC	Right Support Leg 1 PC	Leg Connector 1 PC
F 				
Crossbar 1 PC				


HARDWARE LIST

#1 	#2 	#3 	#4 	#5 
M6X40mm Long Bolt 4 PCS (Extra 1)	M6X38mm Medium Bolt 4 PCS (Extra 1)	M6X13mm Short Bolt 3 PCS	Hex Nut 11 PCS (Extra 2)	Flat Washer 22 PCS (Extra 4)
#6 	#7 	#8 		
Wrench 1 PC	Allen Wrench 1 PC	Plastic Washer 4 PCS		


NOTE: We recommend at least two people work together to assemble unit.

Step 1. Lay chair seat (part B) down on a soft flat surface, such as carpet, as shown below. Attach chair back (part A) to chair seat (part B) using short bolts (part #3), hex nuts (part #4), flat washers (part #5), wrench (part #6) and allen wrench (part #7).

NOTE: Please do not fully tighten bolts until unit is fully assembled.




Step 2. Attach left support leg (part C) and right support leg (part D) to leg connector (part E).




Step 3. Attach support legs (parts C & D) to chair back (part A) and chair seat (part B) using long bolts (part #1), hex nuts (part #4), flat washers (part #5), plastic washers (part #8), wrench (part #6) and allen wrench (part #7).






NOTE: Please do not fully tighten bolts until unit is fully assembled.



Step 4. Attach crossbar (part F) to left support leg (part C) and right support leg (part D) using medium bolts (part #2), hex nuts (part #4), flat washers (part #5), wrench (part #6) and allen wrench (part #7).

NOTE: Please fully tighten all bolts at this time.



- | | | |
|----|---|-----|
| #2 |  | X 4 |
| #4 |  | X 4 |
| #5 |  | X 8 |
| #6 |  | X 1 |
| #7 |  | X 1 |