


natural wood

5 shelf storage unit

Assembly Instructions

PACK CONTAINS:

5 Shelves • 8 Uprights • 4 Connecting Blocks • 32 Small Screws • 41 Large Screws • 1 Wall Plug



STEP 1 Assemble the uprights by taking 2 x uprights and place them on a flat surface end to end, ensure the two ends butt up together level and square (the counter sink holes in the uprights should be on the outside face of the upright), place the connecting block onto the uprights keeping 4 x holes to either side of each upright. Attached the connecting block by inserting the small screws through the pre drilled holes in the connecting block into the upright. Repeat process to create 4 x full uprights

STEP 2 Attach the uprights to the under shelf support as per the diagram, line up the screws to the middle of the shelf strap support, and then fully insert. Repeat for all shelves at your required height.

STEP 3 We recommend that you fix the free standing storage unit to the wall using the screw and wall plug supplied. (If you have a skirting board along the floor you may need to use a spacing block to fill out the gap between the wall and the shelf unit. Different sizes screws maybe required or specialised screws and wall plugs if attaching into a dry wall panels which are not supplied). Place the shelf unit against the wall and mark the position for wall fixing screw on your wall through the pre-drilled hole in the upright.

WARNING: CHECK FOR HIDDEN PIPES AND CABLES BEFORE DRILLING.

IMPORTANT: IF YOUR WALLS ARE NOT SOLID LIKE BRICK OR STONE, YOU WILL REQUIRE SPECIALIST FITTINGS (NOT SUPPLIED)

STEP 4 Drill holes in your wall to a depth of 30mm using a 6mm drill bit. If the surface of your wall is soft and crumbly, we would advise you to sue a 5mm drill bit for a tighter fit.

STEP 5 Insert plugs into holes with ends flush to the wall surface.

STEP 6 Insert screw through the pre-drilled hole in the upright and insert into the wall plug and secure.



**MAX LOAD
PER SHELF
4 KGS**

