




12' × 16' Metal Patio Gazebo

ASSEMBLY MANUAL



MODEL#: LGMF1598B

Missing part? Damaged? Contact us via email at

service@domioutdoorliving.com

Pre-assembly



1. Two or more people are required for assembly.



2. You will need one or more stepladders.



3. Wearing protective gloves is recommended.



4. You may need a safety hat.



5. Please use a Phillips screw driver.



6. For ease of construction, you may need a drill.



7. You may need a safety goggle.



8. Do not fully tighten screws prior to complete assembly.

Warning & Attention



-Try to assemble this product on the flat ground, otherwise it is difficult to carry out;

-It would be much easier to assemble the product with three or more people;



-After assembly, please check whether all screws are tightened, to prevent parts from falling apart.

▲ Use bolts to secure the frame to the ground to against the strong wind.



1



If the deck is hard wood and the depth of it is over 3 inch, you can use **5/16 in. x4 in. Structural Wood Screw** to mount the gazebo.





2




If the ground is concreted and the depth of it is over 3 inch, you can use 1/4 inch expansion bolts to mount the gazebo

3



Or you can make a concrete footing for gazebo, **15×15×15 inches** is recommended. use expansion bolts to mount the pergola like (2) shows.

IMPORTANT:
Anchor is not recommended





A 4x Pole




C 2x Beam



C1 2x Beam



D 2x Beam



D1 2x Beam




D2 2x Beam



E 4x Corner Roof Bar




E1 4x Corner Roof Bar Connector



E2 8x Roof Bar




F 4x Solidfying Bar




G 4x Solidfying Bar




G1 4x Solidfying Bar




H 2x Finishing Bar



H1 2x Finishing Bar



H2 2x Finishing Bar



J 2x Finishing Bar



J1 2x Finishing Bar



J2 2x Finishing Bar



K 2x Finishing Bar



K1 2x Finishing Bar




K2 2x Finishing Bar




K3 2x Finishing Bar




K4 2x Finishing Bar




L1 2x Roof Panel




L2 2x Roof Panel




L3 2x Roof Panel




L4 2x Roof Panel



M1 2x Roof Panel




M2 2x Roof Panel




M3 2x Roof Panel




M4 2x Roof Panel




M5 2x Roof Panel



(M6) 2x Roof Panel




(M7) 2x Roof Panel



(M8) 2x Roof Panel




(N1) 2x Roof Panel



(N2) 2x Roof Panel




(N3) 4x Roof Panel




(N4) 2x Roof Panel




(N5) 2x Roof Panel



(P1) 2x Roof Panel



(P2) 2x Roof Panel



(P3) 2x Roof Panel



(P4) 2x Roof Panel



(P5) 2x Roof Panel



(P6) 2x Roof Panel



(P7) 2x Roof Panel



(P8) 2x Roof Panel



(P9) 2x Roof Panel



(P10) 2x Roof Panel



(Q) 2x Net Frame



(Q1) 2x Net Frame




(Q2) 2x Net Frame




(T) 4x Track



(T1) 4x Track



(T2) 2x Track



(B) 4x Base



(B1) 8x Bracket



(C2) 6x Union Bar



(R) 4x Corner Solidifying Bar




(R1) 4x Corner Solidifying Bar



(S) 1x Inside Roof Connector



(S1) 1x Outside Roof Connector



(S2) 3x J-Hook



(U) 4x Bracket




(U1) 8x Bracket



(U2) 4x Bracket



(U3) 8x Joint Cover



(V) 128x Hook



(W) 140x Black Rubber



(X) 6x Joint Cover




(X1) 4x Corner Cover




X2 8x




X3 12x




Y 4x



Y1 4x




Z 76x



Z1 4x



Z2 4x



1 1x




ST6.3x15

2 36x



ST5x16

3 24x



M6x35

4 32x



M6

5 144x




M6x10

7 28x



M6x16

8 248x




M6x25

9 8x




M6x28

10 88x




M6x45

11 4x




M6x50

12 40x



5



A 4x



B 4x



B1 8x




1 1x




M6x16

8 28x

(1) Attach 2 Part #B1 to Part #A with 4 Bolts #8.




(2) Attach Part #B to Part #A with 3 Bolts #8.




6


(3) Repeat the above procedures to assemble the other 3 Part #A.




C 2x




C1 2x




C2 2x



X 2x



1 1x




8 20x




M6x16

7

(1) Insert Part #C2 into Part #C1 and secure with 3 Bolts #8.





(2) Insert the other side of Part #C2 into Part #C and secure with 3 Bolts #8.










(4) Insert Part #X into the beam.

(3) Connect Part #C1 and Part #C through Part #C2.




(5) Secure the bottom of Part #X and Part #C/C1 with 3 Bolts #8.




(6) Repeat the above procedures to assemble the other Part #C and Part #C1.


C2 4x

D 2x

D1 2x

D2 2x

X 4x

1 1x S4

8 40x M6x16
8 40x
8

(1) Insert Part #C2 into Part #D, and secure with 3 Bolts #8.





(2) Insert the other side of Part #C2 into Part #D2 and secure with 3 Bolts #8.




(4) Insert Part #X into the beam and secure with 1 Bolt #8

(3) Connect Part #D and Part #D2 through Part #C2.




(5) Secure the bottom of Part #X and Part #D/D2 with 3 Bolts #8.


(6) Repeat the above procedures to assemble the other Part #D & #D1 & #D2.



T 2x







T1 2x



V 56x

TRACK ASSEMBLY:









(1) Slide the plastic hooks to the double-rail track #T & T1 (each slot should slide 7 plastic hooks).



(2) Repeat the above procedures for the another 3 track #T & T1.

TRACK ASSEMBLY:

(1) Slide the plastic hooks to the double-rail track #T & T2 & T1 as shown.



(2) Repeat the above procedures for another track #T & T2 & T1.

✓ S4


1 1x



M6x16

8 12x

(1) Use 6 Bolts #8 to fix the track T & T1 to the beam C & C1.



11

(2) Repeat the above procedures for another beam C & C1.


✓ S4

1 1x

M6x16

8 20x

(1) Use 10 Bolts #8 to fix the track T & T2 & T1 to the beam D & D2 & D1.



X2


12

(2) Repeat the above procedures for another beam D & D2 & D1.




S6

1 1x



M6x35

4 32x



(1) Connect Part #C/C1 and #D/D1 to Part #A with 8 Bolts #4.
(From Outside)

(2) Repeat the above procedures to assemble the other 3 corners.

▲ Please don't tighten all bolts.

✓ S4


1 1x



M6x16





8 16x

(1) Connect Part #C/C1 and #D/D1 to Part #A with 4 Bolts #8.
(From Inside)




Repeat the above procedures to assemble the other 3 corners.


▲ Please don't tighten all bolts.

-  **R** 4x
-  **R1** 4x
-  **S4**
- 1** 1x
-  **M6x16**
- 8** 32x


(1) Affix Part #R and Part #R1 to the frame with 8 Bolts #8.



Inside View




Outside View



Repeat the above procedures to assemble the other 3 corners.

▲ Tighten all bolts.





X1 4x



ST5x16



3 16x








(1) Cover the corner with Part #X1. (2) Secure with 2 Self-tapping Screws #3. (from top to bottom)




(3) Secure with 2 Self-tapping Screws #3. (from bottom to top)




Repeat the above procedures to assemble the other 3 corners.



Assemble the 4 Corner Roof Bars:




(1) Connect Part #E1 and Part #E with 2 Bolts #8 .



(2) Attach Part #U to Part #E with Bolt #8 .

(3) Repeat the above procedures to assemble the other 3 corner roof bars.



S 1x



1 1x




M6x16

8 16x


Please have a freestanding ladder ready at the center of the gazebo.

(1) Place 4 Part #E1 on the 4 corners of Part #S. Secure with 8 Bolts #8. (from bottom to top)








Outside View





ATTENTION: You can also finish this step on the ground and then lift 4 corner roof bars and inside roof connector to the top together. (Need 2 people and 2 ladders)



Outside View

(2) Place 4 Part #E on 4 Part #A; Secure with 8 Bolts #8.

-  E2 8x
-  U1 8x
-  S4
-  1 1x
-  M6x10
7 8x



(1) Attach Part #U1 to Part #E2 with Bolt #7 .
 (2) Repeat the above procedures to assemble the other 7 roof bars.

✓ S4



1 1x




M6x16

8 6x


(1) Place Part #E2 on part #S. Secure with Bolt #8 (from bottom to top).



Outside View



Inside View



(2) Connect Part #E2 and the Assembled Beam (C&C1) with part #U1; Secure with 2 Bolts #8.

(3) Repeat the above procedures to assemble the opposite side.

✓ S4



1 1x





M6x16

8 6x

(1) Place Part #E2 on Part #S.
Secure with Bolt #8 (from bottom to top).



Outside View



Inside View

(2) Connect Part #E2 and the Assembled Beam (D1&D2&D) with part #U1. Secure with 2 Bolts #8.

(3) Repeat the above procedures to assemble the opposite side.

✓ S4


1 1x



M6x16


8 12x

(1) Place Part #E2 on Part #S.
Secure with Bolt #8 (from bottom to top).




(2) Connect Part #E2 and the Assembled Beam (D1&D2&D) with part #U1. Secure with 2 Bolts #8.

(3) Repeat the above procedures to assemble the opposite side.




(S1) 1x




(S2) 3x


Inside View




(1) Secure Part # S2 to Part #S and Part #S1.

ATTENTION: The holes of Part #S and Part #S1 need to be aligned, on the same vertical line.





G1 4x



U3 6x



1 1x




M6x10

7 6x




M6x16


8 8x



(1) Insert Part #U3 into Part #G1 and secure with Bolt #8.



(2) Insert 2 Part #U3 into Part #G1 and secure with 2 Bolts #8.




Inside View

(3) Attach Part #G1 and Part #U3 to Part #E2 with Bolt #7.


(3) Attach Part #G1 and Part #U3 to Part #E2 with Bolt #7.

(4) Attach Part #G1 and Part #U3 to Part #E2 with Bolt #7 and Bolt #8.



Outside View

(5) Repeat the above procedures to assemble the opposite side.



G 4x





1 1x




M6x16

8 4x




Outside View

(2) Repeat the above procedures to assemble the opposite side.



F 4x



U3 2x



1 1x




M6x10

7 2x





M6x16

8 4x




(1) Insert Part #U3 into Part #F and secure with Bolt #8.



Inside View

(2) Attach another Part #F to Part #U3 with Bolts #7 and #8.



Outside View

(3) Repeat the above procedures to assemble the opposite side.



U2 4x






1 1x



M6x16

8 12x



Inside View


2x




(1) Insert Part #U2 into Part #F and Part #G.

(2) Secure with 2 Bolts #8.


(3) Secure them to Part #E with Bolt #8.




(4) Repeat the above procedures to assemble the other 3 sides.




J1 2x




J2 2x



Q1 2x



Q2 2x



1 1x




5 8x





7 8x

28

(1) Connect Part #J1 and Part #Q1 with 2 Bolts #7 and 2 Nuts #5.





(2) Connect Part #J2 and Part #Q2 with 2 Bolts #7 and 2 Nuts #5.






ST6.3x15


2 6x




Inside View




Place the Assembled J1 & Q1 and J2 & Q2 on Part #E2, securing with 3 Self-tapping Screws #2.




Repeat the above procedures to assemble the opposite side.



J 2x



Q 2x



1 1x



2 2x




5 4x




7 4x


(1) Connect Part #J and Part #Q with 2 Bolts #7 and 2 Nuts #5.



(2) Place the Assembled Part #J & #Q on Part #E2, securing with 1 Self-tapping Screw #2.



Inside View



(3) Repeat the above procedures to assemble the opposite side.




X3 4x




ST6.3x15

2 4x

(1) Place Part #J and Part #J1 on Part #E; put on Part #X3 and secure with Self-tapping Screw #2.




Inside View




Repeat the above procedures to assemble the other 3 corners.



L1 2x



L2 2x



L3 2x



L4 2x



Z 8x





Z1 4x



Z2 4x





32

X2



Section View





X2



Attach Part #Z, #Z1 & #Z2 by lightly tapping with screwdriver.

Cover Part #Z to Roof Panels.

X2



X2

(N1) 2x

(N2) 2x


(N3) 4x

(N4) 2x

(N5) 2x


(Z) 12x

ATTENTION: The bigger roof panel need to cover the smaller one.




(1) Insert Part #N1, Part #N2 and Part #N3 into the frame.


(2) Insert Part #N5, Part #N4 and Part #N3 into the frame.



(3) Repeat the above procedures to assemble the opposite side.



H1 2x



H2 2x




X2 2x






ST6.3x15

2 6x

(1) Attach Part #H1 to Part #E2, securing with Self-tapping Screw #2.





(2) Attach Part #H2 to Part #E2, securing with Self-tapping Screw #2.



(3) Place Part #H1 and Part #H2 on Part #E2; put on Part #X2 and secure with Bolt #2.

(4) Repeat the above procedures to assemble the opposite side.

ATTENTION: The bigger roof panel need to cover the smaller one.



(H) 2x





ST6.3x15

(2) 2x

(1) Insert Part #L1 and Part #L2 into the frame.



(2) Insert Part #L4 and Part #L3 into the frame.



(3) Attach Part #H to Part #E2, securing with Bolt #2.

(4) Repeat the above procedures to assemble the opposite side.




X3 4x




ST6.3x15

2 4x

Place Part #H and Part #H2 on Part #E1;
put on Part #X3 and secure with Self-tapping Screw #2















Outside View



Repeat the above procedures to assemble the other 3 corners.

Cover Part #Z to Roof Panels

-  (M1) 2x
-  (M2) 2x
-  (M3) 2x
-  (M4) 2x
-  (M5) 2x
-  (M6) 2x
-  (M7) 2x
-  (M8) 2x
-  (Z) 28x




38


Cover Part #Z to Roof Panels




P1 2x




P2 2x



P3 2x





P4 2x




P5 2x



Z 14x




P4




P5

<35>


P6 2x




P7 2x



P8 2x





P9 2x



P10 2x




Z 14x



P6

P7




P8





P9

P10


40




▲ Part #W should be inserted between roof panels and solidifying bar or beams, then secure with bolts and nuts.



ATTENTION: The bigger roof panel need to cover the smaller one.



(W) 16x



(1) 1x




M6

(5) 16x





M6x28


(10) 16x



(1) Insert Part #P1 and Part #P2 into the frame in sequence.




(2) Insert Part #P10 and Part #P9 into the frame in sequence.




(3) Place 8 Part #W between roof panels and beams. Then secure with 8 Bolts #10 and 8 Nuts #5.

(4) Repeat the above procedures to assemble the opposite side.

ATTENTION: The bigger roof panel need to cover the smaller one.



(W) 20x



(1) 1x



(5) 20x





(10) 12x




(12) 8x

Solidifying Bar


(1) Insert Part #P3 into the frame.




(3) Place 4 Part #W between roof panels and solidifying bars. Then secure with 4 Bolts #12 and 4 Nuts #5.



(2) Insert Part #P8 into the frame.




(4) Place 6 Part #W between roof panels and beams. Then secure with 6 Bolts #10 and 6 Nuts #5.



Beam

(5) Repeat the above procedures to assemble the opposite side.

ATTENTION: The bigger roof panel need to cover the smaller one.



W 20x

Solidifying Bar





1 1x

(1) Insert Part #P4 into the frame.



5 20x

(3) Place 4 Part #W between roof panels and solidifying bars. Then secure with 4 Bolts #12 and 4 Nuts #5.




M6x28

10 12x


P7

P4



M6x50

12 8x




(2) Insert Part #P7 into the frame.




(4) Place 6 Part #W between roof panels and beams. Then secure with 6 Bolts #10 and 6 Nuts #5.

Beam



(5) Repeat the above procedures to assemble the opposite side.



W 24x




1 1x



M6

5 20x




M6x25

9 4x



M6x28

10 12x




M6x50


12 8x

ATTENTION: The bigger roof panel need to cover the smaller one.

(1) Insert Part #P5 into the frame.




(3) Place 4 Part #W between roof panels and solidifying bars. Then secure with 4 Bolts #12 and 4 Nuts #5; Place 1 Part #W between roof panels and Part #E2. Then secure with 1 Bolt #9.



(2) Insert Part #P6 into the frame.




(4) Place 6 Part #W between roof panels and beams. Then secure with 6 Bolts #10 and 6 Nuts #5; Place 1 Part #W between roof panels and Part #E2. Then secure with 1 Bolt #9.




(5) Repeat the above procedures to assemble the opposite side.

ATTENTION: The bigger roof panel need to cover the smaller one.



(W) 12x




(1) 1x




(5) 12x




(10) 12x



(1) Insert Part #M1 and Part #M2 into the frame in sequence.




(2) Insert Part #M8 and Part #M7 into the frame in sequence.




(3) Place 6 Part #W between roof panels and beams. Then secure with 6 Bolts #10 and 6 Nuts #5.


(4) Repeat the above procedures to assemble the opposite side.




(W) 20x




(1) 1x



(5) 20x




(10) 12x




(12) 8x

ATTENTION: The bigger roof panel need to cover the smaller one.


(1) Insert Part #M3 into the frame.




(3) Place 4 Part #W between roof panels and solidifying bars. Then secure with 4 Bolts #12 and 4 Nuts #5.




(2) Insert Part #M6 into the frame.



(4) Place 6 Part #W between roof panels and beams. Then secure with 6 Bolts #10 and 6 Nuts #5.



(5) Repeat the above procedures to assemble the opposite side.





W 24x



1 1x

(1) Insert Part #M4 into the frame.




(3) Place 4 Part #W between roof panels and solidifying bars. Then secure with 4 Bolts #12 and 4 Nuts #5; Place 1 Part #W between roof panels and Part #E2. Then secure with 1 Bolt #9.



M6

5 20x



M6x25

9 4x




M6x28

10 12x





M6x50

12 8x




(2) Insert Part #M5 into the frame.




(4) Place 6 Part #W between roof panels and beams. Then secure with 6 Bolts #10 and 6 Nuts #5; Place 1 Part #W between roof panels and Part #E2. Then secure with 1 Bolt #9.

(5) Repeat the above procedures to assemble the opposite side.



W 4x




1 1x




M6

5 4x




M6x45

11 4x



Place Part #W between roof panels and Part #E2. Then secure with Bolt #11 and Nut #5.



Repeat the above procedures to assemble the other 3 sides.

K2 2x


K3 2x

K4 2x



X2 4x

ST6.3x15


2 6x



(1) Attach Part #K4 to Part #E2, securing with Bolt #2.




(2) Place Part #K4 on Part #K2 and Part #E2; Put on Part #X2 and secure with Bolt #2.




(3) Place Part #K3 on Part #K4 and Part #E2; Put on Part #X2 and secure with Bolt #2.

(4) Repeat the above procedures to assemble the opposite side.



(K) 2x



(K1) 2x





(X2) 2x



ST6.3x15

(2) 2x

Attach Part #K and Part #K1 to the frame; Put on Part #X2 and secure with Self-tapping screw #2.



Repeat the above procedures to assemble the opposite side.




X3 4x



ST6.3x15

2 4x




Place Part #K and Part #K3 on Part #E;
Put on Part #X3 and secure with Self-tapping Screw #2.

Repeat the above procedures to assemble the other 3 corners.




ST5x16

3 8x




Attach roof panels to finishing bars with 2 Self-tapping Screws #3.

Repeat the above procedures to assemble the other 3 sides.




Y1 4x

Hang up Mosquito Sidewalls to Inside Track







Y1




Y1

Y1







Y1





Y 4x

Hang up Solid Sidewalls to Outside Track



Thanks for your purchase.

At domi outdoor living, we believe in our products.

That's why we provide a 12-month warranty and friendly, easy-to-reach after-sales service. So, if you have any questions about our product or assembly, please feel free to contact us. We are here for you.

Support:  

After-sales contact email:
service@domioutdoorliving.com

Please have your order ID available if you reach out for support.

If you have damaged parts or product, please send us photos for an immediate response.