










ASSEMBLY INSTRUCTION


TWIN SLEIGH BED

PAGE 1 OF 2

HARDWARE LIST


N.O	Qty	Description	Picture
A	12	Allen bolt Ø6 x L70mm	
B	12	Barrel Nut	
C	20	Wood Dowel Ø10 x 40	
D	8	Screw Ø4 x 20	
E	8	Bolt Ø6 x L70mm	
F	8	Half moon Ø6	
G	8	Hex nut Ø6	
H	1	Open end Wrench	
I	1	Allen key M4	

PART LIST



STEP 1


Assembly Top rail (3) with Center panel (4) before



STEP 1: HeadBoard / Assembly
Center panel & Bottom rail
assembly with (Left & Right) Leg (1 & 2)
by 6 Allen Bolts (A) & 6 Barrel nut (B)
& 10 dowell (C).

STEP 2

Assembly Top rail (3) with Center panel (8) before



STEP 2: FootBoard / Assembly
Center panel & Bottom rail
assembly with (Left & Right) Leg (6 & 7)
by 6 Allen Bolts (A) & 6 Barrel nut (B) & 6 dowell (C) .


MADE IN VIET NAM

ASSEMBLY INSTRUCTION

TWIN SLEIGH BED


PAGE 2 OF 2

STEP 4




STEP 3

Slat (10) assembly with Side Rail by 8 Screw (D).
The assembly is now complete.



STEP 3



STEP 3

HB/FB assembly with Side Rail (9)
by 8 Bolts (E) & 8 Half moon (F)
& 8 Hex nut (G) 4 wood dowel (C).












MADE IN VIET NAM

ASSEMBLY INSTRUCTION


FULL SLEIGH BED

PAGE 1 OF 2

HARDWARE LIST


N.O	Qty	Description	Picture
A	12	Allen bolt Ø6 x L70mm	
B	12	Barrel Nut	
C	20	Wood Dowel Ø10 x 40	
D	16	Screw Ø4 x 20mm	
E	8	Bolt Ø6 x L70mm	
F	8	Half moon Ø6	
G	8	Hex nut Ø6	
H	1	Open end Wrench	
I	1	Allen key M4	
J	2 set	Bolt Ø6 x L45mm	
K	2	Metal " U "	
L			
N			
M			

PART LIST



STEP 1


Assembly Top rail (3) with Center panel (4) before



STEP 1: HeadBoard / Assembly Center panel & Bottom rail assembly with (Left & Right) Leg (1 & 2) by 6 Allen Bolts (A) & 6 Barrel nut (B) & 10 dowell (C) & 1 (K) & 4 screw (D).

STEP 2

Assembly Top rail (3) with Center panel (8) before



STEP 2: FootBoard / Assembly Center panel & Bottom rail assembly with (Left & Right) Leg (6 & 7) by 6 Allen Bolts (A) & 6 Barrel nut (B) & 6 dowell (C) & 1 (K) & 4 screw (D).


MADE IN VIET NAM

ASSEMBLY INSTRUCTION

FULL SLEIGH BED

PAGE 2 OF 2


STEP 5



STEP 5

Slat (11) assembly with Side Rail
by 8 Screw (D).
The assembly is now complete.


STEP 4



STEP 4


HB/FB assembly with Center Rail (10)
by 2 Bolts (J) .

STEP 3



STEP 3

HB/FB assembly with Side Rail (9)
by 8 Bolts (F) & 8 Half moon (F)
& 8 Hex nut (G) 4 wood dowel (C).



MADE IN VIET NAM