


y

Before You Start



- ✓ Read through each step carefully and follow the proper order
- ✓ Separate and count all your parts and hardware
- ✓ Give yourself enough room for the assembly process
- ✓ Have the following tools: Flat Head Screwdriver, #2 Phillips Head Screwdriver and Hammer
- ✓ Caution: If using a power drill or power screwdriver for screwing, please be aware of to slow down and stop when screw is tight. (Assembly speed can be increased by using electric screwdriver)

Helpful Hints


PEOPLE NEEDED FOR ASSEMBLY: 1-2

- Open your item in the area you plan to keep it to avoid excessive heavy lifting.
- Identify, sort and count the parts before attempting assembly.
- Compression dowels are lightly tapped in with a hammer.
- Slides are labeled with an **R** (right) and **L** (left) for proper placement.
- Make sure to always face the point on the top of the Cam Lock towards the outer edge.
- If there is a back panel in the package, please install it to make sure your unit is complete and sturdy.
- Please fix all the screws provided for the back panel which can enhance product stability. If it is difficult to fix it when tightening, it can be fixed with the help of a hammer and then tightened.
- Do NOT use harsh chemicals or abrasive cleaners on this item.
- Never push, pull, or drag your furniture.



Board Identification


Not actual size



①

UPPER CROSS BAR


Qty:1



②

TOP PANEL


Qty: 1



③

LEFT SIDE PANEL


Qty:1



④

RIGHT SIDE PANEL


Qty:1



⑤

LOWER CROSS BAR


Qty:2



⑥

BOTTOM PANEL


Qty:1



⑦

DOOR


Qty: 2



⑧

DOOR

Qty:1




⑨

SHOE BOX BOTTOM


Qty: 3

Board Identification


Not actual size




⑩
SHOE BOX LAYER
Qty: 6



⑪
IRON STRIP
Qty: 2




⑫
IRON STRIP
Qty: 1



⑬
IRON FRAME
Qty: 2

Part List




Ø6.5X35mm

(A)

X6

CAM BOLT




Ø15X9mm

(B)

X6

CAM LOCK



Ø6X30mm

(C)

X12

WOOD DOWEL
spare: 2




M4X14mm

(D)

X42

SCREW
spare: 3




M4X18mm

(E)

X6


BOLT



(F)

X3

HANDLE



(G)

X6

SCREW



(H)

X6


PLASTIC PLUG



(I)

X3


SHOE BOX LEFT SUPPORT



(J)

X3


SHOE BOX RIGHT SUPPORT



(K)

X6

PLASTIC PIN




M6X30mm

(L)

X2

EXPANSION NEIL




M4X35mm

(M)

X14

SCREW

spare: 2



M4X40mm

(N)

X2

SCREW




M6X30mm

(O)

X6

BOLT


Part List



(P)

X1

ALLEN WRENCH




M4X25mm

(Q)

X6

SCREW



(R)


X8

HOLE COVER


Cam Lock Fastening System

Insert the cam bolt into the hole first, then insert the cam lock and lock it.


1



2




3




The opening must point toward the edge of the board

4








Board Identification





Not actual size







STEP1









STEP2












STEP4




Proper orientation of CAM LOCK

STEP 5




Proper orientation of CAM LOCK

STEP 6




M6X30mm



O	X6
---	----







P	X1
---	----




Please tighten the screws to 80% first, and tighten all screws 100% after all parts are assembled.


	
---	---


STEP 7





STEP 8






 M4X14mm	
(D)	X18

	
(I)	X3


	
(J)	X3





STEP 9






STEP 10



	
M4X14mm	
(D)	X6



STEP 11




Cabinet must permanently fixed to the wall with included anti-tipping device to prevent the cabinet from tipping over.

.Mark the drill position on the wall with a pencil.







.Drill holes on the marked position using a bit.

Gently inert the wall anchor (L) into the drilled hole with the help of a hammer


.Fixed the cabinet to the wall with provided screws (N)



STEP12



STEP 13



M4X14mm

D	X6
---	----

