



Installation instruction





The two panels on the left and right of the package are used to protect the product, you can just throw it away.




Assembling

What you need


- Use the packaging carton as a working surface to prevent product damage during assembly

Tool Required Not Provided



Use electric tools with care.

















Weight Limitation



What' included

Code	Description	Qty
A	Cam Bolt M6X35MM	40
B	Cam Lock 15X12MM	40
C	Wooden Dowel M8X30MM	39
D	Screw M3.5X14MM	26
E	Screw M4X35MM	4
F	Screw M6X12MM	12
G	Screw M6X20MM	2
H	Plastic foot nail	8
I	Screw wrench	1
J	EVA spacer	4
K	Plank sticker	16
L	Left-curved hand	1
M	Right-curved hand	1
N	Flip left	1
O	Flip right	1
P	Door panel hinge	3

The Hardwares

<p>A x 40</p>  <p>Ø6×35 mm</p>	<p>B x 40</p>  <p>Ø15×12 mm</p>	<p>C x 39</p>  <p>Ø8×30 mm</p>	<p>D x 26</p>  <p>Ø3.5×14 mm</p>	<p>E x 4</p>  <p>Ø4×35 mm</p>
<p>F x 12</p>  <p>M6×12 mm</p>	<p>G x 2</p>  <p>M6×20 mm</p>	<p>H x 8</p> 	<p>I x 1</p>  <p>4 mm</p>	<p>J x 4</p> 
<p>K x 16</p> 	<p>L x 1</p> 	<p>M x 1</p> 	<p>N x 1</p> 	<p>O x 1</p> 
<p>P x 3</p> 				


IMPORTANT:

1. Do not tighten bolts / screws completely until all bolts / screws are lined up and inserted into holes.
2. Do not over tighten screws and bolts to avoid stripping
3. You can use a screwdriver or an electric tool (be careful when using an electric tool).



Included Accessories


Code	Description	Qty
1	Front panel	1
2	Back panel	1
3	Front floor	1
4	Rear floor	1
5	Middle vertical plate	1
6	Left side plate	1
7	Right side plate	1
8	Baffle	2
9	Trim panel	4
10	Iron crossbar	1

The Accessoriess






Step 1

C x 16  Ø8x30 mm	A x 20  Ø6x35 mm
---	---






Step 2

C x 4  Ø8x30 mm	A x 4  Ø6x35 mm
--	--





Step 3


C x 16  Ø8x30 mm	A x 16  Ø6x35 mm
---	---




x4

Step 4



K x 8 	B x 8  Ø15x12 mm
--	---




For beauty and safety.
Please attach four K-hole stickers
at the end of this step.






Step 5

E x 4  Ø4x35 mm	C x 3  Ø8x30 mm
--	--






Step 6




Two people should stabilize parts No. 3 and No. 4 before installation to avoid imbalance and potential breakage.

Step 7





Two people should stabilize parts No. 3 and No. 4 before installation to avoid imbalance and potential breakage.




Step 8





Step 9




Step 10





K x 8 	J x 4 	B x 8  Ø15x12 mm
---	--	---




For beauty and safety.
Please attach four K-hole stickers
at the end of this step.






Step 11

O x 1 	N x 1 	I x 1  4 mm	F x 8  M6x12 mm
--	---	--	--






Step 12

I x 1	G x 2
	
4 mm	M6x20 mm




Step 13




I x 1	F x 4
	
4 mm	M6x12 mm




When opening or closing Panel No. 2, please operate both sides simultaneously.







Step 14

M x 1 	L x 1 	D x 4  Ø3.5×14 mm
---	--	--









Step 15


P x 3 	D x 6  Ø3.5×14 mm
--	--



Step 16





How do I get the two doors to align flat by adjusting the hinges?




To adjust the vertical height.

Loosen the four screws "A" on both hinges. Two of them are usually in slotted holes which allows you to adjust up or down by a few mm. Then tighten back up.



To adjust depth.


Loosen screw "B" and adjust door, if the door cannot be adjusted, please loosen screw "C", then try again. Tighten screw "B" and "C"




To adjust side ways.

Turning the screw "C" on BOTH hinges on each door.

Step 17



To adjust the gap between Panel 1 and Panel 2, you can move the F screws up or down.



Step 18

When opening or closing Panel No. 2, please operate both sides simultaneously.

