

# Full/Queen Slipcovered Headboard Instruction Sheet

## Checklist of Items Included for Assembly:

- 1.) Frame: Panels (2)
- 2.) Frame: Stabilizer Bar (2)
- 3.) Dowel Pin (1)
- 4.) Flat Head 1.1/2" Screws (8)
- 5.) Phillips Head 2.1/2" Bed Frame Screws (4)
- 6.) Bed Frame Washers (4)
- 7.) Nuts (4)
- 8.) Padding Cover
- 9.) Foot Glides (2)
- 10.) Foot Board Stickers (4)




Illustration A

### Step 1

It is best if you assemble your Headboard with two people. Lay the 2 Headboard Panels side by side on the floor. Take the Dowel Pin and place it in the hole of one of the Panels as shown in Illustration A. Slide the Frame Panels together so that the Dowel Pin slides securely into the hole of the other Panel.





Illustration B

### Step 2

Take one of the two Stabilizer Bars and align it to the holes of the 2 Panels on the bottom of the Headboard. Secure in place with 4 of the Flat Head Screws provided. See Illustration B. Repeat Step 2 for the remaining Stabilizer Bar on the top of the Headboard as in Illustration C.



If your Headboard is sitting on an uneven surface, use the Foot Glides provided to adjust the height of your Headboard so that it is even.

### Step 3

Prop your Headboard upright and align your Bed Frame (NOT Included) up to the holes. A Queen Size frame will fit to the outside holes; a Full Frame will fit to the inside holes. Use the Bed Frame Screws, Washers and Nuts to secure the Frame to the Headboard.




Illustration C

### Step 4

Once your Headboard and Frame are secure, slip the padding cover over the top of the Headboard. Finally, slide your Slipcover (sold Separately) over the padding. Use the black Foot Board Stickers to cover the unused holes on the Feet of the Headboard.

