

installation instructions:

PVC CROWN MOULDING

SAFETY INSTRUCTIONS

- Make sure to use the recommended tools.
- Wear proper protective gear.
- Follow fixture, power tools, manufacturers' instructions, and user manuals.
- Use common sense and follow good construction practices.

TOOL & MATERIAL CHECKLIST

- | | |
|---|--|
| <input type="checkbox"/> miter saw | <input type="checkbox"/> 100% acrylic paint |
| <input type="checkbox"/> miter box | <input type="checkbox"/> Acrylic caulk & gun |
| <input type="checkbox"/> hammer or nail gun | <input type="checkbox"/> tape measure |
| <input type="checkbox"/> nails | <input type="checkbox"/> utility knife |
| <input type="checkbox"/> PVC cement | <input type="checkbox"/> ladder |
| <input type="checkbox"/> carbide-tipped blade | <input type="checkbox"/> safety glasses |
| <input type="checkbox"/> angle finder | <input type="checkbox"/> chalk line box & pencil |
| <input type="checkbox"/> paint brush | <input type="checkbox"/> sandpaper |

SPECIAL INSTRUCTIONS & NOTES


- You can use standard woodworking tools to cut PVC products.
- Hot-dipped galvanized or stainless steel nails/screws are best for PVC trim.
- PVC expands and contracts with temperature. If you are installing above 80 degrees F, cut pieces to fit tightly. 60-80 degrees, leave a 1/16-in gap for 18 ft of length. Below 60 degrees, leave a 1/8-in gap. After installation cover gap with acrylic caulk.
- Fill fastener holes in PVC with acrylic caulk.
- Glue joints and miters together with PVC cement.
- Use 100% acrylic paint before installing, finish with final coat to cover chalked holes.
- When ending moulding at a corner, cut a return piece and glue. Hold until set.

STEP BY STEP INSTRUCTIONS

- Mitering Corners
- Place moulding in the miter box with the wall side against the side of the miter box opposite you and the ceiling touching side against the bottom of the box.
 - Cut miters and butt joints prior to installation.

- Crown Moulding Installation
- Apply a continuous 1/2" bead of adhesive along the top and back of moulding lengths and universal corners. Press moulding into place.
 - Secure the moulding in place with finishing nails
 - Apply putty/filler in remaining gaps and smooth with finger or putty knife.
 - Touch-up moulding as needed and light sand areas with excess putty.

EXAMPLE INSTALLATION DIAGRAMS



***Helpful Tip:** If using multiple pieces of moulding on the same wall, install and join moulding using a scarf joint to hide the seam as much as possible and make installation easier.

