


Assembly Instructions

Bookcase














Thank you for purchasing our product!

Please assemble the products with the guidance of this manual instruction. Contact our friendly customer service department with any comments or in case there is any missing or damaged parts or hardware. Replacements for missing or damaged parts or hardware are normally shipped within 2 to 3 days.




We appreciate your business!

Hardware List



ITEM	DESCRIPTION	PART	QTY	ITEM	DESCRIPTION	PART	QTY
A	Cam Bolt 6X35mm		40 pcs	G	Bracket		2 pcs
B	Cam Lock 15X12mm		40 pcs	H	Cable Tie		1 pc
C	Wooden Dowel 8X30mm		20 pcs	I	Plastic Anchor		1 pc
D	Screw 4X40mm		9 pcs	J	Plastic Cover		36 pcs
E	Screw 4X30mm		4 pcs	K	Screw 2.5X10mm		44 pcs
F	Screw 3X14mm		1 pc				

Note:

1. Please be advised to have at least 2 persons to assemble this unit.




2. Tools not included, but assential for assembling this unit:












"Philips" Screwdriver	
Flat Head Screwdriver	

3. Place a large cloth or blanket on the floor or flat surface to protect parts from scratching.




4. Before assembling this unit, please check that all parts and hardware are present.


Part List



ITEM	DESCRIPTION	PART	QTY	ITEM	DESCRIPTION	PART	QTY
1	Bottom Long Rail		2 pcs	7	Side Panel		2 pcs
2	Bottom Short Rail		2 pcs	8	Front Deco Rail		2 pcs
3	Bottom Panel		1 pc	9	Top Panel		1 pc
4	2nd And 4th Shelf		2 pcs	10	Upper and Under Back Panel		2 pcs
5	1st And 3rd Shelf		1 pc	11	Middle Back Panel		3 pcs
6	Divide Panel		2 pcs				

STEP 1



A		4 pcs
B		4 pcs
C		4 pcs




DO NOT USE POWER TOOLS

1. Tighten cam bolt (A) to bottom long rail (1).
2. Assemble bottom long rail (1) and short rail (2) together by using wooden dowel.
3. Insert cam lock (B) then rotate clockwise to secure cam bolt in place.

STEP 2


C		4 pcs
D		8 pcs




DO NOT USE POWER TOOLS

1. Attach bottom frame to bottom panel (3) by using wooden dowel (C) and screw (D).


STEP 3



STEP 4




STEP 5





1. Attach the unit from step 3 to side panel (7).
2. Insert cam lock (B) then rotate clockwise to secure cam bolt in place.


STEP 6



1. Attach side panel (7) and insert cam lock (B) then rotate clockwise to secure cam bolt in place.


STEP 7

B		8 pcs
C		4 pcs




1. Attach front deco rail (8) by using wooden dowel (C).
2. Insert cam lock (B) then rotate clockwise to secure cam bolt in place .






STEP 8



A		8 pcs
B		8 pcs
C		8 pcs




DO NOT USE POWER TOOLS




1. Tighten cam bolt (A) to top panel (9) and bottom panel (3).
2. Attach top panel (9) and bottom base to the assembly unit.
3. Insert cam lock (B) then rotate clockwise to secure cam bolt in place.

STEP 9




F		1 pc
G		1 pc
K		44 pcs




YOU CAN CHOOSE THE DESIGN OPTION A OR B.

OPTION A: WHITE COLOR WITH CREAM STRIPE




OPTION B: GRAY COLOR






1. Rotate the product and attach back panel (10 & 11) by using screw (K).
2. Attach bracket (G) by using screw (F).

STEP 10



D		1 pc
G		1 pc
H		1 pc
I		1 pc
J		36 pcs



1. Drill a 7/32" hole in the dry wall. Press the plastic wall anchor (I) to the drywall. Ensure that the anchor fits securely in the wall.
2. Attach the bracket (G) to the wall by using screw (D).
3. Rotate the product and fix it on the wall using cable tie (H).
4. Cover all exposed holes by using plastic cover (J).