


Assembly Instructions



ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.


EASY



DIFFICULT


Tools Required For Assembly:

Allen Wrench




(Included)

Wrench



(Included)



2 PERSONS RECOMMENDED

ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.

BASIC ASSEMBLY TECHNIQUES



When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.



Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.



Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.




Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.




Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.












FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.





Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.

Parts List

	#1 x 2pcs Backrest		#2 x 2pcs Seat
	#3 x 2pcs Right Armrest		#4 x 1pc Left Armrest
	#5 x 4pcs Leg		#6 x 2pcs Crossbar A
	#7 x 1pc Table Top		#8 x 4pcs Crossbar B
	#9 x 8pcs Suspender		





Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.

Hardware List



#A x 8pcs
Bolt 5/16" x 3-1/8"



#B x 8pcs
Bolt 1/4" x 2-3/4"



#C x 8pcs
Bolt 1/4" x 2"



#D x 4pcs
Bolt 1/4" x 1-7/8"



#E x 4pcs
Bolt 1/4" x 1-5/8"



#F x 12pcs
Bolt 1/4" x 1/2"



#G x 8pcs
Hex Nut M8




#H x 8pcs
Flat Washer M8



#I x 24pcs
Hex Nut M6



#J x 40pcs
Flat Washer M6



#K x 1pc
Wrench




#L x 1pc
Allen Wrench



#E x 4pcs
#I x 4pcs
#J x 8pcs

1. Align one end of the crossbar A (#6) to the holes along the leg (#5).




2. Insert a bolt (#E) with flat washer (#J) into the leg from beneath, then apply a flat washer (#J) and hex nut (#I) onto the other ends of the bolts. Secure using the Allen wrench (#L).



#C x 4pcs
#I x 4pcs
#J x 4pcs

1. Align one end of the suspenders (#9) to the holes along the legs (#5) that are connected to the crossbars (#6).




2. Insert a bolt (#C) into the hole along the suspender, once inserted apply a flat washer (#J) and a hex nut (#I) onto the end of the bolt (#C). Secure using the Allen wrench (#L).



#C x 4pcs
#I x 4pcs
#J x 4pcs

1. Align one end of the suspenders (#9) to the holes along the legs (#5).




2. Insert a bolt (#C) into the hole along the suspender, once inserted apply a flat washer (#J) and a hex nut (#I) onto the end of the bolt (#C).
Secure using the Allen wrench (#L).



#A x 8pcs
#G x 8pcs
#H x 8pcs

1. Align the left and right armrests (#3,4) to the holes along each end of the seat (#2).




2. Insert the bolts (#A) from beneath, then apply a flat washer (#H) and hex nut (#G) onto the end of the bolt. Secure using the Allen wrench.




#F x 8pcs

Align the backrest (#1) to the holes along the back of the armrests (#3,4), then insert a bolt (#F) into each hole and secure using the Allen wrench (#L).




#F x 4pcs

Align the crossbar B (#8) to the holes along the table top (#7), then insert the bolts (#F) into each hole and secure.





#B x 8pcs
#I x 8pcs
#J x 16pcs




1. Place the legs (#5) underneath the chair, then align the other ends of the suspenders (#9) to the holes along the armrests.

2. Insert a bolt (#B) with flat washer (#J) into the holes along the outer side of the armrests, then apply a flat washer (#J) and hex nut (#I).




#D x 2pcs
#I x 2pcs
#J x 4pcs



Align one end of the crossbar B (#8) to the holes along the leg (#5), then insert a bolt (#D) with flat washer (#J) into the holes, from within apply a flat washer (#J) and hex nut (#I). Secure using the Allen wrench.



#D x 2pcs
#I x 2pcs
#J x 4pcs



Align the other end of the crossbar B (#8) to the holes along the leg (#5), then insert a bolt (#D) with flat washer (#J) into the holes, from within apply a flat washer (#J) and hex nut (#I). Secure using the Allen wrench.



Make sure all parts are firmly secured.



ASSEMBLY IS COMPLETED