

IMPORTANT SAFETY INSTRUCTIONS


- To avoid injury or damage, mount only on a surface that is sturdy.
- To avoid electric shock, make sure the electricity is turned off at the main circuit breaker panel. If you are replacing an existing fixture, turn off the following in order: fixture, wall switch, and main fuse or breaker box.
Note: Some types of fuses must be unscrewed to shut the power off.
- If you are unclear as to how to proceed, please consult a licensed electrician.

UNPACK THE FIXTURE: Check the contents of the box. Box should contain all items on the parts diagram.

INSTALLATION INSTRUCTIONS

1. Measure Canopy (D) height with measuring tape. Adjust Canopy Screws (E) on Mounting Plate (A) to the height of measured Canopy (D) plus 1/4" to allow them to protrude through Canopy (D) during installation. Lock Canopy Screws (E) in place with the hex nuts.
2. Secure Mounting Plate (A) to the junction box (not included) using Mounting Screws (B) provided. Ensure Mounting Plate (A) is positioned with the threads of Canopy Screws (E) pointing down towards the floor.
3. Place Canopy (D) flush against the ceiling with Canopy Screws (E) protruding through the holes in Canopy (D). Verify that 1/4" of the threaded portion of Canopy Screws (E) are visible. Remove Canopy (D) and set it aside.
Note: If 1/4" of Canopy Screws (E) are not visible, remove Canopy (D) and re-adjust Canopy Screws (E) to proper height and lock them in place with the hex nuts.
4. Thread Wire (H) from Socket Assembly (O) through Center Stem (J) and Center Connector (I). Secure Socket Assembly (O) to Center Stem (J). Pull through any necessary Wire (H).
5. To create the chandelier body, secure 3 of 4 Fixture Arms (M) to the holes on Center Connector (I) with Arm Screws (L). Position Ring (N) within the widest point of Fixture Arms (M). Secure last Fixture Arm (M) to Center Connector (I), helping to keep Ring (N) in place.

6. Separate Top Cap (P) and Plate (Q) from Bottom Cap (R), Nipple (S) and Finial (T). With Nipple (S) protruding through Bottom Cap (R), secure the bottom of each Fixture Arm (M) within Bottom Cap (R), ensuring they sit within their designated slot.
7. Slide Plate (Q) over Nipple (S) and secure with Top Cap (P), holding each Fixture Arms (M) in place.
8. Determine desired hanging length using Downrods (G). Secure Downrods (G) together.
9. Thread Wire (H) through Downrods (G). Secure Downrods (G) to the top of Center Stem (J).
10. Use wire cutters to cut Wire (H) 10" beyond the length of Downrods (G) to allow for easier wire connection.
11. Thread Wire (H) through bottom of Canopy (D). Secure Canopy (D) to the top of Downrods (G).
12. Using the wire graph below, connect the appropriate wires from the fixture to the corresponding wires in the electrical junction box (not included) and secure Wire Connectors (C).



- A. Connect the ground wire (bare copper or green) from your fixture to the:
 - 1) ground wire in the junction box, or
 - 2) ground screw in the junction box
- B. Connect the BLACK house wire to fixture hot wire that corresponds to diagram (black, round & smooth, white/grey with tracer, brown/gold without tracer).
- C. Connect the WHITE house wire to fixture neutral wire that corresponds to diagram (white, ribbed/ridged, white/grey without tracer, brown/gold with tracer).

13. Place all Wires (H) and Wire Connectors (C) back into the junction box.
14. Place Canopy (D) against the ceiling, ensuring Canopy Screws (E) are protruding through the holes in Canopy (D). Secure Canopy (D) and the fixture in place with Decorative Caps (F).
Note: If the fixture does not sit flush against the ceiling, remove fixture and readjust Canopy Screws (E) and hex nuts.
15. Install bulbs (not included) into Sockets (K).

Enjoy your new fixture!

HELPFUL TOOLS: Safety Goggles, Screwdriver, Wire Cutter/Stripper, Ladder, Chain Pliers

