



Assembly Instructions




General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. A Phillips head screwdriver is required for the assembly of this product .



- V. The provided glue is to secure wood dowels in place . When first inserting dowels , locate the appropriate hole for the dowel , place a small amount of glue in the hole and insert the dowel . Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together , place a small amount of glue on the end of the dowel before attaching parts together . Wipe away excess glue immediately.




VI HOW THE KNOCK DOWN (KD) ASSEMBLY SYSTEM WORKS


- 1.Screw the Cam Bolt into the pre-drilled hole on the panel. Make sure Cam Bolt goes into the pre-drilled hole on the end of panel for Cam Lock.
- 2.Insert the Cam Lock into the pre-drilled large hole on the panel. Make sure the arrow on the face of Cam Lock points towards Cam Bolt.
- 3.Take a Phillips screwdriver and rotate the Cam Lock clockwise to lock the Cam Bolt.
- 4.Use the sticker to conceal the Cam.




















- VII. Power tools should not be used to assemble this product .




Parts List














Hardware List


A		Ø8x30mm	Dowel	58	pcs
B		Ø6x35mm	Cam bolt	33	pcs
C		Ø15x11mm	Cam lock	33	pcs
D		Ø30mm	Cam cover	33	pcs
E		Ø5x15mm	Screw	8	pcs
F		1/4"x50mm	Bolt	12	pcs
G		M4	Allen Wrench	1	pc
H			Handle	3	pcs
I			Glue tube	2	pcs
J		Ø6x50mm	Bolt	14	pcs
K		1/4"x28mm	Bolt	4	pcs
L			Stopper	4	pcs
M		Ø3x14mm	Flat-head screw	6	pcs
N		Ø3.5x18mm	Screw	28	pcs
O			Spacer	4	pcs
P			Plastic Nut	4	pcs
Q		Ø4x10mm	Screw	4	pcs
R		Ø4x60mm	Screw	2	pcs
S		Ø7x30mm	Nut	2	pcs
T		Ø13x1mm	Washer	2	pcs



Philips head screwdriver required for assembly
(not included)


Hardware List

U			Left Shoe Cubby Bracket	2	pcs
V			Right Shoe Cubby Bracket	2	pcs
W		Ø4x38mm	Screw	8	pcs
X			Pulley	2	pcs
Y			Pulley	2	pcs
Z		Ø3x12mm	Screw	16	pcs
AA			Metal Bracket	4	pcs
BB		Ø5x16mm	Shelf Support	12	pcs
CC			Plastic wedge	12	pcs
DD		Ø3x17mm	Flat-head screw	12	pcs
EE		Ø60mm	Hole cover	2	sets




Philips head screwdriver required for assembly
(not included)


Step 1




Step 2




Step 3




Step 4




Step 5




Step 6




Step 7




Step 8




Step 9




Step 10





Step 11






Step 12



Step 13




Step 14




CAUTION: Heavy! You may need assistance with this step.

Step 15




Step 16




Note: Don't over tighten the bolts (K)


Step 17




Step 18





Step 19



Step 20




Step 21




CAUTION : Heavy! You may need assistance with this step.


Step 22




Step 23




Step 24



Step 25




Step 26



Step 27

Note:


After aligning the pilot holes,
then tighten the screws(N)




Step 28

Note:


After aligning the pilot holes,
then tighten the screws(N)




Step 29




Step 30




Step 31



Step 32








Step 33




Step 34

Note:

1. Press the pin of part **X** in the retracted position.
2. Snap the pulley of part **Y** into the sliding rail of the bottom panel.
3. Press the button of part **X** slightly to release the pin and align with the sliding rail of the top panel.
4. If necessary, adjust the screw on the pulley to make the door slide smoothly. (Turn left to loose the pulley, turn right to tighten the pulley)





Step 35




Step 36

The holes in the Bracket (U and V) line up with those in Side Frame (3) or partition Board (5),
Insert Plastic Spacers (O) through the holes and secure with screw (Q)




CAUTION: Heavy! You may need assistance with this step.

Step 37




Insert Shoe Cubby Dividers into the slot you desired

Step 38




If necessary adjust the floor leveler at the bottom of the Support Leg


Step 39



Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall. Wall anchor and hardware are included with this product. Please make sure hardware is suitable for your walls before installing, as different wall materials may require different types of anchors.



Step 40



Final Assembly