



## SUGGESTED TOOLS




### 1. Remove Old Toilet

- Disconnect supply line and remove old screws.
- Remove old toilet and make sure the water supply valve is shut off before installation.

### 2. Install New Floor Bolts to the Floor Flange




### 3. Install Wax Ring





### 4. Connect Water Supply Line

- Attach flexible water supply line to the inlet of the fill valve. **DO NOT** connect to the water shut off at this stage.




### 5. Position the New Toilet

- Lower the toilet onto the closet bolts, so the bolts project through mounting holes in base of toilet. Using a rocking motion, press the bowl down to position the toilet onto the flange.
- Install plastic cap washers, followed by metal washers and nuts onto the closet bolts. Tighten the bolts alternately until toilet is firmly seated on the floor. **CAUTION: DO NOT OVERTIGHTEN NUTS, SEVERE DAMAGE MAY OCCURE.**
- Install the plastic cap covers.



### 6. Connect Water Supply

- Connect water supply line (new or existing) between shut off valve and tank inlet water fitting. Tighten coupling nuts securely. **NOTE: DO NOT OVERTIGHEN**
- Turn on supply valve and check for leakage at fittings, tighten or correct as needed.



ALTAIR