


# Assembly Instructions



## ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.

EASY  DIFFICULT

## Tools Required for Assembly:

Allen Wrench



# ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.

## BASIC ASSEMBLY TECHNIQUES



1 When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.



2 Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.



3 Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



4 Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.



5 Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.



6 Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.



FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.




Before you begin, please read Page 2 of "Assembly and Care Advice".


And remember, do not tighten until each step is completed or instructed.

MD


### Parts List




#1 x 1 pc  
Headboard




#2 x 1 pc  
Footboard




#3 x 2 pcs  
Support Leg



#4 x 2 pcs  
Side Rail




#5 x 12 pcs  
Slat




#6 x 1 pc  
Center Slat w/Holes


### Hardware List




#A x 8 pcs  
Bolt 1/4"x5/8"




#B x 2 pcs  
Bolt 1/4"x1-1/4"




#C x 2 pcs  
Bolt 1/4"x1-3/4"



#D x 12 pcs  
Flat Washer




#E x 1 pc  
Allen Wrench



Due to the size of this product, it is highly recommended that the assembly should be done near the area of its intended location. Make sure you have enough space to move around during the assembly.


# Step 1

- I. Align the side rail (#4) onto the pre-drilled holes of the headboard (#1). Prepare two bolt assemblies by inserting the flat washer (#D) onto the bolt (#A) and secure those bolts using an Allen wrench (#E) to lock the side rail (#4) with the headboard (#1). Repeat the process for the other side rail (#4) to the other side of the headboard (#1).
- II. Align the other end of the side rail (#4) onto the pre-drilled holes of the footboard (#2). Prepare two bolt assemblies by inserting the flat washer (#D) onto the bolt (#A) and secure those bolts using an Allen wrench (#E) to lock the side rail (#4) with the footboard (#2). Repeat the process for the other side rail (#4) to the other side of the footboard (#2).




# Step 2

Align the ends of the slat (#5) with the brackets on each side of the side rails (#4). Make sure the studs of the slat (#5) are facing downward to lock into the brackets of the side rails (#4). Repeat the process for the remaining 11 slats (#5) BUT skip the center as shown below.




### Step 3

Align the support leg (#3) with the pre-drilled hole of the center slat with holes (#6). Insert the flat washer (#D) onto the bolt (#C) and secure that bolt using an Allen wrench (#E) to lock the center slat with holes (#6) with the support leg (#3). Repeat the process for the other support leg (#3).



### Step 4

Align the assembled center slat and support legs with the center brackets of the side rails (#4). Insert the flat washer (#D) onto the bolt (#B) and secure that bolt using an Allen wrench (#E) to lock the center slat with holes (#6) with the side rail (#4). Repeat the process for the other side of the center slat.



ASSEMBLY IS COMPLETED