


Assembly Instructions



Instructions Include Scrollwork Canopy (Sold and Packed Separately)


ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.

EASY  DIFFICULT

Tools Required for Assembly:

Wrench




Phillips Screwdriver




ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


BASIC ASSEMBLY TECHNIQUES




1 When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




2 Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.




3 Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



4 Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.



5 Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.




6 Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.



FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.

MD

Parts List

Hardware List



#1 x 1 pc
Headboard



#A x 8 pcs
Threaded Stud




#2 x 1 pc
Footboard



#B x 8 pcs
Hex Nut



#3 x 4 pcs
Finial



#C x 1 pc
Wrench



#4 x 2 pcs
Side Rail




#D x 8 pcs
Screw



#5 x 4 pcs
Slat



#6 x 8 pcs
Slat Support Leg






Due to the size and/or weight of this product, it is highly recommended that the assembly should be done near the area of its intended location. Make sure you have enough space to move around during the assembly. ALWAYS have at least two people to help with transporting and assembling of the product to avoid any potential injury and/or damage.




- I. Insert 4 threaded studs (#A) into the headboard (#1) and 4 threaded studs (#A) into the footboard (#2).
- II. Insert one side rail (#4) onto the threaded studs (#A) of the headboard (#1) and secure the 2 hex nuts onto the threaded studs (#A) using the wrench (#C) to tighten. Repeat the process to secure the other side rail (#4) onto the other side of the headboard (#1).
- III. Insert the other end of the side rail (#4) onto the threaded studs (#A) of the footboard (#2) and secure the 2 hex nuts onto the threaded studs (#A) using the wrench (#C) to tighten. Repeat the process to secure the other side rail (#4) onto the other side of the footboard (#1).

#A x 8 pcs
#B x 8 pcs






Align the threaded end of the slat support leg (#6) with the pre-drilled holes of the slat (#5) and tighten by hand until secured. Repeat the process for attaching the remaining 6 slat support legs (#6) into the 3 slats (#5).




Align the ends of the 4 assembled slat (#5) with the pre-drilled holes on each side of the side rails (#4). Secure two screws (#D) for each slat (#5) by using a Phillips screwdriver to tighten them down to the side rails (#4).







Align the threaded end of the finials (#3) with the pre-drilled holes on top of the headboard (#1) AND on top of the footboard (#2) and tighten by hand until secured.



Adjust the leveler according to the ground level. To lower or to raise the slat support leg, you need to turn the leveler clockwise or counterclockwise, respectively.









ASSEMBLY IS COMPLETED






These instructions are for the assembly of scrollwork canopy (sold and packed separately) onto the fully assembled bed.


MD

Parts List

-  #7 x 2 pcs
Headboard Post
-  #8 x 2 pcs
Footboard Post
-  #9 x 4 pcs
Scrollwork Frame
-  #10 x 1 pc
Mounting Plate
-  #11 x 1 pc
Top Center Finial
-  #12 x 1 pc
Bottom Center Finial


Hardware List

-  #E x 4 pcs
Bolt 1/4"x1/2"
-  #F x 4 pcs
Flat Washer
-  #G x 1 pc
Allen Wrench





If the finials (#3) are already assembled on the headboard (#1) and footboard (#2), then remove them by unscrewing the finials (#3). Align the threaded end of the two headboard posts (#7) and the two footboard posts (#8) with the pre-drilled holes on the headboard (#1) and footboard (#2) and tighten by hands until secured.




Turn right (clockwise) to tighten



- I. Align the scrollwork frame (#9) with the pre-drilled hole on top of the headboard post (#7) and hold it in place by screwing the finial (#3) through the scrollwork frame (#9) and the headboard post (#7). Do not tighten yet. Repeat the process for the remaining 3 scrollwork frames (#9) onto the other headboard post (#7) and the two footboard posts (#8).
- II. Align all 4 of the scrollwork frames (#9) with the mounting plate (#10) AND the bottom center finial (#12).
- III. Prepare 4 bolt assemblies by inserting the flat washer (#F) onto the bolt (#E).
- IV. Insert the bolt assemblies through the bracket holes of the scrollwork frames (#9), the mounting plate (#10) AND the bottom center finial (#12) and secure those bolts using the Allen wrench (#G) to lock all the parts together.
- V. Align the threaded end of the top center finial (#11) with the center hole of the mounting plate (#10) and tighten by hand until secured with the bottom center finial (#12).
- VI. Completely tighten the finials (#3).

#E x 4 pcs
#F x 4 pcs



Turn right (clockwise) to tighten

Turn right (clockwise) to tighten

ASSEMBLY IS COMPLETED