


Item # :GMSG008-BLHO

Assembly Instructions




If you find any damage after opening, please be sure to take pictures of the damage and contact us. We will help you solve the problem as soon as possible.


Thank You!

General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are: wood dowels, screws and bolts.
- V. The provided glue is to secure wood dowels in place. When first inserting dowels, locate the appropriate hole for the dowel, place a small amount of glue in the hole and insert the dowel. Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together, place a small amount of glue on the end of the dowel before attaching parts together. Wipe away excess glue immediately.




- VI. A Phillips head screwdriver is required for the assembly of this product.




- VII. Power tools should not be used to assemble this product.




- VIII. Drill may be needed for securing product to wall.
- IX. Concealed hinges are three-way adjustable.



Horizontal
by screw adjustment




In-and-Out
by loosening the hinge-arm
mounting screw or via cam
adjustment

















Vertical
Via slots in the mounting
plate or via cam adjustment

Parts List



Hardware List









A		Ø8x30	Wooden dowel	44 pcs
B		Ø6x35	Cam bolt	40 pcs
C		Ø15x9.5	Cam lock	44 pcs
D		Ø3*12	Screw	52 pcs
E			Hinge	4 pcs
F		Ø4x12	Screw	24 pcs
H		Ø6x25	Bolt	4 pcs
I		Ø6x15	Bolt	8 pcs
J			Spring Washer	12 pcs
K			Flat Washer	12 pcs
L		M4 mm	Hex key	1 pcs
M			Door knob	2 pcs
N		Ø4x20	Bolt	2 pcs




Philips head screwdriver required for assembly
(not included)

*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*

Hardware List

O			Sticker	44 pcs
P1		42*20*9MM	Plastic Bracket	2 pcs
P2		Ø3.5*16	Screw	2 pcs
P3		Ø3.5*30	Screw	2 pcs
P4			Wall Plug	2 pcs
P5			Cabinet Restraint Strap	1 pcs
Q		90*20*3	Plate	4 pcs
R		Ø6x32	Cam bolt	4 pcs




1. Push the cam bolt into the entry hole.
2. Insert the cam lock. Ensure that the arrow on the top of the cam lock points towards the entry hole for the cam bolt.
3. Turn the cam lock clockwise with a screwdriver. You should feel a click when the cam lock is locked in place. The joint is now secure.

Note: If more torque is applied, it may break the nut.


*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*

Step 1




Screw cam bolts (R) into part (12) with Philips head screwdriver as per diagram.

Step 2




- 1/ Insert dowels (A) into panels (18).
 - 2/ Attach panels (18) to panels (12) using cam bolts (B) and dowels (A) as guided.
- Insert cam lock (C) into panel (18) tighten with a screwdriver;

Step 3




Using bolt (H) attach spring washer (J), flat washer (K) and plate (Q) to part (12) with hex key (L) as per diagram.

Step 4



Insert wooden dowels (A) into part (7).
Screw cam bolts (B) into part (7) with Philips head screwdriver as per diagram.


Step 5



1/ Using bolt (I) attach spring washer (J), flat washer (K) and plate (T) to part (7) with hex key (L) as per diagram.


2/ Using cam lock (C) secure parts (12) to parts (7) with Philips head screwdriver as per diagram.

Step 6



Screw cam bolts (B) into part (7) with Philips head screwdriver as per diagram.


Step 7



Insert wooden dowel (A) into panel (2,3).

Screw cam bolts (B) into panel (2,3) with Philips head screwdriver as per diagram.


Step 8



Insert wooden dowel (A) into panel (4).

Screw cam bolts (B) into panel (4) with Philips head screwdriver as per diagram.


Step 9



Insert wooden dowel (A) into panel (5).

Screw cam bolts (B) into panel (5) with Philips head screwdriver as per diagram.


Step 10



Insert wooden dowel (A) into panel (6).


Screw cam bolts (B) into panel (6) with Philips head screwdriver as per diagram.

Step 11




Insert wooden dowel (A) into panels (8,9)

Step 12




Screw cam bolts (B) into panel (1) with Philips head screwdriver as per diagram.

Step 13




Note: Please don't over-tighten the cam lock, otherwise, it will be broken.




Attach panel (8) to panel (4) using cam bolts (B) and dowels (A) as guided,
Insert cam lock (C) into panel (8) tighter with a screwdriver.

Step 14






1/ Attach panel (8) to panel (4) using cam bolts (B) and dowels (A) as guided ;
Insert cam lock (C) into panel (8) tighten with a screwdriver;
2/ Attach panel (5) to panel (8) using cam bolts (B) and dowels (A) as guided ;
Insert cam lock (C) into panel (8) tighten with a screwdriver;

Step 15




Note: Please don't over-tighten the cam lock, otherwise, it will be broken.




- 1/ Attach panel (8) to panel (5) using cam bolts (B) and dowels (A) as guided ;
Insert cam lock (C) into panel (8) tighten with a screwdriver;
- 2/Attach panel (6) to panel (8) using cam bolts (B) and dowels (A) as guided ;
Insert cam lock (C) into panel (8) tighten with a screwdriver;

Step 16




- 1/ Attach panel (9) to panel (6) using cam bolts (B) and dowels (A) as guided ;Insert cam lock (C) into panel (9) tighten with a screwdriver;
- 2/Join panels (2,3) together with panel (4,5,6) using cam bolts (B) and dowels (A) as guided. Insert cam lock (C) into panel (4,5,6) tighten with a screwdriver;

Step 17




Note: Please don't over-tighten the cam lock, otherwise, it will be broken.




- 1/ Attach panel (7) to panels (2,3,9) using cam bolts (B) and dowels (A) as guided ;
Insert cam lock (C) into panel (2,3,9) tighten with a screwdriver;
- 2/ Attach panel (1) to panels (2,3,8) using cam bolts (B) and dowels (A) as guided ;
Insert cam lock (C) into panel (2,3,8) tighten with a screwdriver;

Step 18




Attach back panels (17,16,15,14,13) one by one to the back of the console using screws(D).
Note that back panel (16) will overlap back panel (17) as shown in insert above.

Step 19




Cover visible cam locks of the panels (2,3,8,9) with stickers (O) as desired

Step 20



Attach hinges (E) to doors (10,11) using screws (F). Attach handles (M) to doors (10,11) using screws (N)

Step 21




Attach doors (10 ,11) to the console using screws(F) at hinges (E) .See page 2 for instructions on how to adjust hinges so doors align with console as desired.

Step 22


WARNING

Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall. Wall anchor and hardware are included with this product. Please make sure hardware is suitable for your walls before installing, as different wall materials may require different types of anchors.



Using screw (P2) attach part (P1) to panel (13) with Philips head screwdrivers as per diagram.

Step 23



Drill two holes on wall at same height as plastic bracket (P1) on Bookcase with Power Drill. Insert wall plugs (P4) into holes on wall with Hammer. Attach plastic bracket (P1) to wall plugs (P4) using screws (P3) with Screwdriver. Move the Bookcase back against wall. Pull the restraint straps (P5) through the plastic bracket (P1) on the wall and Bookcase and pull the restraint straps (P5) tight.

WARNING

DO NOT use outdoor

DO NOT exceed weight limit

DO NOT use this item unless all fixings are secured.

DO NOT push the item as this will damage the base.

The unit must be handled by at least 2 persons when moving in the same or adjacent rooms.

Before moving the unit, make sure to remove any object that is heavy or might fall off. Please note that lifting from the tabletop with too much weight on the product might lead to part damage/separation.

When lifting the unit, use both hands and bend your knees, not your backs.

When transporting the unit to places far away, protect and secure the unit to avoid damage in transit.

DO NOT expose the surfaces to direct sunlight or to extreme environmental conditions. Damages caused by this kind of exposure is not covered by the product's warranty.

DO NOT leave spilled liquid in the cabinet

DO NOT place hot or cold items directly onto the surface of the item as marking will occur.

Clean the surfaces preferable with a clean cloth damped in a solution of mild soap and water, then dry with a clean towel.