











End Table



PART LIST


			
<p>A</p> <p>Top Panel 1 PC</p>	<p>B</p> <p>Column Foot 4 PCS</p>	<p>C</p> <p>Up Middle Shelf 1 PC</p>	<p>D</p> <p>Under Middle Shelf 1 PC</p>

HARDWARE LIST

				
<p>#1</p> <p>Ø1/4"*1-3/4"</p> <p>Bolt 8 PCS(Extra 1)</p>	<p>#2</p> <p>Ø3mm*5/8"</p> <p>Flat Head Screw 8 PCS(Extra 1)</p>	<p>#3</p> <p>Ø1/4"*11mm</p> <p>Spring Washer 8 PCS(Extra 1)</p>	<p>#4</p> <p>Ø1/4"*13mm</p> <p>Flat Washer 8 PCS(Extra 1)</p>	<p>#5</p> <p>4mm</p> <p>Allen Key 1 PC</p>

ADDITIONAL TOOLS(Not Provided)


Note:It is not recommended to use power tools during assembly




Phillips Head Screwdriver





Note:Wood dowels are Intended for alignment, Additional clearance between wood dowel and pre-drilled hole is intentional for ease of assembly.

Step 1. Please fully push out the drawer.








Step 2.




- | | | |
|----|---|-----|
| #1 |  | x 4 |
| #3 |  | x 4 |
| #4 |  | x 4 |
| #5 |  | x 1 |

Step 3.




- #1  x 2
- #3  x 2
- #4  x 2
- #5  x 1

Step 4.




- #2  x 3






Step 5.



#2  x 3

Step 6.



#1  x 2
 #2  x 2
 #3  x 2
 #4  x 2
 #5  x 1

Step 7. Please push the drawer in as shown.

