



Outdoor
Living Today

ASSEMBLY MANUAL

8x12 Deer Fence Option Kit & 8x16 Deer Fence Option Kit

Licensed Under US PATENTS 7,424,787; 7,490,435

IMPORTANT

If you purchased an 8'x12' Deer Fence Option go to Page 2 for Assembly Manual.

If you purchased an 8'x16' Deer Fence Option go to Page 16 for Assembly Manual.

8'x12' Deer Fence Option - Base Kit + 1 Extension



8'x16' Deer Fence Option - Base Kit + 2 Extensions



If you ordered an 8'x12' Deer Fence Option you will receive 1 - 4ft Extension Box.
If you ordered an 8'x16' Garden in a Box, you will receive 2 - 4ft Extension Boxes.

The Base Kit (8'x8') is contained in Boxes 1 & 2.

In the event of a missing or broken piece, simply call the Outdoor Living Today Customer Support Line @ 1-888-658-1658 within 30 days of the delivery of your purchase. It is our commitment to you to courier replacement parts, free of charge, within 10 business days of this notification. Replacement parts will not be provided free of charge after the 30 day grace period.



Outdoor
Living Today

ASSEMBLY MANUAL

8x12 Garden in a Box

Deer Fence Option Kit

Licensed Under US PATENTS 7,424,787; 7,490,435

Stock Code:

RB812DFO

Version #1.6

April 16, 2025

**Thank you for purchasing a 8' x 12'
Raised Garden Bed Deer Fence
Option Kit.**

**Please take the time to identify all
the parts prior to assembly.**

**Please use Safety Eyewear and Gloves
while Assembling. Be sure to read and
follow all operating instructions for any
tools used during assembly.
Remember- NO SAW CUTTING IS
REQUIRED!**

Safety Points and Other Considerations

**Please follow this instruction manual when
assembling your Raised Garden Bed Deer
Fence Option Kit and retain the manual for
future maintenance purposes.**



**Estimated Assembly Time for
the Deer Fence Kit = 1 Hour.**

CONTACT

ADDRESS

9393 287th Street,
Maple Ridge, British Columbia,
Canada V2W 1L1

PHONE & FAX

Toll Free: 1-888-658-1658

Fax:

ONLINE


Email: olmsupport@outdoorlivingtoday.com

Web: www.outdoorlivingtoday.com

Exploded View and Parts List for 8x12 Raised Bed Deer Fence Option Kit

Parts List

- Part 1** 8 pcs - Side/Rear Deer Fence Panels (46"wide x 33 5/8"high)
- Part 2** 3 pcs - Front Deer Fence Panels (30 5/8"wide x 33 5/8"high)
- Part 4** 4 pcs - Corner Brackets (angle cut ends) (1 1/2" x 1 1/2" x 24")
- Part 5** 5 pcs - Vertical Panel Supports - Long (3/4" x 2 1/2" x 45")
- Part 6** 5 pcs - Vertical Panel Supports - Short (3/4" x 2 1/2" x 22")



Hardware Kit (Provided)

2 1/2"  8 pcs

2"  116 pcs



#2 Square Drive Bit x 1 pc



Black Plastic Butt Hinge - 2 pcs

3/4"  18 pcs
Black

Tools Required (Not Provided)



Screw Gun/Drill



1/8" Drill Bit



Level



Tape Measure



Wood Clamp



Hammer

Safety Equipment Required (Not Provided)




Safety Glasses




Work Gloves

We recommend filling your raised bed with soil prior to installing your Deer Fence Option Kit.




1. Prior to installing your Deer Fence Option Kit, confirm your 8x12 Raised Bed is level and square. Measure diagonally inside corner to corner (approximately 164 1/4") in both directions. Adjust as required. Use a level to determine if the tops of the bed frames are sloped and adjust if necessary.



Expert Advise:
Use a Wood Clamp when positioning and attaching deer fence panels together.

Position frames so they are even.

2. Starting in rear corner, position the frame of a **Rear Panel (1)** - 46" wide x 33 5/8" high directly on top of the raised bed frame. Screw frames together with 4 - 2" screws as shown on the left. Install panels with the 1 1/2" thick side on top.




3. Position a Side Panel (1) - 46" wide x 33 5/8" high directly on top of the side raised bed frame. Hold both deer fence frames together and starting at the top, screw together with 5 - 2" screws as shown on the left. Screw bottom of frame down to raised bed frame with 4 - 2" screws.


4. Position a second Rear Panel (1) - 46" wide x 33 5/8" high on top of the rear raised bed frame. Hold both rear deer fence frames together and starting at the top, screw together with 4 - 2" screws as shown above. Screw bottom of frame down to raised bed frame with 4 - 2" screws. Complete remaining side and rear panels attachments following Steps 2 and 3.




5. Locate all three Front Deer Fence Panels (2) - 30 5/8" wide x 33 1/2" high. Designate one to be a door panel and leave to the side. Attach both outside panels as per Steps 1 - 3 except use only 3 - 2" screws to attach bottom frame. Position and install designated door panel between front panels and screw only from bottom frame into top of raised bed door frame with 3 - 2" screws as shown above.





6. Locate both **Black Plastic Hinges (3)** and attach to deer fence frame with **6 - 3/4" black screws per hinge** as shown above. Use **1/8" drill bit** to pilot hole shallow holes before attaching to avoid splitting deer fence framing. Open and close door to check door aligned correctly. Adjust as required.




7. Attach **Corner Brackets with angle cut ends - (4)** on the inside frames at the top. Use **2 - 2 1/2" screws** per bracket. Screw on an angle. Pre-drill ends with **1/8" drill bit** to prevent wood splitting.




8. Locate **Vertical Panel Supports - Long (5) - 3/4" x 2 1/2" x 45"** and **Vertical Panel Supports - Short (6) - 3/4" x 2 1/2" x 22"**. Starting with **45" long support** first, center on panel frames, flush at bottom and attach with **4 - 2" screws**. Offset the screw to either side of the support to ensure you contact the heart of the bed frame.



9. Position and attach short Vertical Panel Support using 3 - 2" screws as per Step 7. Complete remaining rear and side walls.



10. Attach Black Barrel Bolt to door and panel frame using 6 - 3/4" black screws. Note how female part of Barrel Bolt is positioned higher than male. Do a dry run first to position Barrel Bolt correctly, then attach. Pre-drill with 1/8" drill bit to prevent wood from splitting.



11. The Door Stop (I) and screws were included with your 8x12 Raised Garden Bed Kit. See Step 21 of that manual. Install the Door Stop at the top of interior panel frame as shown above.



Outdoor
Living Today

Congratulations
on assembling
your 8x12 Raised
Garden Deer
Fence Option Kit!



We hope your experience constructing our **8x12 Raised Garden Deer Fence Option kit** has been both positive and rewarding. We value your feedback and would like to hear back from you on how well we are doing in the following areas:

- 1. Customer Service**
- 2. On Time Shipping**
- 3. Motor Freight Delivery**
- 4. Quality of Materials**
- 5. Assembly Manual**
- 6. Overall Satisfaction**



The materials contained in this Assembly Manual may be downloaded or copied provided that ALL copies retain the copyright and any other proprietary notices contained on the materials. No material may be modified, edited or taken out of context such that its use creates a false or misleading statement or impression as to the positions, statements or actions.

Please call, write or email us at:

Canadian Address
9393 287th Street
Maple Ridge, British Columbia
Canada V2W 1L1

United States Address
P.O. Box 96
Sumas, Washington
USA 98295

8'x16' Deer Fence Option

Assembly Manual on Next Page



Outdoor
Living Today

ASSEMBLY MANUAL

8x16 Garden in a Box

Deer Fence Option Kit

Licensed Under US PATENTS 7,424,787; 7,490,435

Stock Code:

RB816DFO

Version #1.6

April 16, 2025

**Thank you for purchasing a 8' x 16'
Raised Garden Bed Deer Fence
Option Kit.**

**Please take the time to identify all
the parts prior to assembly.**

**Please use Safety Eyewear and Gloves
while Assembling. Be sure to read and
follow all operating instructions for any
tools used during assembly.
Remember- NO SAW CUTTING IS
REQUIRED!**

Safety Points and Other Considerations

**Please follow this instruction manual when
assembling your Raised Garden Bed Deer
Fence Option Kit and retain the manual for
future maintenance purposes.**



**Estimated Assembly Time for
the Deer Fence Kit = 1 Hour.**

CONTACT

ADDRESS

9393 287th Street,
Maple Ridge, British Columbia,
Canada V2W 1L1

PHONE & FAX

Toll Free: 1-888-658-1658

Fax:

ONLINE


Email: olmsupport@outdoorlivingtoday.com

Web: www.outdoorlivingtoday.com

Exploded View and Parts List for 8x16 Raised Bed Deer Fence Option Kit

Parts List

- Part 1** 10 pcs - Side/Rear Deer Fence Panels (46"wide x 33 5/8"high)
- Part 2** 3 pcs - Front Deer Fence Panels (30 5/8"wide x 33 1/2"high)
- Part 4** 4 pcs - Corner Brackets (angle cut ends) (1 1/2" x 1 1/2" x 24")
- Part 5** 7 pcs - Vertical Panel Supports - Long (3/4" x 2 1/2" x 45")
- Part 6** 7 pcs - Vertical Panel Supports - Short (3/4" x 2 1/2" x 22")



Hardware Kit (Provided)

2 1/2"  8 pcs

2"  146 pcs



#2 Square Drive Bit x 1 pc



Black Plastic Butt Hinge - 2 pcs

3/4"  18 pcs
Black

Tools Required (Not Provided)



Screw Gun/Drill



1/8" Drill Bit



Level



Tape Measure



Wood Clamp



Hammer


Safety Equipment Required (Not Provided)



Safety Glasses



Work Gloves




Level

204 3/8"

We recommend filling your raised bed with soil prior to installing your Deer Fence Option Kit.


1. Prior to installing your Deer Fence Option Kit, confirm your 8x16 Raised Bed is level and square. Measure diagonally inside corner to corner (approximately 204 3/8") in both directions. Adjust as required. Use a level to determine if the tops of the bed frames are sloped and adjust if necessary.




Expert Advise:
Use a Wood Clamp when positioning and attaching deer fence panels together.

Position frames so they are even.

2. Starting in rear corner, position the frame of a Rear Panel (1) - 46" wide x 33 5/8" high directly on top of the raised bed frame. Screw frames together with 4 - 2" screws as shown on the left. Install panels with the 1 1/2" thick side on top.




3. Position a **Side Panel (1)** - 46" wide x 33 5/8" high directly on top of the side raised bed frame. Hold both deer fence frames together and starting at the top, screw together with **5 - 2" screws** as shown on the left. Screw bottom of frame down to raised bed frame with **4 - 2" screws**.




4. Position a second **Rear Panel (1)** - 46" wide x 33 5/8" high on top of the rear raised bed frame. Hold both rear deer fence frames together and starting at the top, screw together with **4 - 2" screws** as shown above. Screw bottom of frame down to raised bed frame with **4 - 2" screws**. Complete remaining side and rear panels attachments following **Steps 2 and 3**.






5. Locate all three **Front Deer Fence Panels (2)** - 30 5/8" wide x 33 1/2" high. Designate one to be a door panel and leave to the side. Attach both outside panels as per **Steps 1 - 3** except use only **3 - 2" screws** to attach bottom frame. Position and install designated door panel between front panels and screw only from bottom frame into top of raised bed door frame with **3 - 2" screws** as shown above.





6. Locate both **Black Plastic Hinges (3)** and attach to deer fence frame with **6 - 3/4"** black screws per hinge as shown above. Use **1/8"** drill bit to pilot hole shallow holes before attaching to avoid splitting deer fence framing. Open and close door to check door aligned correctly. Adjust as required.



7. Attach **Corner Brackets with angle cut ends - (4)** on the inside frames at the top. Use **2 - 2 1/2"** screws per bracket. Screw on an angle. Pre-drill ends with **1/8"** drill bit to prevent wood splitting.




8. Locate Vertical Panel Supports - Long (5) - 3/4" x 2 1/2" x 45" and Vertical Panel Supports - Short (6) - 3/4" x 2 1/2" x 22". Starting with 45" long support first, center on panel frames, flush at bottom and attach with 4 - 2" screws. Offset the screw to either side of the support to ensure you contact the heart of the bed frame.





9. Position and attach short Vertical Panel Support using 3 - 2" screws as per Step 8. Complete remaining rear and side walls.





10. Attach Black Barrel Bolt to door and panel frame using **6 - 3/4" black screws**. Note how female part of Barrel Bolt is positioned higher than male. Do a dry run first to position Barrel Bolt correctly, then attach. Pre-drill with 1/8" drill bit to prevent wood from splitting.



11. The **Door Stop (I)** and screws were included with your 8x16 Raised Garden Bed Kit. See **Step 21** of that manual. Install the Door Stop at the top of interior panel frame as shown above.



Outdoor
Living Today

Congratulations
on assembling
your 8x16 Raised
Garden Deer
Fence Option Kit!



We hope your experience constructing our **8x16 Raised Garden Deer Fence Option kit** has been both positive and rewarding. We value your feedback and would like to hear back from you on how well we are doing in the following areas:

- 1. Customer Service**
- 2. On Time Shipping**
- 3. Motor Freight Delivery**
- 4. Quality of Materials**
- 5. Assembly Manual**
- 6. Overall Satisfaction**



The materials contained in this Assembly Manual may be downloaded or copied provided that ALL copies retain the copyright and any other proprietary notices contained on the materials. No material may be modified, edited or taken out of context such that its use creates a false or misleading statement or impression as to the positions, statements or actions.

Please call, write or email us at:

Canadian Address
9393 287th Street
Maple Ridge, British Columbia
Canada V2W 1L1

United States Address
P.O. Box 96
Sumas, Washington
USA 98295