





Assembly Instructions




General assembly guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- V. The three main types of hardware used to assemble this product are wood dowels, screws and bolts.
- V. A hammer, Phillips head and Slotted head screwdrivers are required for the assembly of this product.



- V I. Power tools should not be used to assemble this product.

















Parts List




Part#	Description	Qty
1	Headboard Left Foot	1
2	Headboard Right foot	1
3	Footboard Left Foot	1
4	Footboard Right foot	1
5	Back side rail	1
6	Front Side Rail	1
7	Upper Rail / Lower Rail	2
8	Middle Slat (HEADBOARD)	2
9	Head/Foot Rail	2



Part#	Description	Qty
10	Central Foot	3
11	Central Support	1
12	Union Support	3
13	Set Slat	4

Hardware List

A	 Ø1/4*100mm	Bolt (Head 13)	08 pcs	
B		1/4mm	Barrel nut	08 pcs
C		Ø10*40mm	Wooden dowel	24 pcs
D		Ø10*30mm	Wooden dowel	16 pcs
E	 Ø7*100mm	Bolt (Head 13)	8 pcs	
F	 Ø7*60mm	Bolt (Head 13)	06 pcs	
G	 Ø4*35mm	Screw	16 pcs	
H	 Ø4*25mm	Screw	12 pcs	
I	 Ø3,5*16mm	Screw	08 pcs	
J			Hex Key	01 pcs
K			Corner Brace	02 pcs
L	 Ø3/16*1 1/2	Screw	02 pcs	
M	 Ø3/16	Nut	02 pcs	
N	 Ø3/16	Washer	02 pcs	





Hammer recommended for assembly (not included)



Phillips head and slotted head screwdrivers are required for assembly (not included)




The hardware quantities listed above are required for proper assembly. Some extra hardware may also have been included.

Step 1



Insert wood dowel (C) into parts (5,6,7,8 and 9).




Step 2



HEADBOARD



Secure part 1 to parts 7, 8, and 9 with screw (E) using Hex Key (J).

Step 3


E**3**

Secure part 2 to parts 7, 8, and 9 with screw (E) using Hex Key (J).

Step 4

H**12**





Pre Drilled Holes



HEADBOARD

Secure part 12 to headboard with screw (H) using phillips head screwdriver.





Step 5



FOOTBOARD

Secure part 4 to part 9 with screw (E) using Hex Key (J).





Step 6



FOOTBOARD

Secure part 3 to part 9 with screw (E) using Hex Key (J).





Step 7



HEADBOARD


Secure hardware (K) to headboard with screw (I) phillips head screwdriver.

Step 8




FOOTBOARD



Secure hardware (K) to footboard with screw (I) phillips head screwdriver.



Step 9



In this step, please do not tighten the screw all the way.




HEADBOARD





Secure parts 5 and 6 to headboard with screw (A) and barrel nut (B) using Hex Key (J).

Step 10



In this step, please do not tighten the screw all the way.






FOOTBOARD





Secure part 5 and 6 to legs 3 and 4 with screw (A) and Barrow nut (B) using hex key (J).

Step 11






Secure part 11 to parts 10 with screw (F) using Hex Key (J).



In this step please tighten all screws to the end.






Step 12




Secure part 11 to support (K) with screw (L) and washer (N) and nut (M) using slotted head screwdriver.

Step 13




Insert wooden dowel (D) as shown in the diagram.

Step 14







In this step, distribute sets of Slats 13 using the applied dowels as guides.



Insert the set of slats 13 as shown in the diagram.

Step 15



Secure the set of slats 13 with screw (G) using phillips head screwdriver.

Step 16

