




ASSEMBLY INSTRUCTIONS



Tools Recommended

THIS INSTRUCTIONS CONTAINS IMPORTANT SAFETY INFORMATION.
PLEASE READ BEFORE ASSEMBLY AND KEEP FOR FUTURE REFERENCE.

IMPORTANT NOTICE



- This product contains small components, please ensure that they are kept away from small children.
- THIS INSTRUCTIONS CONTAINS IMPORTANT SAFETY INFORMATION. PLEASE READ BEFORE ASSEMBLY AND KEEP FOR FUTURE REFERENCE.
- Read each step carefully. It is very important that each step of instruction is performed in the correct order. If these steps are not followed in sequence, assembly difficulties will occur.
- Make sure all parts are included. Most parts are labelled or stamped on the raw edge.
- Work in spacious area, preferably on a carpet, near the place the unit will be used.
- Do not use power tools to assemble your furniture. Power tools may strip or damage the parts.
- Move your new furniture carefully, with two people lift and carry the unit to it's new location.
- Never push, drag or pull your furniture (especially on carpet)

















PLEASE DO NOT RETURN PRODUCT TO US IMMEDIATELY

If a part is missing or damaged, email our customer service. We will gladly ship your replacement parts FREE of charge.

For Prompt, reliable service, please have your assemble instruction ready.


 WARNING	
	<p>Children have died from furniture tipover. To reduce the risk of furniture tipover:</p> <ul style="list-style-type: none">• ALWAYS install tipover restraint provided.• NEVER put a TV on this product.• NEVER allow children to stand, climb or hang on drawers, doors, or shelves.• NEVER open more than one drawer at a time.• Place heaviest items in the lowest drawers.
	



- | | | | |
|---|--|---|---|
|  <p>A x 12
M6 x 35 mm</p> |  <p>B x 12
Ø15 x 10 mm</p> |  <p>C x 12
Ø6 x 30 mm</p> |  <p>D x 8
M4 x 40 mm</p> |
|  <p>E x 16</p> |  <p>F x 16
M4 x 12 mm</p> |  <p>G x 2</p> |  <p>H x 2</p> |
|  <p>I x 4
M4 x 20 mm</p> |  <p>J x 6
Ø35 mm</p> |  <p>K x 8</p> |  <p>L x 36
M3.5 x 12 mm</p> |




Step 1

Lock screw A on the part 2 and 3. The installation position is as shown in the figure below.





Step 2



Put eccentric B into the corresponding hole in the part 9 and tighten the part 2 and 9 by turning it clockwise with a screwdriver. The following figure shows the installation position.




Step 3



Insert the dowel C into part 4 first, then assemble parts 2 and part 4, put the eccentric B into the corresponding hole and use a screwdriver to turn it clockwise to tighten. The installation position is as shown below.




Step 4






Insert the part 10 into the slots of the parts 4 and 9. The installation position is as shown below.

Step 5




Insert the dowel C into part 4 first, then assemble parts 3,4 and part 9, put the eccentric B into the corresponding hole and use a screwdriver to turn it clockwise to tighten. The installation position is as shown below.






Step 6

Insert the part 10 into the slots of the parts 2,3 and 9. The installation position is as shown below.






Step 7

Insert the dowel C into part 2 and 3 first, then assemble part 1 and part 2,3. Assemble Part 1 with Parts 2 and 3 with screw D. The installation position is as shown in the figure below.




Step 8


Insert the dowel C into part 2 and 3 first, then assemble part 6 and part 2,3. Assemble Part 6 with Parts 2 and 3 with screw D. The installation position is as shown in the figure below.



Step 9


Lock the part 11 to the part 4 with screw F. The following figure shows the installation position.



 F x 16
M4 x 12 mm

Step 10







First install the movable laminate support K on the parts 2 and 3, and then place the part 5 on the movable laminate support K. The following figure shows the installation position.



 K x 8




Step 11

Use screw I to lock the door handle H to the parts 7 and 8 first, then use screw L to lock the hinge J to the parts 7 and 8. The following figure shows the installation position.





Step 12

Screw L and hinge J are used to lock the part 7 and 8 on the part 2 and 3 respectively, and then adjust the hinge position with a screwdriver according to the actual situation, as shown in the figure.





Step 13

Use the small screws in the hardware bag G to lock the piece of iron to the part 1.
The following figure shows the installation position.








Step 14

Lock the backplane buckle E to the four corners of the backplane.
The following figure shows the installation position.



Step 15



First knock the expansion screws in hardware G into the wall with a hammer, and then use the long screws in hardware G to pass through the iron sheet and lock into the expansion screws in the wall. The following figure shows the installation position.

Step 16

