










STEP 23




SP6-15

STEP 24








SP6-15

STEP 25




STEP 26









SP6-15


 SP6-15
 20 pcs

STEP 28




STEP 29




STEP 30

For Front Door




STEP 31


For Front Door



STEP 32




STEP 33







STEP 34



Refer to STEP 32 to install the D2-5.





STEP 35






x2

	
M6-55 20 pcs	M6 20 pcs


STEP 36





x2





		
M6-55	SP6-15	M6
2 pcs	2 pcs	2 pcs



STEP 37



	
M6-15	M6
2 pcs	2 pcs






STEP 38







	
SP6-20	SP6-15
12 pcs	12 pcs

STEP 39





Place the triangular panel assembled in STEP 34 (as shown in the figure) in the corresponding position on the walls.







			
M6-15	M6	Z6	M5-8
2 pcs	2 pcs	2 pcs	6 pcs

STEP 40

Place the triangular panel assembled in STEP 36 in the corresponding position on the walls.







Note: Before installing the screws, please make sure that E1-1 is snapped into the corresponding position.)





			
M6-15	M6	Z6	SP6-20
2 pcs	2 pcs	2 pcs	2 pcs

STEP 41

Install E2-1 first and then place the triangular panel assembled in STEP 37 in the corresponding position on the wall.





Note: Before installing the screws, please make sure that E2-1 is snapped into the corresponding position.)




			
M6-15	M6	Z6	SP6-20
2 pcs	2 pcs	2 pcs	4 pcs





STEP 42

Place the triangular panel assembled in STEP 34 (as shown in the figure) in the corresponding position on the walls.










Note: Before installing the screws, please make sure that E1-1 is snapped into the corresponding position.





			
M6-15	M6	Z6	SP6-20
2 pcs	2 pcs	2 pcs	2 pcs


STEP 43

Place the assembled triangle panel on the corresponding position of the wall panel.




	
SP6-20	M5-8
8 pcs	6 pcs





STEP 44



1




2




x2

		
M6-10	M6	SP6-15
4 pcs	4 pcs	28 pcs


STEP 45





1. Place one end of the 10-D2-7 into the corresponding position and tilt the other end into place.






2. Once the holes are aligned, install M6-25 and M6.






	
M6-25	M6
12 pcs	12 pcs


STEP 46




x4






x2




STEP 47







Note the mounting direction of D4.




STEP 48




After placing 10-D1 and 10-D3 on the triangular panels, align them with the grooves of the triangular panels and push them forward.








D4 should fit perfectly on the tripod.






 SP6-20
 36 pcs



STEP 49










STEP 50





STEP 51





	
SP6-20	SP6-35
82 pcs	6 pcs

STEP 53





SP6-25




SP6-25
16 pcs


STEP 54



STEP 55




Do not push in hard when there is an obstruction, rotate DZ to adjust.






Push DZ completely down below, ensuring the bottom surface is level.

STEP 56





SP6-20
6 pcs

STEP 57




SP6-20
12 pcs


STEP 58




Take the **door** inside.
Push it forward into position.




Push it into the groove of the floor.








Press the DZ downwards.





Tilting the **door** and
snapping it into the DDZ.




After inserting the DDZ, push the
door to the fitting position.







	
SP6-20	M5-12
4 pcs	4 pcs

STEP 60



Two people are needed. One person closes the door and inserts the pin, while the other person adjusts the gap outside the door. After making sure the gap is even, the person inside installs DDZ screws SP6-20.



	
SP6-20	M5-12
8 pcs	4 pcs

- In case of fire, do not attempt to extinguish any burning polypropylene with water. Unsuitable for storage of flammable or corrosive substances.
- It is of utmost importance to assemble all of the parts according to the directions. Do not skip any step.
- Please consult your local authorities if any permits are required to erect shed.
- Periodically check shed to assure that it remains stable and that the site remains level.
- It is highly recommended to secure the shed to an immovable object or to the ground by drilling holes in the floor at the pre-marked locations and inserting proper screws into the ground (size: 1.9"-3" ,screws are not included).
- Wear safety-goggles and always follow the manufacturer's instructions when using power tools.
- Wash shed with garden hose or a mild detergent solution. Using a stiff brush or abrasive cleaner could damage shed.
- Hot items such as recently used grills, blowtorches, etc. must not be stored in the shed.
- Heavy articles should not be leaned against the walls, as this may cause distortion.
- Keep roof clean of snow and leaves. Heavy amounts of snow on roof can damage the shed making it unsafe to enter.
- Although wind direction varies, it is an important factor when taking into account where to place your shed. Therefore, it is recommended to reduce wind exposure of the shed in general, and the door side in particular.
- Keep doors closed and locked to prevent wind damage.
- Do not stand on the roof.