



ASSEMBLY INSTRUCTIONS



Before You Start


1. Read through each step carefully and follow the proper order. Separate and count all your parts and hardware.
2. Give yourself enough room for the assembly process.
3. Please place the product on empty cardboard box or carpet to avoid scratches on it.
4. If possible, please find a partner to help you with assembly, which can accelerate assembly.
5. Keep all small parts of this product away from children. They may cause serious injury.
6. Have the following tools: Flat Head Screwdriver, #2 Phillips Head Screwdriver and Hammer.




Caution: If using a power drill or power screwdriver for screwing, please be aware of to slow down and stop when screw is tight. Failure to do so may result in stripping the screw. (Assembly speed can be increased by using electric screwdriver)

HOW THE KNOCK DOWN (KD) ASSEMBLY SYSTEM WORKS





















1. Screw the Cam Bolt into the pre-drilled hole on the panel. Make sure Cam Bolt goes into the pre-drilled hole on the end of panel for Cam Lock.
2. Insert the Cam Lock into the pre-drilled large hole on the panel. Make sure the arrow on the face of Cam Lock points towards Cam Bolt.
3. Take a Phillips screwdriver and rotate the Cam Lock clockwise to lock the Cam Bolt.
4. Use the sticker to conceal the Cam.















PARTS LIST





HARDWARE LIST



A		Ø6x35mm	Cam bolt	24 pcs
B		Ø15x9mm	Cam lock	24 pcs
C		Ø30mm	Cam cover	24 pcs
D		Ø8x30mm	Wooden dowel	30 pcs
E			Plastic wedge	4 pcs
F		Ø3x17mm	Flat-head screw	4 pcs
G		Ø4x38mm	Screw	10 pcs
H		M 4	Hex key	1 pc
I			Knob	2 pcs
J		Ø4x22mm	Knob bolt	2 pcs
K		12"	Left cabinet member	2 pcs
L		12"	Right cabinet member	2 pcs
M		12"	Left drawer runner	2 pcs
N		12"	Right drawer runner	2 pcs
O		57x20x20mm	Plastic connector	4 pcs
P		Ø6x13mm	Bolt	8 pcs
Q			Power strip with USB	1 pc
R		Ø3.5x12mm	Screw	26 pcs
S		Ø5x35mm	Screw	8 pcs
T		Ø6x50mm	Screw	4 pcs

STEP 1








STEP 2

 **Bx4**  **Dx4**






STEP 3

	
Dx8	Sx8






STEP 4





Note the CL or CR stamped label on the track!

STEP 5



Note the CL or CR stamped label on the track !


STEP 6





STEP 7


Bx8




Ix2


Jx2



Mx2


Nx2




Rx12





x2




STEP 8

 
Dx4 Bx4









STEP 9

Dx4 Ox4 Px4 Tx4 Hx1







STEP 10

 **Dx4**  **Bx4**










STEP 11







Note the hole direction.





STEP 12

 **Dx6**  **Bx4**  **Gx2**







STEP 13



			
Ex4	Fx4	Qx1	Rx2



STEP 14



STEP 15



· Stick stickers (C) on cam locks (B).

Final Assembly