

Rainbow Metal Bistro Set - Table and Two Chairs



Assembling & Using Your Product

Unpack all components carefully. Check the packaging to ensure that you have removed all of the parts.

Components


- A Metal Chair (x2)
- B Metal Table

- C Replacement Corner Protectors (x2)
- D Replacement Glides (x4)

Assembly


Chairs

1. Stand the chair upright on its front feet.
2. Grasp the back of the chair with one hand. With the other hand, grasp the bar of the seat (behind the chair back) and slide it down.



Table

1. Stand the table upright on the feet closest to the tabletop.
2. Grasp the top and bottom edges of the tabletop. Pivot the tabletop upright, allowing the outer legs to swing out. Ensure that the hinges below the table lock into position.



Troubleshooting & Caution

If you have any questions or problems, please contact the retail store where you purchased this table and chair set.

If the glides under the feet are damaged

- Pull the damaged glide out of the hole, then insert a new glide.

If the corner protectors on the rear bar of the seat are damaged

- Be very careful not to pinch your finger while replacing a corner protector!
 1. Partially fold the chair.
 2. Pull the damaged corner protector off the rear bar.
 3. Slide the replacement corner protector fully onto the rear bar.



Caution

- The maximum weight capacity of each chair is 264 lbs (120 kg).
- The maximum weight capacity of the table is 176 lbs (80 kg).
- Do not stand on the seat of a chair.
- Do not stand on the table.
- Do not allow children to fold or unfold the table or chairs.
- Do not allow fingers to be pinched between parts of the table or chairs.

Limited Warranty Information

Thank you for choosing our product! We aim to please with our wide range of products including Fountains, Birdbaths, Statuary, Pond Supplies, and More. All of our products are constructed from the highest quality materials. In the event that we have not achieved our usual standard of excellence, we will repair or replace, at our discretion, within the warranty period. A valid proof of purchase, with the purchase date clearly indicated, must be provided. Photos of defective merchandise will also be required to help distinguish the actual cause of the defect. Please read below for a detailed description of warranty coverage.

- **Water Damage**

The products are not manufactured to withstand extreme temperatures. Improper storage that allows water to freeze within a product may cause damage and is considered negligence and will, therefore not be covered under this warranty. The use of "hard water" and/or caustic cleaners can affect the paint or other finishes. Failure to keep the unit clean, and use of such additives/cleaners, will also void the warranty. Please note: for fountains, it is normal for some splashing to occur and protecting the immediate surfaces is not the responsibility

- **Paint & Color (Retention and/or Loss)**

The use of water will cause natural erosion to the color. This area can be touched up using standard paint. The paint is designed to protect the entire finish against breakdown of color. As with any product, all finishes with time will gradually fade and discolor. The warranty will only cover against severe or complete fading within the first year from date of purchase with the above exclusion.

- **Procedure/Service**

Should a warranty/claim be needed, you should contact the retailer from whom you purchased the product. You must be prepared to show proof of purchase, provide photographs and any other information needed to validate your claim. This may be necessary to distinguish between a partial or complete replacement of a defective product. The warranty does not cover any items with multiple parts; the warranty will ONLY cover the individual component of the unit/item that may be defective. Replacement parts can be made available to a consumer through the original selling party, or an approved parts retailer. If this is not an option, contact our customer service department. Item is covered under one year limited warranty from the date of purchase. When requesting replacement parts due to a warranty claim after 30 days of purchase, credit card information will be requested for shipping charges.

- **Not Covered Under Warranty**

The limited warranty will NOT cover cases of damages due to

1. Damages caused in Transit
2. Inadequate care and/or neglect
3. Environmental and/or natural elements
4. Immersion in water, unless specified
5. Improper Installation/Storage and/or Maintenance

This warranty is void if the product has been damaged by accident, misuse, negligence, improper installation and/or modifications have occurred. This includes any and/or all defects arising out of freezing water damage, hard water damage, failure to keep the unit clean and free of harmful additives such as bleach, chlorine, etc., which affect the paint and/or parts. This warranty also does not cover any additional charges or installation, removal, disposal and/or shipping costs or consequential damage associated with any warranty claim.