






# Installation & Assembly


Version: 1.0




**EN\_IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.**




**EN\_QUICKFIT:** Tighten quickfit until shoulder is flush with panel. Do not overtighten or undertighten.













**EN\_CAM LOCK:** When fitting cam lock, ensure starting position is correct before you insert connecting quickfit.







**EN\_Quickfit** head should be in the centre of the cam lock when the two panels are joined.  
Cam lock should be inserted before quickfit.














**EN\_Turn** cam lock clockwise to tighten.

NO.	PARTS	QTY	SPARE
1		x1	
2		x1	
3		x1	
4		x1	
5		x1	
6		x1	
7		x1	
8		x2	
9		x7	
10		x1	


NO.	PARTS	QTY	SPARE
11	   Hardware Kit	x2	
12		x1	



 <p><b>A</b> x26 Ø6x35mm +2(spare)</p>	 <p><b>B</b> x26 Ø15x10mm +2(spare)</p>	 <p><b>C</b> x52 Ø6x30mm +3(spare)</p>	 <p><b>D</b> x32 Ø4x35mm +3(spare)</p>	 <p><b>E</b> x4 Ø10x3mm +2(spare)</p>	 <p><b>F</b> x2 Ø4x12mm</p>
<p><b>G1</b></p>  <p><b>G2</b></p>  <p><b>G</b> x14 Ø3x16mm +1(spare)</p>	 <p><b>H</b> x36 Ø20mm +4(spare)</p>	 <p><b>I</b> x2 Ø6x30mm</p>			




**01**



B x4




C x8



D x4


Ø4x35mm



B x6






C x12



D x6

Ø4x35mm






C x8

D x8

Ø4x35mm



Notice

6



C x8



09



**Note: At least two people are required for this step.**




**Notice**



**Attention: Which side of the back panel on the 10th and 11th has the same color as the cabinet, facing towards the front of the cabinet.**

D x8  
Ø4x35mm






Notice


C x8

E x4

F x2  
Ø4x12mm







Notice

7

Notice

12





**Attention: Board 8 is shorter than Board 7 and Board 12**

B x3






90°



G x14


G1

G2





Please ask users to use hole stickers according to their own appearance requirements "H".




D x2

I x2



(1)x2



First, use a ruler to measure the approximate height of the product on the wall, and then mark it with a pen.

(2)x2


WALL  
+  
drilling hole  
Ø6x30mm



Then use a tape drill to make holes in the wall that are suitable for the product screws.

(3)x2


WALL I



Then, put the expansion bolt into the hole

(4)x2

WALL



Finally, pass the matching screws through the "anti-rewind" and tighten them to fix them on the wall.

