


# ASSEMBLY INSTRUCTIONS SS16303BK

10'X12' Attached Pergola


































Thanks for choosing our product. Please kindly check parts listed below and read this manual carefully, then assemble them step by step. Please feel free to contact us for any questions.




## Attention

1. We care about every customer's using experience, please feel free to chat us if has anything missing or damaged or any advice, efficient solution would be offered soon.
2. Recommend 3-4 person to assemble together.
3. Please use ladder when you install the top.
4. Please keep your children away when you assembly. This item contains small parts which can be swallowed by children.


## Parts List

<b>A</b> X2  Top Back Leg	<b>B</b> X2  Top Front Leg	<b>C</b> X4  Bottom Leg	<b>D</b> X4  Side Beam
<b>D1</b> X2  Middle Beam	<b>E</b> X14  Board Arm	<b>F</b> X12  Board Protection	<b>G</b> X6  Middle Board Connection
<b>H</b> X7  Arm Connection	<b>I</b> X2  Arm Hold Tube(Side)	<b>I1</b> X1  Arm Hold Tube(Middle)	<b>J</b> X2  Arm Hold Tube Connection
<b>K1</b> X6  Back UV Protected Board	<b>K2</b> X6  Front UV Protected Board	<b>L</b> X4  Leg Connection	<b>M</b> X10  Wall & Beam Connection
<b>N</b> X4  Back Connection	<b>O</b> X1  Right Beam Hold	<b>P</b> X1  Left Beam Hold	<b>Q</b> X14  Arm & Beam Connection
<b>R</b> X14  Arm Protection	<b>S</b> X7  Arm Up Connection	<b>T</b> X7  Arm Down Connection	<b>U</b> X4  Beam Plug
<b>V</b> X16  Hold Plug	<b>W</b> X153  Bolt M6*5mm	<b>X</b> X21  Bolt M6*35mm	<b>Y</b> X16  Bolt M6*15mm
<b>Z1</b> X28  Bolt M6*40mm	<b>Z2</b> X8  Bolt M6*70mm	<b>Z3</b> X1  Allen Wrench	<b>Z4</b> X1  Middle Wall Connection
<b>Z5</b> X6  Expansion Bolts			


STEP1





A		X2
B		X2
C		X4
L		X4
W		X32







STEP2



STEP3




D		X4
N		X4
W		X32
D1		X2

STEP4


Y










X16




STEP5








O		X1
P		X1
W		X9
Z4		X1





STEP6







S		X7
T		X7
Z1		X28
E		X14




STEP7



Q		X14
X		X14
W		X28
H		X7

## STEP8




**TIPS:** Part Q is used by slotted holes that please use the same sides of both holes to make top side of Q higher than Part D . Slotted holes will support the cover board more strongly.

W



X28

## STEP9



I1



X1

I



X2

W



X8

J




X2

## STEP10

X



X7





## STEP11




K1




X6




STEP12

R		X7
W		X7
F		X6






STEP13

G



X6



G



Up the side with  
leaking hole

STEP14




K2




X6








STEP15

R		X7
W		X7
F		X6



STEP16

U		X4
V		X16



STEP17

Z5  X6

