ASSEMBLY INSTRUCTIONS



Serious or fatal crushing injuries can occur from furniture tip over. To prevent tip over this furniture must be used with the wall attachment device(s) provided. The screw(s) and plug(s) for the wall are not suitable for all wall types. Use screw(s) and plug(s) suitable for your walls. If you are uncertain, seek professional advice. Read and follow each step of the instructions carefully.

This furniture must be installed with the Wall Mount – Anti-Tip Kit to prevent serious or fatal injuries.



Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install anti-tip device provided.
- NEVER put a TV on this product. •
- NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves. •
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

ASSEMBLY INSTRUCTIONS



Prepare for Installation

- Use an 8mm drill bit (not included) for Step 3.
- Use a 16/17mm wrench (not included) for Step 4. Note: the Hex Bolt head diameter is 10mm
- · Ensure the product is on a flat, level surface. Features may not function properly on sloped or uneven surfaces.
- · Wall Mount must be mounted directly into a concrete wall or stud.





Locate the two holes on the back of the product,

one in the top-left corner and one in the top-right.

• Insert Part A and Part B into their respective holes.

Step 2

Locate the Wall Stud

- Position the product against the wall to determine anchor points.
- Use a stud finder to locate the wall stud and mark the attachment points in pencil.
- Measure to ensure the distance between the marks matches the distance between the straps on the product.



• Tighten securely using Part E.

Drill Holes

- aligned with the pencil marks from Step 2. These holes will be used to
- included) will be needed to tighten Part D properly. install Part C.



Secure the Product to the Wall

Use Part D to securely fasten

of the product. A wrench (not

Part A to the wall from the back



Final Check The wall mount is now installed, and the product is ready for use.

· Drill two holes in the wall