

LED FLUSH MOUNT

INSTRUCTIONS PERTAINING TO RISK OF FIRE OR INJURY TO PERSONS
READ ALL INSTRUCTIONS



IMPORTANT SAFETY INSTRUCTIONS
SAVE THESE INSTRUCTIONS

TOOLS AND MATERIALS REQUIRED:




Wiring supplies as required by electrical code




SAFETY PRECAUTIONS:

1. **TURN OFF ELECTRICAL POWER BEFORE STARTING INSTALLATION OF LIGHT FIXTURE.**
2. **THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.**
3. **CAUTION - RISK OF ELECTRIC SHOCK. CONSULT A QUALIFIED ELECTRICIAN TO ENSURE CORRECT BRANCH CIRCUIT CONDUCTOR.**
4. **WARNING, THIS IS A LINE VOLTAGE MODEL AND DOES NOT AND CANNOT USE A DRIVER.**
5. **LINE VOLTAGE MODELS ALREADY HAVE A POWER SUPPLY CHIP BUILT INTO THE LED ARRAY.**


INSTALLATION




1. Remove plastic lens by gently rotating the decorative knobs counter-clockwise and remove metal ring, then lift the lens.




2. Put the fixture in your desired location and match the metal pan center wire hole to the electrical box for wire connection for marking the screw holes.




3. After confirming the fixture location and marking the 4 screw holes, remove fixture metal pan, and drill the screw holes for screw anchors application.



4. Using wire nuts to connect ground wire (green) from fixture and LED board to ground wire from electrical box. Connect black wire from fixture to black wire from electrical box. Connect white wire from fixture to white wire from electrical box.



5. Then drive screws in halfway and put the metal pan back to screws key slot location. You may adjust magnet PCB board light source. Secure fixture by tightening mounting screws.



6. Place acrylic lens over the fixture pan. Place the metal ring over the acrylic lens lining up the holes with the fixture pan posts and then secure it with the decorative knobs included.