



Assembly Instructions




Please visit our website for the most current instructions, assembly tips, report damage, or request parts.

General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are: wood dowels, screws and bolts.
- V. The provided glue is to secure wood dowels in place. When first inserting dowels, locate the appropriate hole for the dowel, place a small amount of glue in the hole and insert the dowel. Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together, place a small amount of glue on the end of the dowel before attaching parts together. Wipe away excess glue immediately.



- VI. A Phillips head screwdriver is required for the assembly of this product .




- VII. Power tools should not be used to assemble this product.























- VIII. Drill may be needed for securing product to wall.

Parts List



Hardware List


A		Ø8x30mm	Wooden dowel	32 pcs
B		Ø6x35mm	Cam bolt	29 pcs
C		Ø15x11mm	Cam lock	29 pcs
D		Ø6x50mm	Screw	6 pcs
E		Ø4x38mm	Screw	4 pcs
F			Glue tube	1 pc
G		Ø6x12mm	Bolt	8 pcs
H		Ø4x12mm	Screw	12 pcs
J			Handle	2 pcs
K		Ø4x22mm	Screw	4 pcs
L			Shelf support pin	8 pcs
M			Plastic wedges	8 pcs
N		Ø3x17mm	Screw	8 pcs
P			Pulley	4 pcs
Q			Door Guide	4 pcs
R			L shape bracket	2 pcs
S		Ø4mm	Hex key	1 pc
T		Ø30mm	Sticker	29 pcs
U		F18V66L	Fireplace Insert	1 pc



Philips head screwdriver required for assembly
(not included)


*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*

Step 1





Insert wooden dowel (A) into part(19,2), use screwdriver secure cam bolt(B) into part(1).

Step 2





Insert wooden dowel (A) into part (3, 4, 5, 6), use screwdriver secure cam bolt (B) into part (3, 4, 5, 6, 11, 12).

Step 3




Insert wooden dowel(A) into part(7,8,9,10).

Step 4





Secure parts (3,5) to part(9) and part (4,6) to part (10) using cam locks (C).

Step 5




Insert screw (E) to secure part(11,12) to part (21).

Step 6




Insert cam lock(C) to part (7,8) and attach to part(11,12).

Step 7





Attach part (22) to part (2) using hex key (S) and screw (D).

Step 8




Attach parts (7,8) to part (2) using hex key (S) and screw (D).

Step 9





Insert cam lock(C) into part (2, 19), then attach part (2, 19) to part (3,5,4,6).

Step 10




Slide part(20) into the groove as per diagram.

Step 11




Insert top panel (1) into side panels (9, 7, 8, 10) and fireplace faceplate(19), then insert and secure cam lock (C) to side panels (9, 7, 8, 10) to lock it.

Step 12




Place sticker (T) as per diagram .

Step 13




Use screwdriver to secure screw (N) into plastic wedges (M) into back panel (20).

Step 14





Slide fireplace (U) as per diagram.

Step 15




Use screwdriver to secure the L-shape bracket(R) to the side panel (8).

Step 16




Use screwdriver to secure the L-shape bracket(R) to the side panel (7).

Step 17




Insert shelf support pin (L) into side panels as per diagram and slide shelf onto the support pin.

Step 18




Insert bolt (G) ,screw (H,K) into part (17,18) to secure pulley(P), handle(J), door guide (Q).

Step 19



Place door (17,18) into bottom slide groove and attach to the frame with pulley(P).

Step 20



Final Assembly